UPS IST6

120kVA Series

User Manual





www.aecups.com

Copyright © Allis Electric Co., Ltd. 2021.All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Allis Electric Co., Ltd.

Trademarks and Permissions

AEC trademarks are trademarks of Allis Electric Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Allis Electric and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specification in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

User Manual Foreword

Foreword

Summaries

Thank you for choosing the UPS!

This document gives a description of the IST6 120KVA, including the features, performance, appearance, structure, working principles, installation, operation and maintenance, etc.

Please save the manual after reading, in order to consult in the future.



The figures in this manual are just for reference, for details please see the actual product.

Suitable Model

• IST6 120KVA

Symbol Conventions

The manual quotes the safety symbols, these symbols used to prompt users to comply with safety matters during installation, operation and maintenance. Safety symbol meaning as follows.

Symbol	Description
DANGER	Alerts you to a high risk hazard that could, if not avoided, result in serious injury or death.
MARNING	Alerts you to a medium or low risk hazard that could, if not avoided, result in moderate or minor injury.
CAUTION	Alerts you to a potentially hazardous situation that could, if not avoided, result in equipment damage, data loss, performance deterioration, or unanticipated results.
	Anti-static prompting.
A	Be care electric shock prompting.

Symbol	Description
©—" TIP	Provides a tip that may help you solve a problem or save time.
□ NOTE	Provides additional information to emphasize or supplement important points in the main text.

Product standard: Q/ZZKJ 007

Contents

1 Safety Description	1
1.1 Safety Announcements	1
1.1.1 Safety Instructions	1
1.1.2 Use Announcements for Battery	4
1.1.3 ESD Protection.	5
1.1.4 Grounding Requirements	5
1.1.5 Warning Mark Setting	5
1.2 Operation and Maintenance Requirements	5
1.3 Environment Requirements	7
2 Overview	8
2.1 Product Intro	8
2.1.1 Model Meaning	8
2.2 Features	9
2.3 Working Principle	11
2.3.1 Schematic Diagram	11
2.3.2 Working Mode	11
2.4 Appearance and Structure	13
2.4.1 Appearance	13
2.4.2 Structure Layout	15
2.5 Optional Accessory	23
2.5.1 SNMP Card and Its Software	24
2.5.2 Expansion Card	26
2.5.3 Parallel/BSC Accessory	29
2.5.4 Battery Temperature Sampling Accessory	30

	2.5.5 Surge Protection Device	30
	2.5.6 Top Wiring Accessory	30
	2.5.7 Battery Tripper Control Accessroy	31
	2.6 Alarm Function	31
3 I	Installation	41
	3.1 Installation Process.	41
	3.2 Installation Preparation	42
	3.2.1 Installation Tools	42
	3.2.2 Installation Environment	43
	3.2.3 Installation Clearance	44
	3.2.4 Input and Output Wire Selection	44
	3.3 Transporting, Unpacking and Checking	46
	3.3.1 Transportation	46
	3.3.2 Unpacking and Checking	47
	3.4 Mechanical Installation	48
	3.4.1 UPS Installation	48
	3.4.2 Optional Accessory Installation	52
	3.5 Electrical Connection	61
	3.6 Parallel System Connection	65
	3.7 System Check and Test	67
	3.7.1 Check Electrical Connection	67
	3.7.2 UPS Test	67
	3.7.3 Connect Load	68
4 T	Touch Screen Operation	69
	4.1 Menu Hierarchy	69
	4.2 Main Page	69
	4.3 System Work Status Display	71
	4.4 Buzzer Control Function	76
	4.5 Monitor Page	76
	4.5.1 Mains Input	76

4.5.2 Bypass Input	77
4.5.3 Battery Input	78
4.5.4 REC. Module	78
4.5.5 INV. Module	79
4.5.6 Output Information	79
4.6 Set Manage	80
4.6.1 Cabinet Set	81
4.6.2 Battery Set	82
4.6.3 Output Set	82
4.6.4 Smart Mode	83
4.6.5 Dry Contact	83
4.6.6 Battery Test	84
4.6.7 Communication Set	84
4.6.8 Record Manage	85
4.6.9 HMI Set	85
4.6.10 Password Set	86
4.7 Information Manage	86
4.7.1 Run Information	87
4.7.2 History Record	88
4.7.3 User Log	88
4.7.4 Smart Record	89
4.7.5 Smart Wave Record	89
4.7.6 Device Information	90
4.8 ON/OFF	91
5 Use and Operation	93
5.1 Use Announcements	93
5.2 Operation Process	
5.3 ON/OFF Operation	
5.3.1 Check Before Power-on	
5.3.2 Start UPS	94

	5.3.3 Shut Down UPS	96
	5.3.4 Switch to Bypass Mode Manually	97
	5.3.5 Switch to Maintenance Bypass Mode From Mains Mode	97
	5.3.6 Switch to Inverter Mode from Maintenance Bypass Mode	98
	5.3.7 Emergency Power Off (EPO)	99
	5.3.8 Emergency Power Off Recovery	99
	5.4 Parallel System ON/OFF Operation	99
	5.4.1 Start Parallel System	99
	5.4.2 Shut Down Parallel System	102
	5.4.3 Emergency Power Off(EPO)	102
6 N	Maintenance and Troubleshooting	104
	6.1 Maintenance Guide	104
	6.1.1 Safety Precautions	104
	6.1.2 Preventive Maintenance	104
	6.2 Battery Maintenance	105
	6.3 Battery Replacement Announcements	105
	6.4 Troubleshooting	106
	6.4.1 Common Abnormal Phenomena Diagnosis	106
	6.4.2 Emergency Dispose for System Fault	108
7 P	Package, Transportation and Storage	110
	7.1 Package	110
	7.2 Transportation	110
	7.3 Storage	110
A 7	Technical Specifications	111
B P	Physical Characters	115
	Acronyms and Abbreviations	

1 Safety Description

This chapter introduces the safety announcements. Prior to performing any work on the UPS, please read the user manual carefully to avoid human injury and device damage by irregular operations.

1.1 Safety Announcements

This section mainly describes the safety announcements when operation and maintenance. For details, please refer to safety description in relevant chapters.



CAUTION

Before operating, please read the announcements and operation instructions in this section carefully to avoid accident.

The promptings in the user manual, such as "Danger", "Warning", "Caution", etc. don't include all safety announcements. They are just only the supplement of safety announcements when operation.



Any device damage caused by violating the general safety operation requirements or safety standards of design, production, and usage will be out of Allis Electric's guarantee range.

1.1.1 Safety Instructions



CAUTION

The input and output of the UPS is dangerous high voltage, once operate improperly, it may endanger human safety. Please read this manual carefully before installing or operating, and pay attention to the warning labels. Do not dismantle the cover plate of the UPS unless authorized person.



DANGER

Don't touch terminals or conductors that connected with grid to avoid lethal risk!



DANGER

Device damage or device fault may cause electric shock or firing!

- Before operating, please inspect the device and see if there is any damage or exist other danger.
- Check if the external devices or circuit connection is safe.



WARNING

Touching high voltage and mains directly or through damp objects will lead to lethal risk.



DANGER

During a lightning storm, it is strictly prohibited to perform high voltage and AC operation, as well as in the tower or the mast. The atmosphere will generate a strong electromagnetic field in a lightning storm. Therefore, in order to avoid device struck by lightning, lightning protection and grounding system should be prepared in time.



WARNING

The UPS output mustn't connect the half-wave rectifier load or inductive load, such as air-conditioner, hair drier, starter, electric drill, motor, daylight lamp, etc.



WARNING

Do not reversely connect the grounding wire and neutral wire, live wire and neutral wire, which will cause short circuit.

It should be well grounded and the voltage between ground wire and neutral wire should be not more than 5V.



WARNING

Please do not put fingers or tools into the rotating fans to avoid human injury or device damage.



WARNING

In case of fire, please use dry power fire extinguisher. If using liquid fire extinguisher, it may cause electric shock.



CAUTION

Keep good ventilation! Ensure that the air inlet and outlet and fan are not blocked.



CAUTION

The UPS is the class C3 device. If UPS is applied for the low-voltage power supply system of all commercial areas, light industrial areas that supplies power for the residential building, it may need to take additional actions to avoid the interference.



CAUTION

When UPS is powered off, there still exists dangerous voltage. It should affix warning labels away from UPS location and the warning labels should include: 1. It supplies power for UPS. 2. Please disconnect UPS before wiring.

1.1.2 Use Announcements for Battery



CAUTION

Please use specified battery. Non-specified battery will damage the UPS.

The charging voltage of different brands and different models batteries are different. Before using, ensure that the charging voltage of the UPS matches with battery. If any doubt, please consult the manufacturer for support.



WARNING

Battery operation must be done according to instructions, especially battery wiring. Irregular operation will cause battery damage, even human injury.

- It is prohibited to short circuit the anode and cathode of the battery. The battery wiring must be tightened. It is strictly prohibited to touch any two wiring terminals of battery or the bare terminals of wires simultaneously, or it may cause battery damage or human injury.
- Prevent electrolyte leaking from battery. The metal objects and circuit board will be corroded by the overflowing electrolyte and it will result in device damage and circuit board short circuit.
- Keep the battery away from fire source and devices that easy cause spark to avoid danger or unnecessary loss.

1.1.3 ESD Protection



CAUTION

To prevent human electrostatic damaging sensitive components (such as circuit board), make sure that you wear a anti-static wrist strap before touching sensitive components, and the other end is well grounded.

1.1.4 Grounding Requirements



WARNING

The device must be grounded before wiring. The grounding terminal must be connected to earth.

- When installing, the UPS must be grounded first. When dismantling, the grounding wire must be removed at last;
- Don't damage the grounding conductor;
- The UPS must be connected to protection grounding permanently. Before operation, check the electrical connection to ensure the UPS is grounded reliably.

1.1.5 Warning Mark Setting

In order to avoid accident for the unwanted person gets close to the UPS or makes improper operation, observe the following requirements while installing, maintaining or repairing.

- Set warning marks where the switches are to avoid switching them on improperly.
- Set warning signs or safety warning belt in the operation area, which is to avoid human injury or device damage.
- After maintenance, please pull out the key of the UPS and save it properly.

1.2 Operation and Maintenance Requirements

There exists high temperature and high voltage inside the UPS. Please comply with the relevant safety regulations and operation procedures during installation, operation and maintenance to avoid human injury or device damage. The safety precautions mentioned in the user manual are just as a supplement to the local safety regulations.



CAUTION

The related operation and wiring for the UPS should be performed by qualified professionals, and ensure the electrical installation accords with the electrical installation standards.

The installation and maintenance man should be trained, know about each safety announcement, get the right operation method, and then, the installation, operation and maintenance can be done.



DANGER

Mounting and dismantling power cables is prohibited when power on. Please switch off the power switches before mounting or dismantling power cables. Before connecting, make sure the cable connection, cable labels are in accordance with the actual installation.

- Only authorized professionals are allowed to open the UPS! The input and output of the UPS are dangerous high voltage. Touching high voltage will lead to lethal risk.
- Before maintenance, please disconnect the AC power and battery to isolate the power input. It is better to measure the input terminals of UPS by a voltmeter to ensure the input power is disconnected and in a safe condition.
- Even if all external powers are disconnected, there still exists residual electric charge on the capacitor inside the UPS, and the output terminals may exist high voltage which may endanger human life. It is necessary to set the UPS aside for enough time (≥10 min) to release all charge before opening the UPS chassis.
- The battery circuit isn't isolated with AC input. There may exist dangerous voltage between battery terminals and grounding terminals. Battery group exists dangerous high voltage. Pay attention to the insulation when installing and using the battery.
- Do not wear conductive objects, such as watches, bracelets and rings during operating.



WARNING

Drilling holes on the cabinet is prohibited! Inappropriate drilling will damage the components inside the UPS. Metal debris generated by drilling will lead to circuit board short circuit.



Changing the UPS configuration, structure or assembly will affect the performance of the UPS. If user needs to do like this, please consult the manufacturer in advance.

1.3 Environment Requirements



DANGER

Do not put the UPS in the environment where has inflammable, explosive gas or smog. Don't do any operation in this environment.

It's dangerous to operate UPS in the explosive environment, please strictly observe the environment requirements in the user manual when using and storing UPS.

The environment requirements of UPS are as follows.

- Meet the UPS operation specification (operating temperature: $-5^{\circ}\text{C} \sim 40^{\circ}\text{C}$, relative humidity: $0\% \sim 95\%$).
- Keep good ventilation and far away from water source, heat source and inflammable and explosive objects.
- The altitude should not exceed 2000m. If the altitude exceeds 2000m, it should reduce the rated power according to IEC 62040-3.
- Please avoid using UPS in the following environment for a long time.
 - The place where has direct sunshine or near a heat source.
 - The place where has metallic conductive dust.
 - The place where has direct sunlight, dust, volatile gas, corrosive material or high salt.

2 Overview

This chapter mainly introduces the UPS features, working principle, working mode, operation panel, appearance, optional components, alarm function, etc.

2.1 Product Intro

The IST6 120KVA is the online double-conversion UPS system, that consists of cabinet, power module, bypass module, system control box and distribution unit. The modular design is convenient for user to add, decrease or replace the power module online, which will not affect the UPS operation. It's a high performance sine-wave UPS that specially designed for the network computer room and precision instrument of financial, communication, insurance, transportation, tax, army, security, energy source, education, government, enterprise, etc.

IST6 120KVA has four power modules and a redundancy slot. UPS can select a redundancy module to improve UPS reliability. The detailed configuration is as shown in Table2-1.

□ NOTE

Table2-1 Configuration description

Item	IST6 120KVA
Switch configuration	Full configuration(4 pieces)

30K power module	4*30K	
Redundancy module slot	1 piece	
Power module height	2U	
Bypass module height	3U	
UPS dimensions(mm)	600*860*2000	
Wiring method	Bottom wiring in default. It's compatible with top wiring(select the top wiring component).	
Remark	 If the power module isn't fully configured, it can recognize the actual power through the model in the touch screen. e.g. When configure two power modules, the model in the touch screen shows IST6 120KVA-60. The power module order is 1 to 5 from bottom to top, see the labels in the side of cabinet. 	

2.2 Features

Hot swappable

The power module adopts the none-principle-subordinate parallel control technique, each power module is independent and do not need to match each other strictly. They can be put into use or exit online at will, which achieves the online hot maintenance. The system has high adaptability, availability, expandability and low cost.

Three-level inverter technology

Adopts three-level inverter technology, which makes the quality of output voltage wave better and the efficiency of whole UPS higher.

Completely digitalized DSP control

Adopt the completely digitalized DSP control for the inverter control, phase synchronization, output current-sharing, logic control of the power module, which is with high precision, high speed and perfect whole system performance.

Energy conservation and high efficiency

Adopt the advanced PFC control technology, the input power factor is greater than 0.99, which greatly improves the use ratio of electric energy and reduces the load of grid, and saves the cost of power distribution. The size of whole UPS is small, and the weight is light, calorific value is small, which enhances the use ratio of environment and decreases the investment cost.

Smart fan speed control

The fan speed is adjusted automatically in accordance with the load status to prolong fan life and reduce noise.

ECO energy conservation mode design

The UPS is designed with the ECO energy conservation mode. When the grid is good, if the UPS operates in this mode, the bypass prior to output, and the efficiency can be up to 99%. When the bypass voltage or frequency is out of normal range and cannot satisfy the user's power supply requirement, it will switch to inverter output, and this guarantees the reliability of power supply and also, save energy.

Manual maintenance bypass design

It designs the manual maintenance bypass channel to ensure the UPS supplies power for load while maintenance, which greatly improve the system operation reliability and maintainability.

Reliable EMC performance

Pass the authority institution and professional test on EMC, including conducting disturbance, radioactive disturbance, conducting anti-disturbance, radioactive anti-disturbance, power falling, mass impulse, static discharging, surge, etc. The excellent EMC characteristics can completely filter each grid interference, and also, decrease and eliminate the interference of UPS itself effectively.

7 inch touch screen display

With 7 inch touch screen display, the operation is simple and convenient, which is convenient to daily manage and maintain the UPS. It can display the running parameters and running status of UPS and each power module, and record the history event and alarm information. It can store 10000 pieces of information at most.

User Manual 2 Overview

2.3 Working Principle

2.3.1 Schematic Diagram

The schematic diagram of the IST6 120KVA is as shown in Figure 2-2.




Figure 2-2 Schematic diagram

2.3.2 Working Mode

The IST6 120KVA has four work modes: normal mains power supply mode, battery power supply mode, bypass power supply mode and maintenance bypass power supply mode.

Normal mains power supply mode

When the mains is normal, AC power is transformed to DC power by PFC, and supplies power for inverter. While rectifier the AC power into DC power, the rectifier eliminates the abnormal noise wave, noise and unstable frequency, and make the inverter provides stable and clean power for load. The specific working process is as follows.

When the mains power supply is normal, the rectifier inside the power module will rectifier the mains to a positive and negative DC voltage, and the DC voltage gets through the inverter and then will output a stable 220Vac AC voltage to supply power for the load. When the system detects that the inverter is normal, it will supply the inverter voltage to load.

Battery power supply mode

When mains is abnormal, system will switch to battery input, the Boost circuit boosts the battery voltage to a certain value and then supplies the DC power for the inverter, that makes the AC output without interruption phenomenon and then protects the load. The specific working process is as follows.

When mains is abnormal at any time, the rectifier will switch to battery input immediately to keep the voltage of DC electrolysis, and the inverter will not power down. Before battery discharges completely, if mains recovers, the rectifier will switch to mains input and charge battery at the same time. During the switching between grid power supply and battery power supply, the inverter output cannot power down.

In the battery power supply mode, if mains does not recover normal all the time, and the battery energy is running out, the UPS will send sound & light alarm, stop inverter working at the min. battery discharge value, long beep to alarm, and the load will power down.

Bypass power supply mode

When system is abnormal (such as over-temperature, short-circuit, output voltage abnormal or overload, and exceed the inverter bearing range), the inverter will shut down to avoid damage automatically. If mains still is normal at this time, it will turn to bypass to supply power for load. The specific work process is as follows.

If the inverter circuit fault or inverter overload and exceeds the bearing range, the UPS will turn to bypass to output. During bypass power supply, if fault or overload is removed, the UPS will start inverter and begin to supply power for load. When the load is serious overload and exceeds the bypass bearing range, the UPS will close the bypass output, and it will cause load powering down. When load short-circuit, the UPS will switch to bypass to supply power from inverter. If the short-circuit is serious, the mains switch and bypass switch of UPS may trip out. After suffering the short-circuit fault, UPS will try to restart. If the short-circuit is removed, the UPS will switch to inverter; if the fault is not removed, the UPS will try to restart for 3 times. 3 times later, the UPS will turn to fault protection. At this time, it needs to power off or click the touch screen to shut down the UPS, and restart the UPS, and then, it will recover working.

Maintenance bypass power supply mode

When the UPS needs to be maintained and the power supply for load cannot be interrupted, user can shut down the inverter and make the UPS work in bypass status, then switch on the maintenance bypass switch and switch off the mains switch, bypass switch. During the switching of manual maintenance User Manual 2 Overview

bypass, the AC power is supplied for load by maintenance bypass switch. At this time, the UPS has no electricity, maintainer can perform the maintenance safely.

2.4 Appearance and Structure

2.4.1 Appearance

The IST6 120KVA consists of cabinet, operation panel, power module, bypass module, system control box, distribution unit, etc. The appearance of the IST6 120KVA is as shown in Figure2-3.




Figure 2-3 Appearance

Operation Panel




Figure 2-4 Operation panel

Table2-2 Illustration of the operation panel

NO.	Name	Illustration
(),1	Touch screen	Human-machine interactive interface
,2	AC/DC indicator	On (green): The rectifier works normally. On (red): The rectifier works abnormally.
),3	DC/AC indicator	On (green): The inverter works normally. On (red): The inverter works abnormally.
	BYP. indicator	On (green): Bypass outputs normally. On (red): Bypass is abnormal.
	BATT. LOW indicator	On (green):Battery power supply. On (red): Battery low-voltage.
),6	OVERLOAD indicator	On (green): Output normal. On (red): Output overload.
 ,7	ON combination button	Press the two buttons for 3s, power on UPS.
0,8	OFF combination button	Press the two buttons for 3s, power off UPS.
0,9	EPO button	Press the button, the system will power outage immediately.

User Manual 2 Overview

2.4.2 Structure Layout

The structure layout of the IST6 120KVA is as shown in Figure2-5.




Figure 2-5 Structure layout of IST 6 120 KVA (open front door)

Power module

- Power module height: 2U
- Dimensions(H×W×D): 86mm×500mm×700mm(include hangers and handles)
- Weight: 24kg




Figure 2-6 Front view of power module

Table2-3 Illustration of the operation panel of the power module

NO.	Name	Illustration
(),1	RUN indicator (green)	On: Power module stays in inverter status. Flicker: Power module stays in standby status.
,2	ALARM indicator (yellow)	On: Module input voltage abnormal, fan abnormal, overload, etc.
(),3	FAULT indicator (red)	On: Module fault.
 ,4	Ready switch	 Place the ready switch to "unlock" status, the indication color is green, the power module is not locked with the cabinet, and at this time, the power module can be dismantled. Place the ready switch to "lock" status, the indication color is red, the power module is locked with the cabinet, and at this time, the power module cannot be dismantled.

Bypass module

- Bypass module height: 3U
- Dimensions(H×W×D): 130mm×500mm×635.5mm (include hangers and handles)
- Weight: 17kg




Figure 2-7 Front view of bypass module

Table2-4 Illustration of the operation panel of the bypass module


NO.	Name	Illustration
(),1	RUN indicator (green)	On: Bypass module is working.

User Manual 2 Overview

NO.	Name	Illustration
),2	ALARM indicator (yellow)	On: Module input voltage abnormal, fan abnormal, etc.
(),3	FAULT indicator (red)	On: Module fault.
 ,4	Ready switch	 Place the ready switch to "unlock" status, the indication color is green, the power module is not locked with the cabinet, and at this time, the bypass module can be dismantled. Place the ready switch to "lock" status, the indication color is red, the bypass module is locked with the cabinet, and at this time, the bypass module cannot be dismantled.

System control box

The system control box is as shown in Figure 2-8.



- ① Expansion card position (Optional)
- ② SNMP card position(Optional)

3 Control card1

- 4 Control card 2
- 5 System monitor card

Figure 2-8 System control box

MAGTE

The expansion card position is for dry contact expansion card or BMS expansion card. For details, refer to **2.5.2 Expansion Card**.

System control card




Figure 2-9 System control card

Table2-5 Illustration of the system control card

NO.	Name	Illustration	
(),1	RS485 port	Realize the smart integrated display function. It is used for a UPS to monitor the running information of other parallel UPSs. The RS485 port adopts the RJ45 plug. The pin definition of the RS485 port is shown in Figure2-10. In the parallel system, the RS485 connections are as shown in Figure2-11 and Figure2-12.	
<u></u>	PARALLEL port	Parallel ports connection among cabinets to realize the parallel/BSC function. When multi UPSs in parallel, connect the parallel port of each UPS by parallel wire. N UPSs require N parallel wires to ensure there are at least two parallel wires for a UPS, which will improve parallel reliability.	
,3	NORMAL indicator(green)	On: The system control card is in the running status of the main card. Flicker: The system control card is in the initialization status.	
	ALARM indicator (yellow)	On: The system control card has the alarm signal. Flicker: The system control card in the running status of the secondary card.	
<u></u>	FAULT indicator (red)	On: System control card fault.	

User Manual 2 Overview




Figure 2-10 Pin definition of the RS485 port




Figure 2-11 RS485 port connection(two UPSs)




Figure 2-12 RS 485 port connection (multiple UPSs)

• System monitor card

There is one human-machine interactive communication port, four input dry contact communication signals and three output dry contact signals(as shown in Figure 2-13), the illustration is as shown in Table 2-6.




Figure 2-13 System monitor card

There are two network ports on the system monitor card: MODBUS port and RS232 port.

 The MODBUS port is used for MODBUS communication, which is to communicate with upper computer. The MODBUS port adopts RJ45 plug. The pin definition of the MODBUS port is shown in Figure 2-14





Figure 2-14 Pin definition of the MODBUS port

2. The RS232 port is used for RS232 communication, which is to achieve the external SNMP card communication. The RS232 port adopts the RJ45 plug. The pin definition of the RS232 port is shown in Figure 2-15.

User Manual 2 Overview



Pin definition:

Pin 1: White orange-RS232:TX

Pin 2: Orange-RS232:RX
Pin 3: White green-Reserved

Pin 4: Blue-RS232:TX

Pin 5: White blue-RS232:RX

Pin 6: Green-Reserved

Pin 7: White brown-5V power

Pin 8: Brown-GND

Figure 2-15 Pin definition of the RS232 port

Table2-6 Illustration of dry contact

Port	Mark	Signal	Illustration	
	NO	External EPO normal open port	When the NO and COM is short circuit, the	
EPO1	COM	Reinforced insulation ground	signal is effective. The signal is preset and isn't settable.	
B-	NC	Battery temperature sampling resistance port	External temperature sampling wire. The	
Тетр	COM	Reinforced insulation ground	signal is preset and isn't settable.	
	NC	External EPO normal close port	When the NO and COM disconnect, the	
EPO2	COM	Reinforced insulation ground	signal is effective. The signal is preset and isn't settable. (When use, the CN8 in the monitor card should be connected through 2P jumper cap.)	
	NC	OUT.1 normal close output port	When the signal is effective, COM and NO	
OUT.1	NO	OUT.1 normal open output port	connect, and NC disconnects. This signal is	
	COM	Reinforced insulation ground	settable.	
	NC	OUT.2 normal close output port	When the signal is effective, COM and NO	
OUT.2	NO	OUT.2 normal open output port	connect, and NC disconnects. This signal is	
	COM	Reinforced insulation ground	settable.	
	NC	OUT.3 normal close output port	When the signal is effective, COM and NO	
OUT.3	NO	OUT.3 normal open output port	connect, and NC disconnects. This signal is	

Port	Mark	Signal	Illustration	
	COM	Reinforced insulation ground	settable.	
IN.1	NO	External switch normal open input port	When the NO and COM is short-circuit, the	
	COM	Reinforced insulation ground	signal is effective. This signal is settable.	
IN.2	NO	External switch normal open input port	When the NO and COM is short-circuit, the	
	COM	Reinforced insulation ground	signal is effective. This signal is settable.	
IN.3	NO	External switch normal open input port	When the NO and COM is short-circuit, th signal is effective. This signal is settable.	
	COM	Reinforced insulation ground		
IN.4	NO	External switch normal open input port	When the NO and COM is short-circuit, the	
	COM	Reinforced insulation ground	signal is effective. This signal is settable.	

The four input ports(IN port) on the system monitor card can be defined according to user requirements, as shown in the Table2-7.

Table2-7 The definition of the input dry contact

NO.	Definition	Remark	
1	Battery abnormal	When this signal is received, UPS alarms and records this status, and then turn off the charge function.	
2	Battery grounding fault	Grounding fault signal.	
3	Battery switch disconnected	Battery switch auxiliary contact.	
4	Bypass switch disconnected	Bypass switch auxiliary contact.	
5	Mains abnormal	Mains power failure signal, cooperate with auto generator mode to start the generator.	
6	Input SPD abnormal	Input SPD abnormal, UPS records this event.	

The three output ports(OUT port) on the system monitor card can be defined according to user requirements, as shown in the Table2-8.

Table2-8 The definition of the output dry contact

NO.	Definition	Remark	
1	Inverter output	UPS is in the inverter output status, and this dry contact is ON.	
2	Bypass output	UPS is in the bypass output status, and this dry contact is ON.	
3	Battery trip	Battery trips, and this dry contact is ON.	
4	Bypass output	UPS is in the battery output status, and this dry contact is ON.	
5	Battery under-voltage alarm	Battery discharges to the under-voltage alarm, and this dry contact is ON.	
6	Battery under-voltage protection	Battery discharges to the under-voltage protection status, and this dry contact is ON.	
7	Output overload	UPS is in the overload status, and this dry contact is ON.	
8	UPS fault	Fault status, and this dry contact is ON.	
9	Bypass abnormal	Bypass is abnormal or it's unable to track bypass, and this dry contact is ON.	
10	Mains abnormal	Mains is abnormal, and this dry contact is ON.	
11	Start generator	When the generator starts, and this dry contact is ON.	

Battery cold start button

When there isn't mains and bypass status, long press the battery cold start button for 2s and UPS will start in the battery status.

2.5 Optional Accessory

The IST6 120KVA UPS can select different accessories(as shown in Table2-9) to meet different requirements.

Table2-9 Optional accessory list

NO.	Name	NO.	Name
1	SNMP card and its software	5	Surge protection device
2	Expansion card	7	Top wiring accessory
3	Parallel/BSC accessory	8	Battery tripper control accessory
4	Battery temperature sampling accessory	/	/

2.5.1 SNMP Card and Its Software

SNMP card(as shown in Figure 2-16) is installed in the UPS to realize the UPS remote management.




Figure 2-16 SNMP card

M NOTE

When the SNMP card is selected, the SNMP card will be installed on the system control box of UPS before shipping.

Table2-10 Illustration of the SNMP card

NO.	Name	Function description
(),1	NETWORK port	Ethernet port.
<u></u>	COM1 port	Connect with humiture module(RS485).
,3	Indicator	Show working status.

Table2-11 Illustration of indicator of the SNMP card

Green indicator(R)	Red indicator(E)	Status description
ON	ON	Start

User Manual 2 Overview

Green indicator(R)	Red indicator(E)	Status description
Flicker	*	Running
OFF/ON	*	Crash, keep final status.
*	OFF	No alarm.
*	Flicker	Alarm

\square NOTE

NETWORK port

The NETWORK port adopts the RJ45 plug. The pin definition of the NETWORK port is shown in Figure 2-17.




Figure 2-17 The pin definition of the NETWORK port

SNMP card software



It is suitable but not only for the following browsers(the early operating system may not be good in compatibility): Chrome56+ browser, IE11+ browser. The login interface is different in different browser.



Please ensure that the setting IP address is in the same network segment with user's computer IP address.

After finishing the SNMP installation and wring, please configure the software in the following order.

^{*} means the indicator is in any status.

Step 1 Open browser, and enter the IP address of the WiseWay built-in card (KC502)(Default IP is 192.168.0.100).

∭ NOTE

When the IP address of the SNMP built-in card(KC502) is changed or multiple SNMP cards are used at the same time, the corresponding IP address can be obtained through WiseFind software(enter the address in PC to download the WiseFind software and then install it).

Step 2 Enter the user name and password in the login page and click **Login** to enter the monitoring page.

∭ NOTE

Default user name is admin, corresponding password is KHadmin0592.

User can scan the QR code or enter the URL through browser(PC mode) to get more product information.

User manual	Software			
WiseWay KC502	WiseClose	WiseFind	WiseInsight	WiseSMS
		3536564 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		
https://drive.263. net/link/YtH6Mi 1Mtbn0CpH/	https://drive.263. net/link/a0Wjvay Xwu0lQ4m/	https://drive.263. net/link/rvRBjZc MLiFrC1J/	https://drive.263. net/link/Rqk69m 4ek9UGEKI/	https://drive.263. net/link/MzoJG31 jCc3cC3H/

----End

2.5.2 Expansion Card

Dry contact expansion card

The dry contact expansion card(as shown in Figure 2-18) is mainly used for the detection signal sampling. The dry contact expansion card includes three input dry contact communication signals and two output dry contact signals, the illustration is shown in Table 2-12.

User Manual 2 Overview




Figure 2-18 Dry contact expansion card

M NOTE

When the dry contact expansion card is selected, the dry contact expansion card will installed on the system control box of UPS before shipping.

Table2-12 Illustration of the dry contact

Port	Mark	Signal	Illustration	
	NC	OUT.4 normal close output port	When the signal is effective, COM	
OUT.4	NO	OUT.4 normal open output port	and NO connect, and NC	
	COM	Reinforced insulation ground	disconnects. This signal is settable.	
	NC	OUT.5 normal close output port	When the signal is effective, COM	
OUT.5	NO	OUT.5 normal open output port	and NO connect, and NC	
	COM	Reinforced insulation ground	disconnects. This signal is settable.	
	COM	Reinforced insulation ground	When the NO and COM is short-	
IN.5	NO	External switch normal open input port	circuit, the signal is effective. This signal is settable.	
	СОМ	Reinforced insulation ground	When the NO and COM is short-	
IN.6	NO	External switch normal open input port	circuit, the signal is effective. This signal is settable.	
	COM	Reinforced insulation ground	When the NO and COM is short-	
IN.7	NO	External switch normal open input port	circuit, the signal is effective. This signal is settable.	

The pin definition of the input dry contact and output dry contact are as shown in Table2-7 and Table2-8.

2 Overview User Manual

BMS expansion card

The BMS expansion card(as shown in Figure 2-19) is mainly used for the Li-battery communication. The BMS expansion card includes one BMS communication port, two input dry contacts and one output dry contact. The illustration is shown in Table 2-13.




Figure 2-19 BMS expansion card

Table2-13 Illustration of the BMS expansion card

Port	Mark	Signal	Illustration
BMS		BMS port	It is used to communicate with the Libattery. The BMS port adopts the RJ45 plug. The pin definition of the BMS port is shown in Figure 2-20.
COM Reinforced		Reinforced insulation ground	When the NO and COM is short-circuit, the
IN.8	NO	External switch normal open input port	signal is effective. This signal can be se to charge disabled.
	COM	Reinforced insulation ground	When the NO and COM is short-circuit, the
IN.9	NO	External switch normal open input port	signal is effective. This signal can be se to discharge disabled.
	NC	OUT.6 normal close output port	When the signal is effective, COM and NO
OUT.6	NO	OUT.6 normal open output port	connect, and NC disconnects. This port is
	COM	Reinforced insulation ground	reserved.

M NOTE

For Li-battery reliability consideration, if Li-battery is used, it's recommended to install BMS expansion card and debug with the Li-battery before shipping.

User Manual 2 Overview




Figure 2-20 Pin definition of BMS port

2.5.3 Parallel/BSC Accessory

Parallel/BSC accessory are for parallel/BSC ports connection among UPSs.

When multi UPSs in parallel, connect the parallel port of each UPS by parallel wire. N UPSs require N parallel wires to ensure there are at least two parallel wires for a UPS, which will improve parallel reliability.

The synchronous BSC output dual bus control is used in a dual bus system to synchronize the output frequency and phase of each system in a dual bus system to ensure that the two buses can switch to each other.



If parallel wires are selected, the parallel wires are configured with UPS before shipping.

Parallel port connection

• Parallel system connection(two UPSs)




Figure 2-21 Parallel system connection (two UPSs)

• Parallel system connection(multiple UPSs)

2 Overview User Manual




Figure 2-22 Parallel system connection(multiple UPSs)

2.5.4 Battery Temperature Sampling Accessory

The battery temperature sampling accessory is used to monitor the battery temperature to realize the battery charging and discharging temperature compensation. When the battery temperature compensation function is selected, it will be configured that one temperature control wire, one temperature control extension wire and one 2 pin green terminal.




Figure 2-23 Battery temperature sampling accessory connection

□ NOTE

The temperature control wire should be fixed in the higher temperature area of the battery.

2.5.5 Surge Protection Device

In areas where lightning strikes are frequent, multistage surge protection system should be installed at the incoming wire of the mains to ensure the safe operation of the device. A class C SPD and protection switch can be selected for UPS.

M NOTE

If the surge protection device is selected, it must power off UPS and then install the surge protection device when there has strong electricity. It's recommended to require installing the surge protection device before shipping.

2.5.6 Top Wiring Accessory

When the cross-sectional area of wire in the site is less than 120mm² and the wiring method is top wiring, it can select the top wiring accessory to realize the top wiring, the wiring diagram is as shown in Figure 3-33.

User Manual 2 Overview

2.5.7 Battery Tripper Control Accessory

When the battery switch tripper is installed, it need to configure the battery tripper control accessory. The output power of the battery tripper control accessory is 24VDC, it can control the voltage turning through dry contact to meet the requirements of shunt tripper and under-voltage tripper.

MOTE

The output of the battery tripper control accessory is 24VDC, it only meets the requirements of the tripper with rated power 24VDC.

2.6 Alarm Function

Once the UPS is abnormal, it will send sound & light alarm. The alarm or protection function of the UPS is as shown in Table2-14.

Table2-14 Abnormal status and alarm protection function

Mains fault Mains over-voltage Mains under-voltage Mains unbalance Mains over-frequency	Fault	Information	Protect requirement	Alarm requirement
Buzzer slowly beeps, the		Mains fault Mains over-voltage Mains under-voltage Mains unbalance Mains over-frequency Mains under-frequency Mains failure Mains phase loss Mains phase sequence abnormal Large mains harmonic component Mains drop	Mains power supply	Buzzer slowly beeps, the AC/DC indicator turns red, and the mains icon on the

Fault	Information	Protect requirement	Alarm requirement
	Mains neutral wire loss		
	Large mains DC component		
	Battery fault		
	Battery reversed		
	Battery over-voltage		Buzzer fast beeps, the
Battery	Charger over-current	Battery power supply is not	BATT. LOW indicator turns
fault	Battery circuit abnormal	allowed.	red, and the battery icon on the touch screen turns red.
	Bypass under-voltage protection		
	Bypass overload		
	Bypass fault		Buzzer slowly beeps, the BYP. indicator turns red,
	Bypass over-voltage		
	Bypass under-voltage		
	Bypass unbalance		
	Bypass over-frequency	Drymaga mayyan	
	Bypass under-frequency	Bypass power supply is not	
Bypass	Bypass failure	allowed.	and the bypass icon on the touch screen turns red.
fault	Bypass phase loss		
	Bypass phase sequence abnormal		
	Large bypass harmonic component		
	ECO power down detection		
	ECO over-voltage	ECO output is not allowed.	Buzzer slowly beeps.
	ECO under-voltage		

Fault	Information	Protect requirement	Alarm requirement
	ECO over-frequency		
	ECO under-frequency		
	Inverter output fault		
	Output short circuit	Inverter output is	Buzzer long beeps, the DC/AC indicator turns red,
	Inverter over-voltage	not allowed.	and the output icon on the
	Inverter under-voltage		touch screen turns red.
Output fault	Output circuit abnormal	None	Buzzer slowly beeps, the DC/AC indicator turns red, and the output icon on the touch screen turns red.
	Low output PF		Buzzer long beeps, DC/AC
	Large output current DC component	Inverter output is not allowed.	indicator turns red on the touch screen, and the output icon turns red.
	System fault	None	
	System EPO on	Bypass output and inverter output are not allowed.	
	System bypass fault	None	Buzzer long beeps.
	System inverter fault	None	
System fault	EPO on	Bypass output and inverter output are not allowed.	
	Bypass overload protection	Bypass output and inverter output are not allowed.	Buzzer long beeps, the OVERLOAD indicator turns red, and the output icon on the touch screen turns red.

Fault	Information	Protect requirement	Alarm requirement
	Bypass SCR abnormal	Bypass output is not allowed	Buzzer long beeps, the BYP. indicator turns red, and the bypass icon on the touch screen turns red.
	Parallel wire abnormal	Inverter output is not allowed	Buzzer long beeps.
	Sovereignty of parallel system fault	None	Buzzer long beeps.
	Inverter overload protection	Inverter output is not allowed	Buzzer long beeps, the OVERLOAD indicator turns red, and the output icon on the touch screen turns red.
	Maintenance bypass on	Inverter output is not allowed	Buzzer long beeps
	Battery charge disabled on	None	Buzzer fast beeps, the
	Battery discharge disabled on	None	BATT. LOW indicator turns red, and the battery icon on the touch screen turns red.
	Cabinet fault	None	Buzzer long beeps.
	Bypass over-temperature	Check whether bypass output or not by the bypass overtemperature enable.	Buzzer long beeps, the BYP. indicator turns red, and the bypass icon on the touch screen turns red.
Cabinet fault	Inverter output over-current	None	
iault	Rectifier fault self-locking	None	
	Inverter fault self-locking	None	Buzzer long beeps.
	Battery overload protection	None	
	Battery discharge protection	None	

Fault	Information	Protect requirement	Alarm requirement
	UPS fault	None	
	Cabinet pre-alarm	None	
	Cabinet over-temperature alarm	None	
	High battery temperature alarm	None	Buzzer fast beeps.
	Low battery temperature alarm	None	
	Battery under-voltage alarm	None	
	Backup time insufficient	None	
Cabinet pre-alarm	Output overload alarm	None	Buzzer fast beeps. the OVERLOAD indicator turns red, and the output icon on the touch screen turns red.
	Output frequency out of scope	None	
	Bypass auxiliary power abnormal	None	
	Bypass over-temperature alarm	None	Buzzer fast beeps.
	Some power module PFC abnormal	None	
	Battery auto-start once power recover disable	None	
	Cabinet fault	None	
	Battery disconnected alarm	None	Buzzer slowly beeps.
Cabinet	Auxiliary power abnormal	None	
alarm	Bypass module is not installed.	Bypass output is not allowed	Buzzer slowly beeps, the BYP. indicator turns red, and the bypass icon on the

Fault	Information	Protect requirement	Alarm requirement
			touch screen turns red.
	Setting parameters mismatch	None	
	Battery parameters mismatch	None	
	Module number mismatch	None	
	Cabinet number mismatch	None	
	System card n _ it is not installed.	None	
	System card n _ flash abnormal.	None	
	System card n _ card slot address repeat.	None	Buzzer slowly beeps.
	System card n _ ON/OFF status and the primary card out of sync.	None	
	Bypass output now.	None	
	System card n _ parameter of primary card and secondary card out of sync.	None	
	System card n _ output status out of sync	None	
	Fan dedusting	None	
	Startup fault alarm		
Startup	Cannot inverter output for heavy load	Static startup is not allowed to work.	
fault alarm	Waiting common inverter for unknown load		Buzzer slowly beeps.
	PFC software version		

User Manual

Fault	Information	Protect requirement	Alarm requirement
	inconformity		
	Inverter software version inconformity		
	CCM software version inconformity		
	Module hardware version inconformity		
	Key parameters mismatch		
	Parallel address conflict		
	Module serial version inconformity		
	Component failure		Buzzer slowly beeps.
	Bypass 1 NTC failure		
	Bypass 2 NTC failure		
	Cabinet NTC failure		
	System card NTC failure		
	Bypass fan abnormal	None	
Component	Cabinet fan abnormal	None	
failure alarm	Parallel wire 1 alarm		
	Parallel wire 2 alarm		
	Bypass 1 is not installed.		
	Bypass 2 is not installed.		
	Monitor card is not installed.		
	Bypass module offline	Bypass output is not allowed.	Buzzer slowly beeps, the BYP. indicator turns red, and the bypass icon on the

Fault	Information	Protect requirement	Alarm requirement
			touch screen turns red.
	Expansion card offline Bypass NTC failure	None	Buzzer slowly beeps.
Comm. abnormal alarm	Communication abnormal Sync CAN inside cabinet abnormal Equalized-current CAN inside cabinet abnormal BMS communication fault Display CAN inside cabinet abnormal Sync CAN among cabinets abnormal Equalized-current CAN among cabinets abnormal Inner SCI communication	None	Buzzer fast beeps.
	abnormal		
Smart mode alarm	Smart mode alarm Generator mode on Generator charge disabled Only a BSC system detected now The load exceeds the set safety load. Power module with no redundancy Power module redundancy	None	Buzzer slowly beeps.

Fault	Information	Protect requirement	Alarm requirement
	insufficient		
	Cabinet with no redundancy		
	Cabinet redundancy insufficient		
	System card with no redundancy		
	Self-load switch abnormal		
	Self-load time-out alarm		
	Inverter bypass out of sync		
	Input dry contact alarm		Buzzer slowly beeps.
	Battery abnormal		Buzzer fast beeps, the
	Battery grounding fault		BATT. LOW indicator turns red, and the battery icon on
	Battery switch off		the touch screen turns red.
Input dry	Bypass switch off		Buzzer slowly beeps, the BYP. indicator turns red, and the bypass icon on the touch screen turns red.
contact	Output switch off	None	Buzzer slowly beeps.
status	Battery discharge disabled on		Buzzer fast beeps, the BATT. LOW indicator turns red, and the battery icon on the touch screen turns red.
	Battery charge disabled on		Buzzer fast beeps, the BATT. LOW indicator turns red, and the battery icon on the touch screen turns red.
	Mains abnormal		Buzzer slowly beeps.

2 Overview User Manual

Fault	Information	Protect requirement	Alarm requirement
	Input SPD abnormal		Buzzer slowly beeps.
	Power module 1 offline		
	Power module 2 offline		
Offline	Power module 3 offline		
alarm	Power module 4 offline	None	Buzzer slowly beeps.
status	Power module 5 offline		
	System card 1 offline		
	System card 2 offline		



CAUTION

In the battery under-voltage protection, if the mains is normal, the UPS will restart and charge the battery group.

3 Installation

This chapter mainly introduces the installation of the UPS, including installation process, installation preparation, transporting, unpacking and checking, mechanical installation, electrical connection, parallel wiring and system checking and test, etc.



CAUTION

Only trained professionals who are with high voltage and AC qualification can install UPS.

The UPS is just suitable to install on the flat ground that is concrete or non-flammable.

3.1 Installation Process

The installation process of the IST6 120KVA is as shown in Figure 3-1.





Figure 3-1 Installation process

3.2 Installation Preparation

3.2.1 Installation Tools





CAUTION

The installation tools must be insulated to avoid electric shock.

3.2.2 Installation Environment

- Install the UPS in the place where the temperature and humidity are within the range of 5°C~40°C and 0%–95% respectively.
- Don't install the UPS in the environment where has metal conductive dust.
- Don't install the UPS in the open air. The installation environment should meet the specification of the UPS.
- Basic requirements for power supply.
 - Grounding preparation. Ensure that the grounding terminal is OK and the voltage between neutral wire and grounding wire should not exceed 5V.
 - Before installation, please ensure that the AC input voltage and mains input wire capacity meet the UPS requirements, and considering if there has current-carrying capacity descending caused by wire aging.
 - The mains input voltage range of the UPS is 80~280VAC. The mains capacity should be greater than the max. input power of the UPS.
 - The selected switch should not with leakage current protection.
- Install the UPS in the environment where with good ventilation and free of dust, volatile gas, salt, and corrosive materials. Keep the UPS far away from water, heat source, flammable and explosive substances. Avoid direct sunlight.



CAUTION

The optimal operating temperature for battery is 20°C–30°C. Operating at temperatures higher than 30°C will shorten the battery lifespan., and operating at temperatures lower than 20°C will shorten the battery backup time.

For safety consideration, please ensure the external DC distribution circuit is with three polar switch.

3.2.3 Installation Clearance

• Keep at least 800mm from the front panel and the rear panel of the UPS to the wall or adjacent device, keep at least 500mm from the top of the UPS to the ceiling for heat dissipation and maintenance, as shown in Figure 3-2.




Figure 3-2 Installation clearance (unit: mm)

• Keep the ventilation holes on the front panel and rear panel unblocked to facilitate ventilation and heat dissipation, or, it may rise the inner temperature, even influence the UPS service time.

3.2.4 Input and Output Wire Selection

For the cross-sectional area of input wires and output wires of the UPS, please refer to the recommended values in Table 3-1.

Table3-1 Wire and terminal requirements

Item		Model	IST6 120KVA
Mains input	Mains input current(.	A)	213
	Cross-sectional area of wire(mm²)	U/V/W/N	1×(4×120)

Item			IST6 120KVA		
	Terminal mo	del	DT120		
В	Bypass input	current	182		
Bypass input	Cross-sectional area of wire(mm²)		U/V/W/N		1×(4×95)
	Terminal mo	del	DT95		
Output	Output currer	nt(A)	182		
	Cross-sectional area of wire(mm²)		U/V/W/N(Select larger cross- sectional area of neutral wire for non-linear load.)		1×(4×95)
	Terminal model				DT95
	±16 pieces of 12V storage batteries	Nominal discharge current of storage battery(The current at 384V)(A)		330	
		Max. discharge current of storage battery(The ending discharge current value <the 10.5v="" battery="" each="" is="" of="" voltage="">)(A)</the>			377
			Cross-sectional area of wire(mm²) +/N/-		1×(3×95)
Battery		Terminal model		DT95	
Battery input	±14 pieces of 12V storage batteries	Nominal discharge current of storage battery(The current at 336V)(A) (Note: when it's 14 pieces batteries, decrease rated power of battery)		336V)(A) (Note:	302
		Max. discharge current of storage battery(The ending discharge current value <the 10.5v="" battery="" each="" is="" of="" voltage="">(A) (Note: when it's 14 pieces batteries, decrease rated power of battery)</the>			345

Item				Model	IST6 120KVA
			-sectional f wire(mm ²)	+/N/-	1×(3×95)
		Termi	nal model		DT95
Grounding	Cross-sectional area of wire(mm²)		PE		95
	Terminal model				DT95



The wires prepared by our company have passed the UL certification. The wires quality is excellent, and all meet the production compliance. The cross-sectional areas above are recommended for 5m wires. Longer wires require larger cross-sectional areas.

3.3 Transporting, Unpacking and Checking

3.3.1 Transportation



CAUTION

The UPS must be transported by trained professionals.

When transporting, please move carefully and avoid impacting or dropping.

If the UPS needs to be stored for a long time after unpacking, it is suggested to pack the UPS by original plastic bag.

The UPS can be transported by motor-driven forklift (as shown in Figure 3-3) or manual forklift (as shown in Figure 3-4). While lifting, please keep the UPS center of gravity at that of the forklift and move slowly and stably.



Figure 3-3 Motor forklift




Figure 3-4 Manual forklift



CAUTION

While lifting the UPS, please keep stable and balanced.

During transporting, keep the UPS vertical. Avoid put down or put up the UPS suddenly.

3.3.2 Unpacking and Checking

- Step 1 Inspect the package's appearance for shipping damage, if any shipping damage is found, report it to the carrier immediately.
- Step 2 Transport the UPS to assigned site.



CAUTION

To avoid tilting during transportation, keep the forklift arm exceeding the wooden bracket.

- Step 3 Unpack the external package. Remove the foam pad and plastic bag, take out the accessories and documents.
- Step 4 Check the UPS.

 Inspect the UPS's appearance for shipping damage, if any shipping damage is found, report it to the carrier immediately.

- Check if the types of the accessories are complete and correct. If there is any discrepancy, take notes and contact the distributor immediately.
- Step 5 Unscrew the bolts that connected UPS with wooden bracket by socket wrench, the bolt position is as shown in Figure 3-5.




Figure 3-5 Bolt position

----End

3.4 Mechanical Installation

3.4.1 UPS Installation



Here we take the ground installation as an example. For other installation way, please adjust the installation procedures on the basis of actual condition.



CAUTION

For the bottom wiring, dig the wiring groove for wiring in advance, as shown in Figure 3-6.




Figure 3-6 Wiring groove diagram (Unit: mm)

MOTE

The recommended wiring groove size is: A×D×H: 200×400×300(mm).

Step 1 Determine and plan the installation position according to the UPS size (as shown in Figure 3-7) and installation clearance requirement (see 3.2.3 Installation Clearance).




Figure 3-7 UPS size(unit: mm)

Step 2 Drill four Φ 14mm holes on the ground by impact drill according to the installation hole size of pedestal (as shown in Figure 3-8).

■ NOTE

If the UPS is installed on U-steel, drill four holes(hole diameter $is\phi14mm$) on the U-steel directly(as shown in Figure 3-9), and then perform **Step 4** to install UPS directly.




Figure 3-8 The installation hole size of pedestal(unit: mm)




Figure 3-9 Recommended U-steel size

Step 3 Install the expansion bolts. The structure and installation of the expansion bolt is as shown in Figure 3-10.




Figure 3-10 Structure and installation of expansion bolt



CAUTION

For installation consideration, the expansion tube should be into the installation hole, that is it should be not higher than ground.

NOTE

The outer height of expansion bolts should be within 30-50mm.

Step 4 Move the UPS from wooden bracket to the ground, align the bottom installation hole with the expansion bolt, and lock the bolts.



CAUTION

When moving UPS by forklift, the forklift arm must be inserted from the side of UPS.

While lifting, please keep the UPS center of gravity at that of the forklift to avoid tilting.

M NOTE

If adopting the bottom wiring, please ensure that the installation position is right above the wiring groove.

Step 5 Install the bottom plates, as shown in Figure 3-11.




Figure 3-11 Install the bottom plates

----End

3.4.2 Optional Accessory Installation

Top wiring accessory



When the wiring method is top wiring, it should select the top wring accessory for wiring. The installation procedures are as follow.



CAUTION

The top wiring accessories are installed in the two sides of UPS. It requires enough space in the two sides of UPS for top wiring installation.

Step 1 Dismantle the side plates, as shown in Figure 3-12.




Figure 3-12 Dismantle the side plates

Step 2 Install the top wiring accessories, as shown in Figure 3-13.




Figure 3-13 Install the top wiring accessories

----End

SNMP card

Step 1 Dismantle the SNMP card plate on the system control box, as shown in Figure 3-14.




Figure 3-14 Dismantle the SNMP card plate

Step 2 Install SNMP card on the system monitor box, as shown in Figure 3-15.




Figure 3-15 Install SNMP card

----End

Dry contact expansion card/BMS expansion card



The installation way for the dry contact expansion card and the BMS expansion card is the same. Here we take the dry contact expansion card as example.

Step 1 Unscrew the screws on the dry contact expansion card and dismantle the dry contact expansion card plate on the system control box, as shown in Figure 3-16.




Figure 3-16 Dismantle the dry contact card plate

Step 2 Install the dry contact expansion card on the system monitor box, as shown in Figure 3-17.




Figure 3-17 Install the dry contact expansion card

----End

Surge protection device



DANGER

Before installing the surge protection device, it must power off UPS completely.

It's recommended to require installing the surge protection device before shipping. If the surge protection device is selected after shipping, the surge protection device installation is as follows.

Step 1 Dismantle the surge protection device plate, as shown in Figure 3-18.




Figure 3-18 Dismantle the surge protection device plate

- Step 2 Remove the wire for the battery cold start button. The position of the battery cold start button is as shown in Figure 2-5.
- Step 3 Install the fixed plate for the surge protection device, as shown in Figure 3-19.




Figure 3-19 Install the fixed plate for the surge protection device

Step 4 Install the SPD and surge protection switch in the fixed plate, as shown in Figure 3-20.




Figure 3-20 Install the SPD and surge protection switch

Step 5 Connect the wires of the SPD and surge protection switch to the corresponding copper bars and plates respectively, as shown in Figure 3-21.




Figure 3-21 The wiring for the surge protection device

Step 6 Knock off the knock-off hole of the surge protection device plate and file the disconnected position through file. The position of the knock-off hole is as shown in Figure 3-22.




Figure 3-22 The position of the knock-off hole

Step 7 Install the surge protection device plate, as shown in Figure 3-23.




Figure 3-23 Install the surge protection device plate

----End

Battery tripper control accessory



DANGER

Before installing the battery tripper control accessory, it must power off UPS completely.

It's recommended to require installing the battery tripper control accessory before shipping. If the battery tripper control accessory is selected after shipping, the battery tripper control accessory installation is as follows.

Step 1 Take the battery tripper PCB board out and install it in the rear of UPS through five M4 screws, as shown in Figure 3-24.




Figure 3-24 The position of battery tripper PCB board

Step 2 Connect the CN1~CN5 of PCB board to the copper bars of UPS and user, the wiring is as shown in Figure 3-25, Figure 3-26, Figure 3-27.




Figure 3-25 Battery tripper board connection




Figure 3-26 CN1, CN2 terminal connection

M NOTE

The CN1 is connected to the output dry contact of system monitor card based on the touch screen configuration. Draw the CN1 wires through the knock-off holes of bottom plate when wiring.

The wiring path of the CN2 is the same to the CN1.




Figure 3-27 CN3, CN4, CN5 terminal connection



CAUTION

Avoid the wire contacting copper bar when wiring, or it may cause wire abnormal for copper bar hot.

----End

3.5 Electrical Connection

In default, the wiring method of the IST6 120KVA is bottom wiring. When it needs the top wiring(the cross-sectional area of wire is less than 120mm²), it needs to select the top wiring accessory to realize the top wiring.

Step 1 Open the door of UPS, and dismantle the bottom wiring plate and rear plate, as shown in Figure 3-28.




Figure 3-28 Dismantle the bottom wiring plate and rear plate

Step 2 Draw the input wires, output wires, battery wires through the bottom wiring holes(as shown in Figure 3-29), connect them to the corresponding copper bar(as shown in Figure 3-30) respectively, and fasten the bolts.




Figure 3-29 The position of wiring hole

User Manual 3 Installation




Figure 3-30 The position of the copper bar

M NOTE

There has two neutral wire copper bars, the neutral wires of input and output connect to one neutral wire copper bar, the neutral wires of battery connect to the other neutral wire copper bar.




Figure 3-31 The position of the grounding copper bar

M NOTE

When the mains and bypass is with the same power, the bypass copper bar doesn't need to connect wires.

When the mains and bypass is with the different powers, dismantle the copper bars(as shown in Figure 3-32) for the mains and bypass with the same power.

3 Installation User Manual




Figure 3-32 Dismantle the copper bars for the mains and bypass with the same power

M NOTE

The copper bars near the front door of UPS are the bypass copper bars. The back copper bars are the mains copper bars.

When the top wiring component is selected, draw the wires through the top wiring holes of UPS, the wiring diagram is as shown in Figure 3-33.




Figure 3-33 Top wiring diagram (top wiring accessory is selected)

User Manual 3 Installation



When the wiring method is top wiring, draw the output wires, battery - wires, neutral wire(three pieces) through the left of UPS, and draw the input wire, battery + wires, neutral wire(two pieces) through the right of UPS.



CAUTION

Add a DC switch when battery DC input, the wiring is as shown in Figure 3-34.




Figure 3-34 Battery wiring

Step 3 After wiring, fill the empty part of the wiring hole with insulated fireproofing mud. Install the bottom wiring plate and rear plate, and close the front door.

----End

3.6 Parallel System Connection

When user needs to perform the parallel system connection, please refers to Figure 2-21 and Figure 2-22. The following take two UPSs as example.

3 Installation User Manual

Top wiring




Figure 3-35 Parallel system connection diagram (top wiring)



The wire color above is just used to distinguish the different ports, the actual wire color may not be the same as shown in the figure.

Bottom wiring




Figure 3-36 Parallel system connection diagram (bottom wiring)



The wire color above is just used to distinguish the different ports, the actual wire color may not be the same as shown in the figure.

3.7 System Check and Test

3.7.1 Check Electrical Connection

After finishing the electrical connection, check the following items.

Table3-2 Check list

No.	Check item	Result
1	Check if the color of AC wires is in accordance with the specification.	Yes□ No□
2	Check if the wiring of the UPS is firmly.	Yes□ No□
3	Check if the safety mark of AC distribution unit is complete.	Yes□ No□
4	Check if the wire connection is firmly.	Yes□ No□
5	Check if the battery is connected in right polarity and sequence.	Yes□ No□
6	Check if the wire mark is correct.	Yes□ No□
7	Check if the wiring is neat and the wire connection is in accordance with the specification.	Yes□ No□
8	Check if the UPS installation and wiring is good for transformation, expansion and maintenance in future.	Yes□ No□
9	Check if the UPS has any foreign matter. (E.g. The rear of module, the top of UPS, wiring terminal bar, switch and so on.)	Yes□ No□

3.7.2 UPS Test

Switch off the mains input to simulate the situation of mains fault. When mains fault, it will turn to battery inverter from mains inverter, and the touch screen will show the alarm and the buzzer will beep once every 1s.

3 Installation User Manual

3.7.3 Connect Load

After the UPS works stably, turn on the load. Start large power devices first, then small power device. Some devices has large starting current which may cause overload protection (or bypass operation), it is better to start these devices first.

4 Touch Screen Operation

This chapter mainly introduces the working parameters, working status and system setting of the UPS.

MOTE

The value in the figures of this chapter is just for illustration, for real page please see the actual product.

4.1 Menu Hierarchy




Figure4-1 Menu hierarchy

4.2 Main Page

After powering on, it will enter the main page, as shown in Figure 4-2.




Figure 4-2 Main page

After entering the main page, user can monitor the system conveniently. The icon meaning on the main page is as follows.

- : System bypass input. When bypass input abnormal, the icon flickers and shows as
- : System mains input. When mains input abnormal, the icon flickers and shows as
- Rectifier information. Click the icon, you can select and check the rectifier information of each module.
- : Inverter information. Click the icon, you can select and check the inverter information of each module.
- Battery status. When battery abnormal, the icon flickers and shows as
- : System output status. When output abnormal, the icon flickers and shows as
- : Back to main page.
- : Information record.
- : System parameter setting.
- ے : Login.





· Alarm



The working status and energy flow on the main page shows the system running status and module running condition directly.

4.3 System Work Status Display

The system working status includes: fault protection, shutdown, bypass output, inverter output, grid-tied aging running, ECO bypass output, transducer INV. output, maintenance bypass output, grid-tied aging off. Each page is as shown from Figure 4-3 to Figure 4-11.




Figure 4-3 Fault protection, with no output




Figure4-4 Shutdown




Figure 4-5 Bypass output




Figure 4-6 Battery INV. output




Figure 4-7 Mains INV. output




Figure 4-8 Grid-tied aging running




Figure4-9 ECO bypass output




Figure4-10 Transducer INV. output




Figure 4-11 Maintenance bypass output

When module or system abnormal, the main page will show "Fault alarm" indicator, click the "Fault alarm", it will show the current fault information, as shown in Figure 4-12.




Figure 4-12 Current fault information

4.4 Buzzer Control Function

When module or system abnormal, the system will send sound alarm. User can click the at left to close or open the buzzer. After closed, if there is new fault, the buzzer will be opened automatically.

4.5 Monitor Page

4.5.1 Mains Input

In main page, click icon, it will enter the mains information page, as shown in Figure 4-13. In the page, it shows the mains phase voltage, mains line voltage, mains current, mains frequency and total input electricity.




Figure4-13 Mains information

4.5.2 Bypass Input

In main page, click icon, it will enter the bypass information page, as shown in Figure 4-14. In the page, it shows the bypass phase voltage, bypass line voltage, bypass current and battery frequency.




Figure4-14 Bypass information

4.5.3 Battery Input

In main page, click icon, it will enter the battery information page. If the battery is lead-acid cell, it shows the positive and negative battery voltage, battery charge/discharge current, battery remaining capacity, battery remaining time, battery temperature, battery status. It shows the charging current or discharging current according to battery charge/discharge status, as shown in Figure 4-15.




Figure 4-15 Battery information

4.5.4 REC. Module

In main page, click icon, it will enter the REC. information page, as shown in Figure 4-16. Click "Module" button, it can view the information of each power module.




Figure 4-16 REC. information

4.5.5 INV. Module

In main page, click icon, it will enter INV. information page, as shown in Figure 4-17. Click "Module" button, it can view the information of each power module.




Figure 4-17 INV. information

4.5.6 Output Information

In main page, click icon, it will enter the output information page, as shown in Figure 4-18. In the page, it shows the output phase voltage, output line voltage, output current, output active power,

output apparent power, output load rate, output power factor, output frequency and total output electricity.

\wedge				Output information
ш		U-N/U-V	V-N/V-W	W-N/W-U
\bigcirc		U-IN/U-V		VV-IN/ VV-O
~	Output phase voltage(V)	220.6	222.1	220.3
***	Output line voltage(V)			
Q	Output current(A)	0	0	0
	Output active power(kW)	0.0	0.0	0.0
ို့	Output apparent(kVA)	0.0	0.0	0.0
	Output load rate(%)	0.0	0.0	0.0
\triangle	Output power factor	0.000	0.000	0.000
	Output frequency(Hz)		49.99	
口》	Total output elec.(MWh)		6.28	
()				Back

Figure 4-18 Output information

4.6 Set Manage

In main page, click icon, it will enter the set manage page, as shown in Figure 4-19. In the page, it shows cabinet set, battery set, battery test, output set, smart mode, dry contact, HMI set, password set, comm. set and record manage.




Figure 4-19 Set manage

4.6.1 Cabinet Set

In set manage page, click Cabinet set icon, it will enter the cabinet set page, as shown in Figure 4-20.




Figure 4-20 Cabinet set

MOTE

Battery cells setting: In the cabinet set page, click **battery set** to perform the battery cells setting, as shown in Figure 4-21 .




Figure 4-21 Cabinet set-battery set

4.6.2 Battery Set

In set manage page, click

Battery set icon, it will enter the battery set page, as shown in Figure 4-22.




Figure 4-22 Battery set

4.6.3 Output Set

In set manage page, click output set icon, it will enter the output set page, as shown in Figure 4-23.




Figure 4-23 Output set

4.6.4 Smart Mode

In set manage page, click Smart mode icon, it will enter the smart mode page, as shown in Figure 4-24.




Figure 4-24 Smart mode

4.6.5 Dry Contact

In set manage page, click Day contact icon, it will enter the dry contact page, as shown in Figure 4-25.



Figure 4-25 Dry contact

4.6.6 Battery Test

In set manage page, click

Battery test icon, it will enter the battery test page, as shown in Figure 4-26.




Figure 4-26 Battery test

4.6.7 Communication Set

In set manage page, click comm. set icon, it will enter the communication set page, as shown in Figure 4-27.




Figure4-27 Communication set

4.6.8 Record Manage

In set manage page, click record manage page, as shown in Figure 4-28.




Figure4-28 Record manage

4.6.9 HMI Set

In set manage page, click icon, it will enter the HMI set page, as shown in Figure 4-29.



Figure4-29 HMI set

4.6.10 Password Set

In set manage page, click

Password set icon, it will the password set page, as shown in Figure 4-30.




Figure4-30 Password set

NOTE
The initial user password is 111.

4.7 Information Manage

In main page, click icon, it will enter the information manage page, as shown in Figure 4-31.



Figure 4-31 Information manage



CAUTION

It can record 10000 pieces information at most. When the record exceeds 10000 pieces, the earliest information will be covered by new one. All records are ranked in reverse order of time.

4.7.1 Run Information

In information manage page, click Run info. icon, it will enter the run information page, as shown in Figure 4-32.




Figure4-32 Run information

4.7.2 History Record

In information manage page, click History record icon, it will enter the history record page, as shown in Figure 4-33. In the page, it shows the history fault and alarm information of system and module.



Figure4-33 History record

4.7.3 User Log

In information manage page, click User log icon, it will enter the user log page, as shown in Figure 4-34. In the page, it shows the user parameter setting record.



Figure4-34 User log

4.7.4 Smart Record

icon, it will enter the smart record page, as shown in In information manage page, click Figure 4-35.



Figure4-35 Smart record

4.7.5 Smart Wave Record

In information manage page, click Figure 4-36.



smart wave icon, it will enter the smart wave record page, as shown in



Figure4-36 Smart wave record

4.7.6 Device Information

In information manage page, click icon, it will enter the device information page. In the page, it shows the product name, model, S/N, product version, etc, as shown in Figure 4-37, Figure 4-38, Figure 4-39.

Figure 4-37 Product information 1




Figure 4-38 Product information 2



Figure 4-39 Product information 3

4.8 ON/OFF

In main page, click icon, it will enter the ON/OFF page. When the system is OFF, click the icon to enter the confirm page, as shown in Figure 4-40. Click **Confirm** button to perform the startup operation.




Figure4-40 Power on prompting

5 Use and Operation

This chapter mainly introduces the operation process and method, including use announcements, operation process, UPS ON/OFF operation and parallel system ON/OFF operation, etc.

5.1 Use Announcements

- Before starting the UPS, check whether the load is proper. The load must not exceed the rated power of the UPS, which is to avoid overload protection.
- Do not use the <ON> and <OFF> buttons on the panel of UPS as the power switch of load. Do
 not start the UPS frequently.
- After the UPS works stably, turn on the load. Some devices has large starting current which may
 cause overload protection, it is better to start these devices first. Start large power device first,
 then small power device. If you want to turn off UPS, it must turn off load first.
- When mains power outage, if the UPS is power supplied by generator, it is necessary to start the
 generator firstly. After the generator works stably, the UPS can be connected, or it may cause
 UPS or load damage. If it needs to close generator, it must close UPS firstly.

5.2 Operation Process

Operation process is as shown in Figure 5-1. If it starts UPS at the first time, it is necessary to do the checking before power-on, see **5.3.1 Check Before Power-on**. If all OK, power on UPS. If the UPS isn't used for a long time, it also needs to be checked before power-on.




Figure 5-1 Operation process

5.3 ON/OFF Operation

5.3.1 Check Before Power-on

Before startup, do the check according to following steps. If all OK, start UPS.

- Step 1 Ensure that the mains switch(POWER), bypass switch(BYPASS), output switch(OUTPUT), maintenance bypass switch(MAINTENANCE) are all OFF.
- Step 2 Check load.
 - Ensure that the load is not conductive load. The UPS output cannot be connected with conductive load, such as motor, fan, air-conditioner, etc. Generally, grid supplies power for these loads.
 - Ensure that the load is closed. At the same time, the load capacity should not exceed the rated output capacity of UPS, or, it will cause overload protection.
- Step 3 Ensure that there is no short-circuit between the live wire and neutral wire, live wire and grounding wire in the input and output.
- Step 4 Measure the AC voltage of mains input terminals, and the voltage should be in the range of 80V~280V, or, it only can use battery to start UPS.
- Step 5 Measure the DC voltage of battery input terminals. The voltage of positive battery group should be greater than a certain value (+11.5× battery amount), the voltage of negative battery group should be less than a certain value (-11.5× battery amount), and pay attention to the polarity, avoid wrong battery connection.
- Step 6 Ensure that the auxiliary contact of battery switch is connected to a input dry contact of system monitor card, and display the corresponding information on the touch screen.

----End

5.3.2 Start UPS

- Step 1 Ensure that all the system parameters setting in **5.3.1 Check Before Power-on** are right .
- Step 2 Switch off the ready switches of bypass module(BM) and all power modules(PM).
- Step 3 Switch on the bypass switch → mains switch → external battery switch, it will in bypass power supply mode. (If it is battery cool start, only just switch on the external battery switch, and then press the battery cold start button on the bypass module for more than 3s, the system power is set up.)
- Step 4 Start the inverter.

• Startup method 1: ON combination button on the panel

When the green indicators of all power modules slowly flicker, press ON combination button on the panel for 3s, the system will turn to the inverter output. View the system running status in the touch screen to check if the system turns to the inverter power supply mode. During test, check if the output voltage and output frequency of UPS are normal through the real-time data in the touch screen.

• Startup method 2: Touch screen

In main page of touch screen, click icon, it will enter the ON/OFF page, as shown in Figure 5-2, click **Confirm** button to perform the startup operation. After starting the inverter, UPS will turn to the inverter output. View the system running status in the touch screen to check if the system turns to the inverter power supply mode. During test, check if the output voltage and output frequency of UPS are normal through the real-time data in the touch screen.



Figure 5-2 Power on prompting

- Step 5 Switch on the output switch, check if the output voltage and output frequency of UPS are normal by multimeter. If yes, UPS can be used.
- Step 6 Start the load. Generally, start large power device first, then small power device.

----End

5 Use and Operation User Manual

5.3.3 Shut Down UPS



CAUTION

If the bypass is normal, after the inverter shutdown, system will turn to the bypass power supply mode. If bypass is abnormal, after the inverter shutdown, system will be with no output. Before performing shutdown operation, please ensure that the load is closed.

- Step 1 Close the user load.
- Step 2 Shut down the inverter.
 - Shutdown method 1: OFF combination button on the panel
 Press the panel OFF combination button on the panel for 3s, the system will turn to the bypass output from inverter output. View the system running status in the touch screen to check if the system turns to the bypass power supply mode.
 - Shutdown method 2: Touch screen

In main page, click icon, it will enter the ON/OFF page, as shown in Figure 5-3, click Confirm button to perform the shutdown operation.



Figure 5-3 Power off prompting

Step 3 Switch off the external battery switch → mains switch → bypass switch → output switch.

Step 4 After the touch screen and all LED indicators are off, the UPS is completely shut down.

----End

5.3.4 Switch to Bypass Mode Manually



CAUTION

Before shutting down the inverter, please ensure that the bypass is normal. If bypass is abnormal, after shutting down the inverter manually, the system will be with no output and the power supply for load will be broken off.

Shut down the UPS inverter, please see **Step2** in the **5.3.3 Shut Down UPS**, The system will turn to the bypass supply power mode automatically.



When the bypass input voltage or frequency exceeds the setting value, shutting down the inverter will cause system without output, and the power supply for load will be interrupted.

5.3.5 Switch to Maintenance Bypass Mode From Mains Mode



CAUTION

The following operations only can be performed by professionals. Any device damage caused by violating the general safety operation requirements or safety standards of design, production, and usage will be out of Allis Electric's guarantee range.

Step 1 Shut down the inverter. In main page, click button to shut down inverter.



icon, it will the ON/OFF page, click Confirm

MOTE

The inverter also can be shut down by OFF combination button on the panel. Generally, it isn't recommended to operate like this.

Step 2 After switch to bypass and the energy flow on the touch screen shows bypass output, set the maintenance bypass switch to ON.

5 Use and Operation User Manual

Step 3 Switch off the mains switch→external battery switch→bypass switch.

Step 4 Switch off the output switch, after the touch screen and all LED indicators are all off, the maintenance can be done.



CAUTION

During maintenance, it is strictly forbidden to switch off the output switch.

----End

5.3.6 Switch to Inverter Mode from Maintenance Bypass Mode



CAUTION

Before perform the operation of switching to inverter mode from maintenance bypass mode, please ensure that the system bypass input is normal.

- Step 1 Switch on the bypass switch → mains switch → external battery switch → output switch.
- Step 2 After the power is normal and the energy flow on touch screen shows bypass output, set the maintenance bypass switch to OFF. At this time, the bypass supplies power for load.
- Step 3 Start the inverter.

When the green indicator of all power modules slowly flicker, click icon to enter the ON/OFF page, click **Confirm** button to start inverter. The UPS turns to inverter output.



The inverter also can be started by ON combination button on the panel. Generally, it isn't recommended to operate like this.

----End

5.3.7 Emergency Power Off (EPO)



CAUTION

Don't perform the EPO operation unless emergency.

Press the EPO button on the panel or external EPO button of system, the UPS will turn to emergency power off status. At this time, the touch screen shows EPO protection, and the buzzer long beeps.



CAUTION

- After pressing the EPO button, the UPS will be with no output, the power supply for load is interrupted.
- When the system stays in maintenance bypass mode, after pressing EPO button, the UPS still has output.

5.3.8 Emergency Power Off Recovery

- Step 1 Ensure that the dry contact of system monitor card, which connected to the external EPO switch, is not in emergency power off status.
- Step 2 Switch off the mains switch, output switch and battery switch, and wait for all LED indicators off, the UPS is completely shut down.
- Step 3 Switch on the mains switch, bypass switch, battery switch, system will be started again, and EPO removes.

----End

5.4 Parallel System ON/OFF Operation

5.4.1 Start Parallel System



CAUTION

- 1. Before starting the parallel system, please perform the **5.3 ON/OFF Operation** for each UPS.
- 2. Before starting the parallel system, please ensure that the wire connection in the output and output and phase sequence is right and the parallel wire is well connected and stay in disconnection status.
- 3. Before completely starting the parallel system, please do not start load, and ensure that all switches of load are off.
- 4. Before performing the parallel wire operation, please do not connect the parallel wire.
- Step 1 Measure the front-end voltage and frequency of input switch of all UPSs(including mains switch and bypass switch) or external input distribution switch. Voltage range: 80V-280V, frequency range: 40Hz-70Hz.
- Step 2 Connect the parallel wires, switch on the mains switch and bypass switch of all UPSs(keep the output switch of all UPSs on off status). If the input power is normal, the rectifier will start automatically, and the touch screens begin to start.
- Step 3 Connect the battery to the parallel system.
- Step 4 If the monitor page of each UPS has no alarm, switch on the battery switch of each UPS(If there are many groups of batteries, it needs to switch off the switch of each battery group, and then switch off the total switch between UPS and battery groups). Measure the voltage of battery switch by multimeter (If there are many groups of batteries, measure the voltage of battery switch of each battery group, and then measure the voltage of total switch). Ensure that the battery connection is normal (the "battery circuit abnormal" alarm on the main page of touch screen disappears in 2min).
- Step 5 Check if the system alarms are all disappeared. If there is any fault alarm, please stop the startup operation and inform serviceman to solve the problem till all faults are removed.
- Step 6 Start the inverter of each UPS. Ensure that each UPS stay in bypass power supply mode and the system has no alarm, start the inverter of each UPS manually, and all UPSs turn to inverter mode.
- Step 7 Measure the output voltage and output frequency of each UPS. After each UPS turns to inverter mode(view the system running status in the touch screen to check if the system is in the inverter power supply mode.), check if the output voltage and output frequency of UPS are normal through the real-time data in the touch screen, measure the front-end output voltage of output switch in output distribution cabinet or external output distribution switch to ensure that the inverter output voltage is normal(output voltage = output voltage setting $\pm 2V$), and ensure that the inverter output frequency is

User Manual

normal(output frequency = output frequency setting $\pm 0.1 \text{Hz}$). Record the measured output voltage effective value of each UPS).

- Step 8 Compare the output voltage of each UPS. After measuring the output voltage and frequency of each UPS, compares the output voltage of each UPS, ensure that the phase voltage effective value difference of any two UPSs is less than 5V, and then the parallel operation can be done. If it does not meet the requirement, the UPS with big voltage difference be connected in parallel system, and it is necessary to debug again.
- Step 9 Shut down the inverter of each UPS. Ensure that there is no alarm of each UPS, shut down each UPS manually. All UPSs turn to the bypass power supply mode.
- Step 10 Check the phase sequence of bypass.

Switch on the output switch of UPS1(Ensure that the total switch of load is switched off, or once switching on the output switch of UPS1, it will supply power for load), keep output switches of other UPSs off, set the multimeter to AC position, one pen connects with the output switch front-end phase-U of UPS2 and the other pen connects with the output switch back-end phase-U of UPS2 to measure the voltage difference between the front-end and back-end of output switch of UPS2. Measure the voltage difference of phase-V and phase-W as the same way. If the phase sequence is right, the voltage difference of each phase should be less than 5V. If the phase sequence is not right, at least one phase voltage difference is greater than 5V. Measure whether the bypass sequence of each paralleled UPS is right(When measuring the other UPSs' phase sequence, it doesn't need to operate the switch. Keep the output switch of UPS1 on and the output switches of other UPSs off). If all bypass phase sequence of all UPSs is right, go on next step. If the phase sequence of any UPS is not right, power off the system and check the input and output wiring of each UPS and see if the connection is right.

Step 11 Switch on the output switches of all UPSs.

Ensure that each UPS is with no alarm, switch on the output switches of all UPSs successively. Ensure that the output of all UPSs is in parallel status.

Step 12 Start the inverter of each UPS.

Ensure that the system is with no alarm, manually start the inverter of each UPS successively. System starts inverter output. Monitor that there is no alarm.

Step 13 Shut down the inverter of each UPS.

Ensure that each UPS is with no alarm, shut down the inverters of all UPSs, the system turns to the bypass power supply mode.

Step 14 Switch on the total output switch of load.

5 Use and Operation User Manual

After the parallel system turns to the bypass power supply mode, switch on the total output switch of load, bypass supplies power for load.

Step 15 Start each UPS successively, the system will turn to the inverter power supply mode.

----End

5.4.2 Shut Down Parallel System



CAUTION

If the bypass is normal, after the inverter shutdown, system will turn to the bypass power supply mode. If bypass is abnormal, after the inverter shutdown, system will be with no output. Before performing shutdown operation, please ensure that the load is closed.

- Step 1 Shut down all loads in the parallel system, keep the UPS running without load for a while for heat dissipation.
- Step 2 Perform **5.3.3 Shut Down UPS** to shut down all UPSs, system turns to the bypass power supply mode.
- Step 3 Switch off the total load switch, output switch (OUTPUT), battery switch, bypass switch (BYPASS) and mains switch (POWER) of each UPS successively.

----End



If it just needs to shut down the inverter of the UPS, system turns to the bypass power supply mode and the load without power outage, just perform **Step 2**. If it needs to shut down all UPS system, perform all above steps.

5.4.3 Emergency Power Off(EPO)

Single UPS running

Press the EPO button of the UPS or the EPO button of total system, the UPS will be shut down and close all outputs.

Multi UPSs running in parallel

• EPO linkage is enabled.

Press the EPO button of any UPS or the EPO button of total system, all the paralleled UPSs will be shut down and close all outputs.

• EPO linkage is disabled.

Press EPO button of one UPS, the output of this UPS will be closed.

Press the EPO button of total system, all paralleled UPSs will be shut down and all output will be closed.

6 Maintenance and Troubleshooting

This chapter mainly introduces the maintenance guide, battery maintenance, battery replacement announcements and troubleshooting, etc.

6.1 Maintenance Guide

Proper maintenance is the key to make the device operate in best status and with a longer service life.

6.1.1 Safety Precautions

To ensure human safety and device security, observe the following precautions.

- Please keep in mind that there is dangerous voltage inside the UPS even if the UPS does not
 operate. Before maintenance, use a multimeter to check the voltage and make sure that the UPS
 is completely shut down and stays in safe status.
- Before switching off the battery switch at any time, use a multimeter to measure if the voltage of
 wiring terminal is normal and the polarity is reverse connected. If the result is abnormal, it is
 strictly forbidden to close the battery switch.
- Do not wear any conductive metal objects during operation, such as ring, watch.
- Observe safety regulations strictly. If any doubt, consult professionals.

6.1.2 Preventive Maintenance

To improve the reliability and efficacy of the UPS, perform the following maintenance tasks on a quarterly basis.

- Keep the operating environment free from dust and chemical pollutants.
- Check if the terminals in the input and output are in good contact every half year.
- Check the working status of fans periodically and avoid sundries blocking the air vents. If a fan is damaged, maintain or replace it in time.
- Check the voltage of battery group periodically, ensure that the battery voltage is within the normal range.
- Check the UPS status periodically and ensure that any fault can be found in time.

6.2 Battery Maintenance

- Battery charge requirements
 - When using the battery at the first time, please start the UPS and charge the battery for 24h. During charging, the UPS still can be used, but if power outage occurs at the same time, the battery discharge time may be less than the standard vale this time.
 - Generally, the battery needs to be charged and discharged every 4 to 6 months. First, discharge till 1/3 of battery capacity and then charge the battery. The charge time of each time cannot be less than 24h.
 - In high temperature area, the battery needs to be charged and discharged every 2 months and the charge time of each time cannot be less than 24h.
 - If the battery will not be used for a long time, it also needs to charge the battery every 3 months and the charge time of each time cannot be less than 24h.
- Clean battery shells by cloth. Oil and organic solvents, such as petrol and diluents are prohibited.
- Keep batteries far away from fire sources and devices that easily generate sparks to avoid explosion.
- Avoid over-discharge the battery during using. Fully charge the battery immediately after discharge(24h at most) and then the battery can discharge again. It is strictly forbidden to discharge the not fully charged battery, or, it will cause battery capacity decrease even battery damage.
- To avoid battery discharging for too much time after mains power outage, switch off the battery switch when the UPS is not used.

6.3 Battery Replacement Announcements

- Do not put the battery into fire to avoid explosion.
- Do not open or disassemble the battery, for the inner electrolyte is harmful for skin and eyes.
- Recycle the battery according to the relative illustration on the battery.
- The battery should be replaced in whole group, do not use the new battery and old battery together.
- A new battery should be with the same capacity, model, and manufacturer as the replaced one. The battery with different capacity, different type and different manufacturer battery is strictly forbidden to use together.

Dangerous voltage may exist in the battery terminal and grounding terminal, before touching,
 please measure if there is dangerous high voltage, which is to avoid endanger human safety. It is
 strictly forbidden to touch the two wiring pillars or the bare end of battery.

6.4 Troubleshooting

6.4.1 Common Abnormal Phenomena Diagnosis

If the UPS works abnormally after startup, please refer to Table6-1 to find possible reason. Meanwhile, check if the fault is caused by external environment, such as temperature, humidity is not accordance with the requirement or overload.

Table6-1 only includes some simple diagnosis. If the diagnosis is not clear, or not sufficient to solve the problem, please contact with local agency or dealer to deal with.

Table6-1 Troubleshooting

NO.	Abnormal phenomenon	Possible reason
1	Mains is normal, but UPS works in battery inverter status, the buzzer beeps intermittently.	Each connection point, socket of grid circuit is poor contact, which causes the AC power supply input blocked.
2	After installation, switch on switches or power switch, the fuse will fuse or trip off.	The three-phase input wires are wrongly connected, such as neutral wire and grounding wire or live wire and grounding wire (case) is wrongly connected or the three-phase output wires are wrongly connected.
3	After startup, the UPS outputs 220V AC power, but the UPS works in bypass status.	 The load is too large, which exceeds the rated output capacity of the UPS. It needs to reduce load or select a UPS with larger output capacity. If it is temporary bypass caused by the impact of load startup, and it can recover to normal automatically, that is normal.

NO.	Abnormal phenomenon	Possible reason
4	The UPS output normally after startup, but once start load, the UPS stops outputting immediately.	 The UPS is serious overload or the output circuit is short-circuit. It is necessary to reduce load to proper capacity or find the reason of short-circuit. Common reason is the output socket is short-circuit or input short-circuit caused by device damage. The load is not started according to the sequence from large power device to small power device. You should restart the UPS. After the UPS runs stably, start the load according to the sequence from large power device to small power device.
5	The UPS works normally after startup, but some time later, the UPS shuts down automatically.	In the battery supply power mode, the battery is runs out and system takes the battery under-voltage protection, the UPS shuts down automatically. This phenomenon is normal. Once mains is normal, system will start and charge battery automatically. Warning: If the battery stays in under-voltage status for a long time, it will influence the battery service life. After taking battery under-voltage protection, if mains cannot recover for a long time, please switch off the battery switch to protect battery and restart the UPS and fully charge the battery once mains recovers.
6	The UPS works normally after startup for a long time, buzzer long beeps and the touch screen shows battery low-voltage.	The grid voltage is too low, and the UPS works in battery inverting status, finally, the battery is under-voltage and takes the under-voltage protection.

NO.	Abnormal phenomenon	Possible reason
7	When there is mains, the UPS outputs normally. When there is no mains, the UPS is with no output.	 Battery fault or the battery group is serious damaged. Charger fault. The battery cannot be charged and causes battery energy insufficient. Battery wire is not well connected or the contact of wire terminal is poor. Battery switch is not switched off. After serious overload, the UPS is not restarted, which causes that the UPS is in bypass output status.
8	Buzzer long beeps, the UPS turns to bypass supply power mode.	See the fault information on touch screen.
9	There is mains, but buzzer beeps intermittently.	The mains voltage or frequency exceeds the allowable range of the UPS.
10	At mains status, the UPS works normally, once power outage, the UPS works normally but load system halt.	The grounding is not poor and the floating voltage between neutral wire and grounding wire is too high.
11	FAULT indicator of a power module is on.	The power module is fault, replace it in time.

6.4.2 Emergency Dispose for System Fault

• How to deal with the system fault in emergency

When system fault, shut down the power of UPS by the touch screen, if necessary, shut down the user load and switch off the input and output switch of the UPS to avoid further UPS damage. Inform the engineering technicist to maintain.

How to deal with the fault of single power module in emergency

When one power module fault, it will be insulated with system automatically. Generally, it will not influence the system normal operation, but it will decrease the redundancy degree of the module. At this time, please shut down the fault module and pull it out of the cabinet, and then inform the engineering technicist to maintain.

After pulling out the module, there still has high voltage inside the module and on the rear connector pin. It is necessary to wait enough time (≥ 10 min) and then open the cover to maintain.

7 Package, Transportation and Storage

This chapter mainly introduces the package, transportation and storage of the UPS.

7.1 Package

During packing, please pay attention to the place direction requirements. At the side of the package, there is afraid of wet, handle with care, upward, stack layer limit, etc. alarm marks. And also, the device model is printed on the package. At front of the package, the LOGO of Allis Electric Company and device name is printed.

7.2 Transportation

During transporting, pay attention to the warning marks and avoid severe impact on the device. Place the device according to the marked direction, which is to avoid damage the component. Any inflammable, explosive, corrosive object is not allowed to shipping with the device. While midway transportation, do not put the device in the open air. The device cannot suffer any rain, snow or liquid material or mechanical damage.

7.3 Storage

When storing the device, place the device according to the marked direction. The package box should be far away from ground for 200mm, and keep at least 500mm from wall, heat source, cold source, window or air inlet.

Storage temperature: -25~55°C (Exclude battery). If the device is transported or stored out of the storage temperature, before installation and startup, put the device aside and let the device temperature recover to normal range for more than 4h. In the warehouse, any inflammable, explosive, corrosive object or harmful gas is not allowed, and also, strong mechanical shake, impact or magnetic field is forbidden. The storage period of these requirements, generally, is 6 months. If the device stored more than 6 months, it is necessary to check again. If the device is stored for a long time, please charge the battery every 3 months.

A Technical Specifications

Index	Model	IST6 120KVA
	Input mode	3 φ 4W+PE
	Rated input voltage(VAC)	220/230/240(phase voltage)
	Input voltage range	Vin=176Vac~280Vac, it does not need to decrease rated power to use. Vin=80Vac~186Vac, for linear load, it is necessary to decrease rated power to use.
	Input frequency range (Hz)	40~70
Input	Bypass sync tracking range (Hz)	50/60±6
ut	Bypass input voltage(VAC)	220/230/240(phase voltage)
	Input power factor	≥0.99
	Input THDi	Resistive load:≤2%; non-linear full load:≤3%
	Battery voltage (VDC)	$\pm 168 \sim \pm 276$ (It can be selected in the range of ± 14 pieces to ± 23 pieces, the default is ± 16 pieces.) If the battery amount is less than $\leq \pm 16$ pieces, it's is necessary to decrease rated power to use, and decrease the output load capacity to 80%.
	Charge current (A)	Power module amount*10A(Max)
Output	Output mode	3 φ 4W+PE
	Output waveform	Sine-wave

Index	Model	IST6 120KVA
	Voltage(VAC)	L—N: 220/230/240 L—L: 380/400/415
	Frequency (Hz)	When mains is normal, it tracks the bypass input frequency; When mains is abnormal, it tracks the frequency $50\pm0.2\%$ or $60\pm0.2\%$ of the UPS.
	Three-phase phase error	With balance load≤1°
	Wave form distortion(THDv)	Linear load≤1%; non-linear load≤4%
	Bypass inverter switching time (ms)	Sync 0; Async<15
	System efficiency	95%
	Overload capacity	 Inverter overload capacity: Linear load(PF=1.0) For less than 105% load, it runs for long-term; For 106%~110% load, it turns to bypass after 60min; For 111%~125% load, it turns to bypass after 10min; For 126%~150% load, it turns to bypass after 1min; For greater than 151% load, it turns to bypass immediately. Non-linear load(PF=0.9) For less than 105% load, it runs for long-term; For 106%~110% load, it turns to bypass after 60min; For greater than 110% load, it turns to bypass immediately. Non-linear load(PF=0.8) For less than 105% load, it runs for long-term; For greater than 105% load, it turns to bypass immediately.

Model		IST6 120KVA
nidex	Dynamic response transient range Load unbalance capacity	Bypass overload capacity: For less than 130% load, it runs for long-term; For 131%~150% load, it turns to bypass after 5min; For 151%~200% load, it turns to bypass after 1s; For 201%~300% load, it turns to bypass after 100ms; For greater than 300% load, protect immediately. The load changes in the range of 0%~100% or 100%~0%, its output voltage is less than 5%. It can bear 100% unbalance load Equipped with the maintenance bypass switch with no switching
	Manual maintenance bypass DC startup function Touch screen display	Equipped Three-phase input voltage, input frequency, three-phase output voltage, load, battery voltage, battery charge/discharge current, output current of each module and inner temperature, parameter
	LED display Alarm function	Display the working status and fault of UPS Input abnormal, battery low-voltage, overload, fault.
Others	Communication function	 RS232 Build-in SNMP communication Modbus communication Dry contact communication
	Battery monitoring function(optional)	BMS battery monitoring manage system monitors the cell working status in real-time.
	Protection function	Output short-circuit protection, output over-voltage/ under-voltage protection, overload protection, over-temperature protection, battery under-voltage protection, etc.

Index	Model	IST6 120KVA
	EMC	Meet GB7260.2-2009
	Cooling way	Forced wind-cooling
	Wiring method	Bottom wiring in default. It's compatible with top wiring(select the top wiring accessory).

• Specifications are subject to change without prior notice.

B Physical Characters

Model	IST6 120KVA
Wiring method	Top wiring / bottom wiring(in default)
Weight(kg)	Cabinet without module:180 Power module:24 Bypass module:17
Size(W×H×D)(mm)	600×2000×860
Noise(dB)	<65
Protection grade	IP20
Communication function	Dry contact, RS232, RS485, MODBUS, SNMP(optional)
Operating temperature (°C)	-5~40
Storage temperature ($^{\circ}$ C)	-25~55
Relative humidity	0%~95% RH(with no condensation)

C Acronyms and Abbreviations

AC Alternating Current

DC Direct Current

DSP Digital Signal Processor

ECO Energy Control Operation

EPO Emergency Power Off

IEC International Electrotechnical Commission

LED Light-emitting Diode

PE Protective Earthing

RS232 Recommend Standard232

RS485 Recommend Standard485

SNMP Simple Network Management Protocol

THDi Total Distortion of the input current waveform

THDv Total Harmonic Distortion of output voltage

UPS Uninterruptible Power System