JUMO AQUIS touch P

Modular Multichannel Measuring Device for Liquid Analysis with Integrated Controller and Paperless Recorder



Operating Manual

JUMO

20258000T90Z001K000

V12.00/EN/00607974/2024-04-25



Caution!
If the device or a sensor connected to it fails abruptly, it is likely that a dangerous overdosage has occurred!
For this case, appropriate precautionary measures must be taken.



NOTE!
Read this operating manual before putting the device into service.
Keep the operating manual at a location that is readily accessible to all users.

Content

1 Safety information 15
1.1 Warning symbols 15
1.2 Note symbols 15
1.3 Intended use 16
1.4 Qualification of personnel 16

2 Acceptance of goods, storage, and transport 17
2.1 Checking the delivery 17
2.2 Important information about storage and transport 17
2.3 Returning goods 17
2.3.1 Accompanying letter for repair 17
2.3.2 Protection against electrostatic discharge (ESD) 18

3 Device description 19
3.1 Brief description 19
3.2 Block diagram 21
3.3 Device setup 22

4 Identifying the device version 23
4.1 Nameplate 23
4.2 Order details 24
4.3 Scope of delivery 26
4.4 Accessories 27

5 Mounting 29
5.1 Notes 29
5.2 Dimensions 30
5.3 Panel mounting 32

6 Electrical connection 35
6.1 Installation notes 35
6.2 Connecting cables 37
6.2.1 Preparing coaxial cables for pH/redox electrodes 37
6.2.2 Conductor cross-sections for base unit and power supply unit 39
6.2.3 Conductor cross-sections for optional boards 40

Content

6.3 Galvanic isolation 41
6.4 Connection diagram 42
6.4.1 Overview of connections 42
6.4.2 Analog inputs base unit 44
6.4.3 Analog inputs optional boards 46
6.4.4 Analog outputs 56
6.4.5 Binary inputs 57
6.4.6 Digital outputs, power supply unit board 59
6.4.7 Digital outputs, optional boards 60
6.4.8 Mains power connection 61
6.4.9 Voltage supply outputs 62
6.4.10 Interfaces for data and bus communication 63

7 Startup 71
7.1 Initial startup 71
7.2 Digital sensors 72
7.2.1 Initial startup 72
7.2.2 Restarting 76
7.3 Function test 77
7.3.1 Checking the optional boards 77
7.3.2 Checking sensors and inputs/outputs 77

8 Operation 79
8.1 Operating concept 79
8.1.1 Passwords and user rights 79
8.1.2 Display and control elements 81
8.1.3 Menu structure 82
8.1.4 Entry of text and numbers 88
8.2 Device menu 90
8.2.1 Log-on/Log-out 93
8.2.2 User levels 94
8.2.3 Functional level 95
8.2.4 Device info 97

8.2.5 Service 98
8.2.6 Calibrating the touchscreen 99
8.2.7 Digital sensors 99
8.3 Alarm/Event list 104
8.3.1 Alarm list 105
8.3.2 Event list 108
8.4 Memory Manager (USB flash drive) 112
8.5 Operating the controllers 115
8.5.1 Automatic control mode 116
8.5.2 Controller in the manual mode 118
8.5.3 Hold mode 119
8.5.4 Optimizing controllers 120
8.6 Operation of the data monitor/recording function 121
8.6.1 Data monitor/recording function control elements 122
8.6.2 History function 125
8.7 Online visualization 126

9 Parameterization 131
9.1 Date and time 131
9.2 Parameter Sets (Controller parameter) 132
9.3 Setpoint values 135
9.4 Manual values 135

10 Configuration 137
10.1 Notes 137
10.2 Basic settings 138
10.3 Display 139
10.3.1 General information 139
10.3.2 Screen 140
10.3.3 Colors 140
10.4 Operation loop 141
10.4.1 General screens 141
10.4.2 Detailed screens 142

Content

10.5 Analog inputs 143
10.5.1 Base unit temperature inputs 143
10.5.2 Universal inputs of base unit and optional boards 145
10.5.3 Calibration timer 148
10.5.4 pH/Redox/NH_3 analysis inputs 149
10.5.5 Calibration timer 150
10.5.6 CR/Ci analysis inputs (conductive/inductive conductivity) 152
10.5.7 Calibration timer 153
10.5.8 CR/Ci measuring ranges 153
10.6 Analog outputs of base unit and optional boards 157
10.7 Digital inputs of base unit and optional boards 158
10.8 Digital outputs of base unit and optional boards 159
10.9 Alias values 160
10.10 Salinity 162
10.11 Digital sensors 164
10.11.1 General settings for digital sensors 165
10.11.2 Configuration of digital sensors 166
10.11.3 Configuration for sensors with JUMO digiLine electronics 167
10.11.4 Configuration of JUMO ecoLine sensors 184
10.11.5 Configuration of JUMO tecLine sensors 187
10.11.6 Sensor alarms 189
10.11.7 CIP/SIP definition for JUMO digiLine pH and JUMO digiLine CR/Ci 194
10.11.8 CIP/SIP definition for JUMO digiLine O-DO H10/H20 195
10.11.9 Calibration timer 195
10.12 Limit monitoring and alarms 196
10.12.1 Limit value monitoring functions 196
10.12.2 Alarms for analog signals and digital sensors 196
10.12.3 Digital signal alarms 200
10.13 Calibration timer 201
10.13.1 Configuration of the calibration timers 201
10.14 Controller 202

10.14.1 Configuration of the controllers 202
10.14.2 Controller inputs 206
10.14.3 Disturbance feedforward control 207
10.14.4 Autotuning 208
10.15 Setpoint value configuration 209
10.16 Timer 210
10.16.1 Control timer 212
10.17 Washtimer 213
10.18 Counter 214
10.19 Recording 215
10.19.1 Parameter 215
10.19.2 Analog channels 215
10.19.3 Binary channels 216
10.20 Ethernet 217
10.21 Serial interfaces 218
10.22 Modbus TCP 220
10.23 Formula 221
10.24 Logic formula 222
10.25 Manual values (configuration) 222
10.26 External analog inputs 223
10.27 External digital inputs 224
10.28 Flow 224

11 Retrofitting optional boards 227
11.1 Installing optional boards 227
11.2 Ci base calibration 230

12 Calibration in general 235
12.1 Notes 235
12.2 General information 235
12.2.1 General procedure for calibration 235
12.3 Calibration logbook 237

13 Calibrating a pH measuring chain 241

Content

13.1 Notes 241
13.2 General information 241
13.2.1 Calibration methods for pH sensors 241
13.2.2 Calibration default settings for pH sensors 242
13.3 pH Calibration routines 245
13.3.1 Zero-point calibration 245
13.3.2 Two-point and three-point calibration 247

14 Calibrating redox sensors 249
14.1 Notes 249
14.2 General information 249
14.2.1 Calibration methods for Redox sensors 249
14.2.2 Calibration default settings for Redox sensors 250
14.3 Redox calibration routines 251
14.3.1 Zero-point calibration 251
14.3.2 Two-point Calibration 253

15 Calibrating ammonia sensors 255
15.1 Notes 255
15.2 General information 255
15.2.1 Calibration methods for ammonia sensors 255
15.2.2 Calibration default settings for ammonia sensors 255
15.3 Ammonia calibration routines 256
15.3.1 Zero-point calibration 256

16 Calibrating CR conductivity sensors 257
16.1 Notes 257
16.2 General information 257
16.2.1 Calibration methods for CR conductivity sensors (conductive) 257
16.2.2 Calibration presets for CR conductivity sensors 259
16.3 CR calibration routines 262
16.3.1 Calibrating the relative cell constant 262
16.3.2 Calibrating the temperature coefficient 264
16.3.3 Calibrating the TC curve for JUMO digiLine CR 266

17 Calibrating Ci conductivity sensors 269
17.1 Notes 269
17.2 General information 269
17.2.1 Calibration methods for Ci conductivity sensors (inductive) 269
17.2.2 Calibration presets for Ci conductivity sensors 272
17.3 Ci calibration routines 275
17.3.1 Calibrating the relative cell constant 275
17.3.2 Calibrating the temperature coefficient (TC) 277
17.3.3 Calibrating the TC curve 279

18 Calibrating universal inputs 281
18.1 Notes 281
18.2 General information 281
18.2.1 Calibration methods for universal inputs 281
18.2.2 Universal inputs calibration default settings 283
18.3 Universal input calibration routines 285
18.3.1 Zero point/slope calibration (linear scaling) 286
18.3.2 Two-point calibration (linear scaling) 287
18.3.3 Slope calibration (free chlorine, pH/Temp.-compensated) 289

19 Calibrating O-DO sensors 291
19.1 Notes 291
19.2 General information 291
19.2.1 Calibration methods for O-DO sensors 292
19.2.2 Calibration default settings for O-DO sensors 294
19.3 O-DO calibration routine 296
19.3.1 JUMO digiLine O-DO H10 and H20 Humid zero-point calibration .298
19.3.2 JUMO digiLine O-DO H10 and H20 Dry zero-point calibration 299
19.3.3 JUMO digiLine O-DO H10 Humid end-value calibration 300
19.3.4 JUMO digiLine O-DO H10 and H20 Dry end-value calibration 301
19.3.5 JUMO digiLine O-DO H10 Humid two-point calibration 302
19.3.6 JUMO digiLine O-DO H20 Dry two-point calibration 304
19.3.7 Zero-point calibration with JUMO digiLine O-DO S10 305

19.3.8 End value calibration for JUMO digiLine O-DO S10 307
19.3.9 End value calibration for JUMO ecoLine O-DO 308
19.3.10 Two-point calibration for JUMO ecoLine O-DO 310

20 Calibrating turbidity sensors 313
20.1 Notes 313
20.2 General information 313
20.2.1 Calibration methods for turbidity sensors 313
20.2.2 Calibration presets for turbidity sensors 314
20.3 Calibration routines for turbidity sensors 315
20.3.1 Two-point calibration 315

21 Calibration during disinfection measurements 317
21.1 Notes 317
21.2 General information 317
21.2.1 Calibration methods for disinfection measurand sensors 318
21.2.2 Calibration default settings for disinfection measurand sensors 318
21.3 Calibration routine for disinfection measurands 320
21.3.1 End value calibration 320
21.3.2 Two-point Calibration 323

22 PC Setup Program 327
22.1 General information 327
22.2 Installing the JUMO PC setup program 328
22.2.1 Process 328
22.3 Logging onto the setup program 330
22.3.1 Rights in the setup program 331
22.4 QuickStart agent 332
22.5 User interface 334
22.5.1 Elements of the user interface 334
22.5.2 Display protection 336
22.5.3 Editing the setup file 339
22.6 Menu bar 341
22.6.1 File menu 341

22.6.2 Data Transfer menu 343
22.6.3 Extras 345
22.6.4 Windows 346
22.6.5 Info 347
22.7 Connection to device 348
22.7.1 Device connections list 348
22.7.2 Configuring the connection with the assistant 350
22.7.3 Configuring the connection without the assistant 357
22.7.4 Searching for a device in the network 359
22.8 Setting up the device with the JUMO PC setup program 361
22.8.1 Identification 361
22.8.2 Configuring and parameterizing 363
22.8.3 User list 363
22.8.4 Country settings 366
22.8.5 Device character set 372
22.8.6 User levels 374
22.8.7 Formula 375
22.8.8 Logic formula 376
22.8.9 Customer-specific linearization 377
22.8.10 Buffer set tables 380
22.8.11 Process images 381
22.8.12 Email 395
22.8.13 Web server 402
22.8.14 TC curve 404
22.8.15 Modbus frames for reading 404
22.8.16 Modbus frames for writing 404
22.9 Diagnosis 405
22.9.1 Calibration logbooks 405
22.9.2 Digital sensor calibration logbooks 405
22.9.3 Digital sensor connection list 405
22.10 Online parameters 407
22.10.1 Date and time 407

22.10.2 Screenshot 407
22.10.3 Ethernet 408
22.10.4 Approval of extra codes 409
22.10.5 Deleting internal measurement data 409
22.10.6 Adjust / test 410

23 Technical data 417

23.1 Analog inputs base unit 417
23.1.1 Temperature measurement input (IN 4) 417
23.1.2 Temperature measurement input (IN 5) 418
23.1.3 Universal input (IN 6) 418
23.1.4 Measuring circuit monitoring base unit 418
23.2 Analog inputs optional boards 419
23.2.1 Universal input (IN 11, IN 12) 419
23.2.2 Analysis input: pH/Redox/NH_3 419
23.2.3 Analysis input: CR (resistive conductivity) 419
23.2.4 Analysis input: Ci (conductivity, inductive) 421
23.2.5 Temperature compensations 422
23.2.6 Measuring circuit monitoring, optional boards 423
23.3 Analog outputs of base unit and optional boards 424
23.4 Digital inputs base unit 424
23.5 Digital inputs optional boards 424
23.6 Digital outputs, power supply unit board 424
23.7 Digital outputs, optional boards 425
23.8 Voltage supply outputs, optional board 425
23.9 Interfaces 426
23.9.1 Serial interface RS485 (base unit) 426
23.9.2 Serial Interface RS422/485 (optional board) 426
23.9.3 PROFIBUS-DP (optional board) 426
23.9.4 Scanning cycle times for digital sensors 426
23.9.5 Ethernet optional board (10/100Base-T) 427
23.9.6 USB interfaces 428
23.10 Electrical data 429

23.11 Screen Touchscreen 429
23.12 Housing 430
23.13 Functions 431
23.13.1 Controller channels 431
23.13.2 Recording function 431
23.13.3 Customer-specific linearization 433
23.14 Approvals/approval marks 433

24 Annex 435
24.1 Troubleshooting and remedies for digital sensors 435
24.1.1 Possible faults on sensors with JUMO digiLine electronics 435
24.1.2 Possible faults on digital JUMO ecoLine and tecLine sensors 438
24.2 Planning the cabling for digital sensors 441
24.2.1 Introduction 441
24.2.2 Voltage supply to the bus with DC 5 V from a JUMO AQUIS touch P 441
24.2.3 Voltage supply to the bus with DC 5 V from a JUMO digiLine hub 444
24.2.4 Voltage supply to the bus with DC 24 V 446
24.2.5 Voltage supply of the bus for JUMO digiLine CR/Ci 448
24.2.6 Voltage drop calculation 449
24.3 China RoHS 452

Content

1.1 Warning symbols



DANGER!
This symbol indicates that personal injury from electrocution may occur if the appropriate precautionary measures are not taken.



WARNING!
In conjunction with the signal word "Warning", this symbol indicates that the risk of personal injury or death exists if the appropriate precautionary measures are not taken.



CAUTION!
In conjunction with the signal word "Caution", this symbol indicates that the risk of equipment damage or data loss exists if the appropriate precautionary measures are not taken.



CAUTION!
This symbol indicates that components of the device can be destroyed by electrostatic discharge (ESD = Electro Static Discharge) if the appropriate precautionary measures are not taken. When returning modules, assemblies, or components from the device, use only the ESD packaging provided.



READ THE DOCUMENTATION!
This symbol, attached to the device, indicates that the associated device documentation must be followed. This is necessary in order to recognize the nature of the potential danger and take the necessary measures to prevent it.

1.2 Note symbols



NOTE
This symbol refers to **important information** about the product, its handling, or additional benefits.



REFERENCE!
This symbol refers to **further information** in other sections, chapters, or other manuals.



DISPOSAL!
At the end of its service life, this device and any batteries present do not belong in the trash! Please ensure that they are **disposed of** properly and in an **environmentally friendly** manner.

1.3 Intended use

The JUMO AQUIS touch P is designed for measurement, control, and automation tasks in industrial environments as specified in the technical data. Other uses beyond those defined are not viewed as intended uses.

⇨ Chapter 23 "Technical data", page 417

The device has been manufactured in compliance with applicable standards and directives as well as the applicable safety regulations. Improper use can result in personal injury or property damage.

To avoid risks, the device may be used only as follows:

- For the intended use
- When in good order and condition
- When taking the technical documentation provided into account

Risks resulting from the application may arise, e.g. as the result of missing safety provisions or incorrect settings, even when the device is used properly and as intended.

1.4 Qualification of personnel

This document contains the information required to ensure use of the device as intended. It is intended for technically qualified personnel who have received special training and have the appropriate knowledge in the field of automation technology (measuring and control technology).

Understanding and technically correct observance of the safety instructions and warnings contained in the supplied documentation are prerequisites for safe mounting, installation, and commissioning as well as safety during operation.

Only qualified individuals have the required technical knowledge to interpret and put into practice the safety instructions and warnings used in this documentation in any given situation.

2 Acceptance of goods, storage, and transport

2.1 Checking the delivery

- Ensure that the packaging and its contents are undamaged
- Check the delivery for completeness against the packing slip and order details
- Inform the supplier immediately if there is any damage
- retain damaged parts until the situation has been clarified with the supplier

2.2 Important information about storage and transport

- store the device in a dry, clean environment
- observe the permissible ambient conditions,
  ⇨ Chapter 23 "Technical data", page 417
- protect the device from shock during transport
- The original packaging offers optimal protection for storage and transport

2.3 Returning goods

- if repairs are needed, return the device in clean condition and in its entirety
- use the original packaging when returning the device

2.3.1 Accompanying letter for repair

Please include the completed accompanying letter for repair when returning goods. Do not forget to state the following:

- Description of the application
- Description of the error that has occurred

The letter of transmittal accompanying the product return can be downloaded from the Internet at www.jumo.de under Services > Repair service.

2.3.2 Protection against electrostatic discharge (ESD)



CAUTION!
Electrostatic charges occur in non-ESD-protected environments.
Electrostatic discharge can damage assemblies or components.
For transport purposes, use only the ESD packaging provided.

To prevent damage from ESD, electronic modules, or components with a high internal resistance must be handled, packaged, and stored in an environment that protects against ESD. Measures that protect against electrostatic discharge and electric fields are described in DIN EN 61340-5-1 and DIN EN 61340-5-2 "Protection of electronic devices from electrostatic phenomena".

When sending back electronic modules or components, please note the following:

- Pack sensitive components only in an environment providing protection against ESD. Workspaces such as this divert electrostatic charges to ground in a controlled manner and prevent static charges due to friction capacities.
- Use only packaging intended specifically for ESD-sensitive modules/components. These must consist of conductive plastics.

No liability is assumed for damage caused by electrostatic discharge (ESD).

3.1 Brief description

Measure

The JUMO AQUIS touch P provides a central platform for the display and processing of pH value, redox voltage, electrolytic conductivity, resistance of high-purity water, temperature, quantities of disinfecting agents such as free chlorine, total chlorine, chlorine dioxide, ozone, hydrogen peroxide and peracetic acid or even flow rates. Pulse frequency inputs (counters) are available for flow measurement. Universal inputs can be used to measure analog measurands using standard signals [0(4) to 20 mA or 0 to 10 V]. The unit can measure and manage up to 23 parameters simultaneously.

Control

Besides numerous simple alarm, limit value or time-controlled switching functions, up to 4 higher-order control loops can be defined in the JUMO AQUIS touch P at the same time. Tried and tested JUMO control algorithms are used for P, PI, PD, and PID control in these applications.

Show

A 3.5" TFT color screen with touch function serves to display all parameters as well as operate and set up the device. The plain text operation philosophy virtually eliminates the need for a manual. German, English, and, on request, French are included in the device at the factory as selectable user interface languages (see order details). Using the PC setup program, the language library of the unit can be expanded to as many as 15 languages. It is also possible to display languages that use Chinese and Cyrillic characters. As a result, the device is predestined for global use.

Recording

A paperless recorder is integrated for data recording. Up to 16 analog measurands and 12 binary signals are recorded and displayed on the screen in their chronological sequence. Storage is tamper-proof and enables official recording obligations to be fulfilled. The data can be extracted via JUMO PCC software or USB flash drive and evaluated using the PC evaluation software JUMO PCA3000.

3 Device description

Application examples

The modular setup and open structure of the device permits a host of potential applications:

- Municipal and industrial water treatment in wastewater treatment plants
- Process systems
- Drinking and bathing water monitoring
- Pharmaceutical water
- Food and beverage production (CIP/SIP plants)
- Gas scrubbers/air washers
- Cooling tower control
- Ion exchangers
- RO units (reverse osmosis)
- Power stations and energy plants
- Fish breeding
- Desalination of seawater



NOTE

The device is not suitable for use in a potentially explosive atmosphere.

3.2 Block diagram



3 Device description

3.3 Device setup



(1) Mounting elements
(2) Metal case barrel
(3) Rear panel with connection terminals (base unit and optional boards)
(4) Housing front
(5) LED (voltage supply turned on)
(6) Touchscreen TFT color screen
(7) USB interfaces

4.1 Nameplate

The nameplate on the device enclosure identifies the device version.

Example of a nameplate



(1) Data matrix code (for service purposes)
(2) Information symbol (Read documentation!
⇨ Chapter 1.1 "Warning symbols", page 15)
(3) Part no.
(4) Fabrication number
(5) Approval mark
(6) voltage supply
(7) MAC address of the Ethernet interface (stored in device and therefore also valid for replaced or retrofitted Ethernet optional boards)
(8) Order code

It is helpful to become familiar with the technical features of the device prior to startup. Compare the type code on the nameplate with the order details.
⇨ Chapter 4.2 "Order details", page 24
In the event of technical questions, please have the information from the nameplate available for the member of our support team.

4 Identifying the device version

4.2 Order details

NOTE

In addition to the standard languages of German, English, and French, 13 additional languages (e.g. Russian, Chinese, Italian etc.) are available. Please use the contact information on the back of this manual to contact JUMO in this regard.

			Slot
	(1)	**Basic type**	
202580		JUMO AQUIS touch P	
	(2)	**Version**	
8		Standard with default settings	
9		Customer-specific configuration (specification in plain text)	
	(3)	**National language**	
01		German	
02		English	
03		French	
	(4)	**Analysis input 1**	**IN 7**
0		Not used	
1		pH/redox/NH_3	
2		CR conductive conductivity measurement (2 and 4-pole)	
3		Ci inductive conductivity measurement	
	(5)	**Analysis input 2**	**IN 8**
0		Not used	
1		pH/redox/NH_3	
2		CR conductive conductivity measurement (2 and 4-pole)	
3		Ci inductive conductivity measurement	
	(6)	**Input/output 1**	**IN 11, OUT 6/7**
00		Not used	
10		Universal input	
11		Relay (changeover contact)	
12		2× relays (normally open contact)	
13		Solid state relay triac 230 V, 1 A	
14		Logic output 0/22 V	
15		2× logic outputs 0/12 V	
16		Analog output	
17		2× solid state relay PhotoMOS®[a]	

	(7)	**Input/output 2**	**IN 12, OUT 8/9**
00		Not used	
10		Universal input	
11		Relay (changeover contact)	
12		2× relays (normally open contact)	
13		Solid state relay triac 230 V, 1 A	
14		Logic output 0/22 V	
15		2× logic outputs 0/12 V	
16		Analog output	
17		2× solid state relay PhotoMOS®[a]	
19		Power supply output DC ±5 V, 24 V	
	(8)	**Input/output 3**	**IN 13/14/15, OUT 10/11**
00		Not used	
11		Relay (changeover contact)	
12		2× relays (normally open contact)	
13		Solid state relay triac 230 V, 1 A	
14		Logic output 0/22 V	
15		2× logic outputs 0/12 V	
16		Analog output	
17		2× solid state relay PhotoMOS®[a]	
18		3× digital inputs	
	(9)	**Input/output 4**	**IN 16/17/18, OUT 12/13**
00		Not used	
11		Relay (changeover contact)	
12		2× relays (normally open contact)	
13		Solid state relay triac 230 V, 1 A	
14		Logic output 0/22 V	
15		2× logic outputs 0/12 V	
16		Analog output	
17		2× solid state relay PhotoMOS®[a]	
18		3× digital inputs	
	(10)	**Voltage supply**	
23		AC 110 to 240 V +10/-15 %; 48 to 63 Hz	
39		AC/DC 24 V +30/-25 %; 48 to 63 Hz	
	(11)	**COM 2 interface**	**COM 2**
00		Not used	
08		Ethernet	
54		RS422/485 Modbus RTU	
63		PROFINET IO	
64		PROFIBUS-DP	
	(12)	**DNV GL tested**	
000		Without approval	
062		With DNV GL approval	

4 Identifying the device version

(13)	Extra codes
000	Without extra code
213	Recording function
214	Math and logic module
962	JUMO digiLine protocol activated

[a] PhotoMOS® is a registered trademark of Panasonic.

	(1)		(2)		(3)		(4)		(5)		(6)		(7)		(8)		(9)		(10)		(11)	
Order code:	☐☐☐☐☐☐	/	☐	-	☐	-	☐	-	☐	-	☐	-	☐	-	☐	-	☐	-	☐	-	☐	-
Order example:	202580	/	8	-	01	-	1	-	2	-	10	-	10	-	13	-	13	-	23	-	64	-

(12)	(13)	
☐☐☐	/ ☐☐☐	, ...[a]
062	/ 213	, 214

[a] List all desired extra codes separated by commas.

4.3 Scope of delivery

JUMO AQUIS touch P according to order details (including 4x fastening elements)
Panel seal
Mini-DVD with JUMO PC setup program as demo version, Adobe Acrobat Reader, operating manual and data sheet in PDF format, GSD generator and JUMO PCC / PCA 3000 as demo version
Installation instructions in 2 volumes

4.4 Accessories

Order code	Type	Part no.
703571 (20258x)/10	Universal input; galvanically isolated	00581159
703571 (20258x)/10	Universal input; galvanically isolated, without DNV approval	00775887
703571 (20258x)/213	Activation of the recording function	00581176
703571 (20258x)/214	Activate math and logic module	00581177
703571 (20258x)/11	Binary output relay (changeover contact)	00581160
703571 (20258x)/12	Binary outputs 2× relay (normally open contact)	00581162
703571 (20258x)/13	Solid state relay triac 230 V, 1 A	00581164
703571 (20258x)/14	Logic output 0/22 V	00581165
703571 (20258x)/15	2 Logic outputs 0/12 V	00581168
703571 (20258x)/16	Analog output	00581169
703571 (20258x)/17	Digital outputs 2× solid state relay PhotoMOS®[a]	00581171
703571 (20258x)/54	Serial interface RS422/485 for Modbus RTU and JUMO digiLine[b]	00581172
703571 (20258x)/64	PROFIBUS-DP	00581173
703571 (20258x)/08	Ethernet	00581174
20258x/3	Analysis input Ci for inductive conductivity	00584265
20258x/2	Analysis input CR for resistive conductivity	00584263
20258x/1	Analysis input pH/Redox/NH_3	00584264
20258x/18	Digital inputs 3× potential-free contact	00592962
20258x/19	Voltage supply output DC ±5 V, 24 V	00592963
	USB flash drive 2.0 (2 GB)[c]	00505592
	USB cable, A-connector to Mini-B connector, length 3 m	00506252
	JUMO PC setup program AQUIS touch S/P, (PG202599)	00594355
	JUMO PCA3000/PCC software package[d]	00431884
	Surface-mounted case for JUMO AQUIS touch P	00628452

[a] PhotoMOS® is a registered trademark of Panasonic.

[b] The accessories required to install a JUMO digiLine bus can be found in the type sheets and operating manual for the JUMO digiLine components (e.g. JUMO digiLine pH/ORP/T type 202705 or JUMO digiLine hub type 203590).

[c] The indicated USB flash drive has been tested and is designed for industrial applications. No liability is assumed for flash drives from other manufacturers.

[d] Communication and evaluation software for stored recording function measurement data

4 Identifying the device version

5.1 Notes



DANGER!

Under no circumstances may the device be installed or removed while under voltage! This poses the risk of electrocution.

Switch-off the entire system beforehand. This work must be performed only by qualified personnel!

The device must never be installed in potentially-explosive areas! Explosion hazard.

Mounting site

When determining the mounting site, it is important to ensure that the device specifications are respected. The relevant tables containing details of case specifications can be found in the chapter entitled "Technical Data". The device must not be exposed to any severe shocks or permanent vibrations. Electromagnetic fields caused by equipment such as motors or transformers must be avoided!

Climatic conditions

The ambient temperature and the relative humidity at the mounting site must correspond to the technical data.

⇨ Chapter 23.12 "Housing", page 430

Installation position

The device can be installed in any position. However, the viewing angle of the TFT touchscreen should be taken into consideration.

⇨ Chapter 23.11 "Screen Touchscreen", page 429

Space requirement

Ensure adequate access to the region around the cable entry points. The minimum bending radius of the cables must be taken into account!

⇨ Chapter 5.2 "Dimensions", page 30

5 Mounting

5.2 Dimensions



Distances

For sufficient ventilation, the following installation distances to adjacent resources must be adhered to:

- horizontal 35 mm
- vertical 80 mm

When inserting the device, sufficient space for maneuvering the connecting cables must be left behind the case. A Ci-conductivity sensor is connected via a M12 connector adapter. This increases the space requirement with regard to installed depth (see following dimensional drawing).

Mounting depth with Ci-conductivity sensor



5 Mounting

5.3 Panel mounting

The device is designed to be inserted in switch cabinets or machine/system walls. The insertion operation is described below.



NOTE

Insertion in a control panel provides protection class IP66. When the JUMO AQUIS touch P is inserted in the wall of control cabinets with a protection class higher than IP66, the protection class of the control cabinet lapses and corresponds to the protection class for control panel insertion (IP66).



CAUTION!

Ensure that the control panel provides adequate support for the device.
The weight values listed in the technical data must be taken into account to ensure adequate mechanical stability for control panel installation.
⇨ Chapter 23.12 "Housing", page 430



(1) Metal case barrel of the JUMO AQUIS touch P
(2) Mounting elements
(3) Seal from the scope of delivery for the device
(4) Housing front
(5) Panel/control cabinet

Procedure

Step	Action
1	Push the panel seal provided (3) from the rear panel of the device over the case barrel to the front panel.
2	Place the device in the cutout provided for this purpose in the control panel (5) as shown in the drawing.
3	Insert the mounting elements (2) into the holders on the case provided for this purpose, as shown on the drawing.
4	Screw the mounting element firmly against the panel so that the case front (4) of the device is tight against the panel (5) and the device is firmly seated.

5 Mounting

6.1 Installation notes



DANGER!
Observe the following instructions!

Qualification of personnel

- The electrical connection must only be carried out by qualified personnel.

Electrical wiring

- When selecting the electrical wiring material as well as when installing and connecting the device electrically, the requirements of DIN VDE 0100 "Erection of low voltage installations" and the applicable country-specific regulations (e.g. based on IEC 60364) need to be observed.
- The input, output, and power supply lines must be separated from one another spatially and not laid in parallel.
- Select suitable cables for sensors and interfaces (shielded and twisted or coaxial cable). These lines must not be installed near live electrical components or current-carrying wiring.
- Route sensor lines and bus lines only as uninterrupted lines (not connected via terminal blocks or the like).
- Provide shielding in accordance with the connection diagram on the device.
- At maximum load, the lines must be heat resistant up to at least 80 °C.
- In a star wiring configuration, grounding wires must be connected to an equipotential grounding busbar and insulation must be intact. Keep lines as short as possible. Ensure proper potential equalization.

6 Electrical connection

Electrical safety

- Disconnect all phases of the power supplied to the device (power grid, outside power supply sources for relays/solid state relays etc.) If current-carrying components could be touched while work is being performed.
- Fuses for power supply circuits should be rated at no more than 10 A (slow-blow).
- To prevent destruction of device outputs in the event of an external short circuit, short-circuit currents in circuits with relay or semiconductor outputs should be limited through use of appropriate fuses.
- The device is not suitable for installation in potentially explosive areas.
- Besides incorrect installation, wrong settings on the device can adversely affect performance of the connected process. For this reason, independently operating safety devices, e.g. pressure relief valves, temperature limiters/ monitors, liquid-metering limiters and overflow prevention devices should be provided and adjustment of them restricted only to train technical personnel. Appropriate safety regulations must be observed in this connection.
- Plug-in screw terminal strips should not be unplugged until after the power has been disconnected.

References to other information

- The electromagnetic compatibility conforms to the standards and regulations cited in the technical data.
- The specifications for galvanic isolation must be taken into account during planning and electrical installation.
  ⇨ Chapter 6.3 "Galvanic isolation", page 41

6.2 Connecting cables

6.2.1 Preparing coaxial cables for pH/redox electrodes

Coaxial cable with Shield-Kon® connector[1]



Length	Part no.
1.5 m	00085154
5 m	00307298
10 m	00082649

Preparing your own coaxial cable



Remove outer sheathing from the cable > Pull back the braided shield



Remove black, semiconducting layer (see image) > Strip insulation off inside conductor > Attach Shield-Kon® connector[1] for shield

1.Shield-Kon is a registered trademark of THOMAS & BETTS INTERNATIONAL, Inc., Wilmington Del., US.



Use shrink tubing to insulate the braided shield

NOTE

The black, semiconducting layer must not touch with the inside conductor! This would short-circuit the signal from the pH electrode.

Preparing a shielded multiconductor cable



Strip the insulation off the connecting cable and pull back the shield



Attach wire ferrules to the ends of the conductors and a Shield-Kon® connector[1] for shielding

1.Shield-Kon is a registered trademark of THOMAS & BETTS INTERNATIONAL, Inc., Wilmington Del., US.



Use shrink tubing to insulate the shield and Shield-Kon® connector[1]

6.2.2 Conductor cross-sections for base unit and power supply unit

The terminals on the base unit and power supply unit are plug-in screw terminals.

Ferrule	Conductor cross section		Length to strip
	minimal	Maximum	
without ferrule			
Power supply unit voltage supply	0.2 mm²	2.5 mm²	7 mm
Power supply unit relay switching outputs	0.2 mm²	2.5 mm²	7 mm
Base unit	0.14 mm2	1.5 mm²	7 mm
Ferrule without lip			
Power supply unit voltage supply	0.25 mm²	2.5 mm²	7 mm
Power supply unit relay switching outputs	0.25 mm²	2.5 mm²	7 mm
Base unit	0.25 mm²	1.5 mm²	7 mm
with ferrule with lip			
Power supply unit voltage supply	0.25 mm²	2.5 mm²	7 mm
Power supply unit relay switching outputs	0.25 mm²	2.5 mm²	7 mm
Base unit	0.25 mm²	0.5 mm²	7 mm
Rigid			
Power supply unit voltage supply	0.2 mm²	2.5 mm²	7 mm
Power supply unit relay switching outputs	0.2 mm²	2.5 mm²	7 mm
Base unit	0.14 mm2	1.5 mm²	7 mm

1.Shield-Kon is a registered trademark of THOMAS & BETTS INTERNATIONAL, Inc., Wilmington Del., US.

6.2.3 Conductor cross-sections for optional boards

The terminals on optional boards are plug-in screw terminals.

Optional boards for	Ferrule	Conductor cross section		Length to strip
		minimal	Maximum	
Universal inputs Analog outputs Digital inputs Digital outputs PhotoMOS®[a] Logic outputs Voltage supply output	without ferrule	0.14 mm2	1.5 mm^2	7 mm
	with ferrule with lip	0.25 mm^2	0.5 mm^2	7 mm
	Ferrule without lip	0.25 mm^2	1.5 mm^2	7 mm
	Rigid	0.14 mm2	1.5 mm^2	7 mm
Analysis inputs pH/Redox/NH_3 Analysis inputs CR[b] Analysis inputs Ci[c] Digital outputs relay Digital outputs triac	without ferrule	0.2 mm^2	2.5 mm^2	7 mm
	with ferrule with lip	0.25 mm^2	1.5 mm^2	7 mm
	Ferrule without lip	0.25 mm^2	2.5 mm^2	7 mm
	Rigid	0.2 mm^2	2.5 mm^2	7 mm

[a] PhotoMOS® is a registered trademark of Panasonic.
[b] CR analysis inputs = Analysis inputs for resistive conductivity
[c] Analysis inputs Ci = Analysis inputs for inductive conductivity

6.3 Galvanic isolation



Note!
If sensors that are not electrically isolated are connected to a digital input and supplied by an external power source, potential differences between the internal and external ground can cause problems. Thus, it is preferable to take power from the power outputs of the JUMO AQUIS touch P.

6 Electrical connection

6.4 Connection diagram

6.4.1 Overview of connections



	Module	Connector terminal	Type
Inputs	Base unit	PWR IN	Voltage supply for the device
		IN 1 to IN 3	Digital inputs
		IN 4 to IN 5	Temperature inputs
		IN 6	Universal input
	Option-al boards	IN 7 to IN 8	analysis inputs
	–	IN 9 to IN 10	Not available[a]
	Option-al boards	IN 11 to IN 12	Universal inputs
		IN 13 to IN 18	Digital inputs

Outputs	Power supply unit	OUT 1 to 2	Digital outputs (relay changeover contact)
	-	OUT 3	Not available[a]
	Base unit	OUT 4	Analog output
	–	OUT 5	Not available[a]
	Option-al boards	OUT 6 to OUT 13	Analog/digital outputs, OUT 8/9 also for voltage supply output DC ±5 V, 24 V
Interfaces	Base unit	COM 1	RS-485
		USB device interface	USB device interface
		USB Host interface	USB Host interface
	Option-al boards	COM 2	Ethernet, PROFINET IO, PROFIBUS-DP or RS422/485

[a] Available only on the AQUIS touch S

6 Electrical connection

6.4.2 Analog inputs base unit



Connector/ terminal	Connection variant	Symbol
IN 4	RTD temperature probe 2-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	RTD temperature probe 3-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
IN 5	RTD temperature probe 2-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	RTD temperature probe 3-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	NTC 2-wire circuit	
	NTC 3-wire circuit	
	Resistance potentiometer A = Start E = End S = Slider	



Connector/ terminal	Connection variant	Symbol
IN 6	Standard signal Current 0(4) to 20 mA	+ 9 I_x - 10

6 Electrical connection

6.4.3 Analog inputs optional boards

Universal inputs



Slot	Connection variant	Symbol
IN 11 IN 12	RTD temperature probe 2-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	RTD temperature probe 3-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	Resistance potentiometer A = Start E = End S = Slider	
	Standard signal Voltage 0 to 10 V	
	Standard signal Current 0(4) to 20 mA	

pH/Redox/NH3 analysis inputs

For optional board "analysis pH/Redox/NH3", 2 versions are currently in circulation. The connection diagram contains the connection terminal layout for both version I and version II. To identify the version of your optional board, compare the connection terminal layout to the following illustrations:

I



II



I = First version
II = Revised version

6 Electrical connection



DC ±5 V:
OUT 8/9



Temperature inputs:
IN 4/5/11



Analysis inputs:
IN 7/8

Slot	Option/ connection variant	Wire (color)[a]	Potential	Terminal				Symbol
				DC ±5 V[b]	Temperature input	Analysis input pH/redox		
						I	II	
IN 7 IN 8	ISFET-pH sensor	A (blue)	DC +5 V	3				
		B (black)	GND with jumper to F	4				
		C (green)	DC -5 V	5				
		D (white/ black)	Ion-sensitive gate			1	1	
		E	Bypass			3	4	
						5	5	
		F (yellow)	Reference			6	6	
		G (white)	Compensation thermometer in 3-wire circuit		Connection[c] 			
		H (red/ black)						
		I (red)						
	The RTD temperature probe can be connected to a temperature input or universal input.[d]							

[a] The conductor colors listed refer to JUMO ISFET-pH sensors. The orange-colored conductor is not connected.

[b] The "Voltage supply output DC ±5 V, 24 V" optional board (part no.. 00592963) is needed in slot "OUT 8/9" to supply voltage to the JUMO ISFET pH sensor.

[c] The connection diagram for the selected analog input must be observed when connecting the temperature probe.

[d] When connecting the temperature probe of JUMO ISFET pH sensors to process connection 615 (NTC 8k55), no customer-specific linearization like that for the JUMO AQUIS 500 pH is needed. The IN 5 temperature input supports connection of 8k55-NTC temperature probes.



Slot	Option/connection variant	Wire (color)	Potential	Terminal			Symbol
				Temperature input	Analysis input pH/redox		
					I	II	
IN 7 IN 8	pH/redox Asymmetric connection of a combination electrode (Standard connection variant)	A (core)	Glass/metal electrode		1	1	
		B (jumper)	-		3	4	
					5	5	
		C (shield)	Reference electrode		6	6	
	For temperature compensation, a separate temperature sensor can be connected to an analog input.						

6 Electrical connection



Slot	Option/connection variant	Wire (color)	Potential	Terminal			Symbol
				Temperature input	Analysis input pH/redox		
					I	II	
IN 7 IN 8	pH/redox Asymmetric connection of a combination electrode with integrated RTD temperature probe and VarioPin terminal head	A (core)	Glass/metal electrode		1	1	
		B (inner shield)	Reference electrode		3	4	
					5	5	
		C (gray)	Pt100/1000	Connection[a] 			
		D (blue)	Not used				
		E (white)	Pt100/1000				
		F (green)	Pt100/1000				
		S (outer shield)	Shield		6	6	
	The RTD temperature probe is used to provide a temperature-compensated pH-value measurement, and can be connected to a temperature input or universal input. Terminal 2 at the analysis input is not connected!						



Slot	Option/connection variant	Wire (color)	Potential	Terminal			Symbol
				Temperature input	Analysis input pH/redox		
					I	II	
IN 7 IN 8	pH/redox Symmetric connection of a combination electrode	A (core)	Glass/metal electrode		1	1	
		B (inner shield)	Reference electrode		3	4	
		C (grounding pin, pipe or tank wall at the measuring point)	Liquid potential		5	5	
		D (outer shield)	Shield		6	6	
	Symmetric connection is used to reduce interference from stray electromagnetic fields along the sensor cable. Terminal 2 at the analysis input is not connected!						

6 Electrical connection



Slot	Option/connection variant	Wire (color)	Potential	Terminal			Symbol
				Temperature input	Analysis input pH/redox		
					I	II	
IN 7 IN 8	pH/redox Symmetric connection of a combination electrode with integrated RTD temperature probe and VarioPin terminal head	A (core)	Glass/metal electrode		1	1	
		B (inner shield)	Reference electrode		3	4	
		C (gray)	Pt100/1000	Connection[a] 			
		D (blue)	Not used				
		E (white)	Pt100/1000				
		F (green)	Pt100/1000				
		G (grounding pin, pipe or tank wall at the measuring point)	Liquid potential		5	5	
		S (outer shield)	Shield		6	6	
	Symmetric connection is used to reduce interference from stray electromagnetic fields along the sensor cable. The RTD temperature probe is used to provide a temperature-compensated pH-value measurement, and can be connected to a temperature input or universal input. Terminal 2 at the analysis input is not connected!						

[a] The connection diagram for the selected analog input must be observed when connecting the temperature probe.

6 Electrical connection

Electrolytic conductivity analysis inputs



Slot	Option/connection variant	Symbol
IN 7 IN 8	Ci optional board (inductive conductivity measurement) Connection via an M12 plug, Attach connections for compensation thermometer (2-wire cable for socket) to a suitable analog input (2-wire circuit), **The factory-installed wiring must not be changed!**	



Slot	Option/connection variant	Symbol
IN 7 IN 8	CR optional board (conductive conductivity measurement) 2-electrode system with 2-wire conductor Terminal 1 must be connected to the outer electrode on concentric conductivity sensors. A = Outer electrode (core color for JUMO types with fixed cable: White) B = Inner electrode (core color for JUMO types with fixed cable: Brown) C = Shield	
	CR optional board (conductive conductivity measurement) 2-electrode system with 4-wire conductor (Wiring to minimize the measuring error caused by line resistance) Terminal 1 must be connected to the outer electrode on concentric conductivity sensors. A/B = Outer electrode C/D = Inner electrode E = Shield	
	CR optional board (conductive conductivity measurement) 4-electrode system A = Outer electrode 1 (I hi) (core color of CR-4P cable for JUMO types: Red) B = Inner electrode 1 (U hi) (core color of CR-4P cable for JUMO types: Gray) C = Inner electrode 2 (U lo) (core color of CR-4P cable for JUMO types: Pink) D = Outer electrode 2 (I lo) (core color of CR-4P cable for JUMO types: Blue) E = Shield	

6.4.4 Analog outputs

Base unit



Connector/ terminal	Connection variant	Symbol
OUT 4	Analog output DC 0 to 10 V or DC 0(4) to 20 mA (configurable)	+ U_x / I_x - → 3, 4

Optional boards



Slot	Option/connection variant	Symbol
OUT 6/7 OUT 8/9 OUT 10/11 OUT 12/13	Analog output DC 0 to 10 V or DC 0(4) to 20 mA (configurable)	+ U_x / I_x - → 1, 2

6.4.5 Binary inputs

Base unit



Connector/ terminal	Connection variant	Wire	Potential	Terminal				Symbol
				DC 24 V[a] OUT 8/9	IN 1	IN 2	IN 3	
IN 1 to 3	Digital input (potential-free contact)	A	Potential-free contact		1	3	1	
		B			2	4	2	
	In the digital input configuration, the "Contact" option must be set to "Potential-free contact".							
	Digital input (external voltage source)	A	Logic signal +		1	3	1	
		B	Logic signal -		2	4	2	
	In the digital input configuration, the "Contact" option must be set to "Ext. voltage supply".							
	Digital input (NPN transistor switching output)[b]	A	Switching signal (collector)		1	3	1	
		B	Sensor -		2	4	2	
		C	Sensor +	1				
		D	Sensor -	2				
	In the digital input configuration, the "Contact" option must be set to "Potential-free contact".							
IN 1 to 3	Digital input (PNP transistor switching output)[b]	A	Switching signal (collector)		1	3	1	
		B	Sensor -		2	4	2	
		C	Sensor +	1				
		D	Sensor -	2				
	In the digital input configuration, the "Contact" option must be set to "Ext. voltage supply".							

[a] To provide power to the sensors at DC 24 V, the optional board for power supply voltage (Part No. 00592963)
must be installed in the device.

[b] The connection variants for transistor switching outputs (NPN / PNP) are especially important for the flow measurement via impeller sensor (type 406020, part no. 00525530, 00525531) at inputs IN 2 and IN 3 (pulse frequency inputs). However, other sensors with transistor switching output can also be connected.

Optional boards



Connector/ terminal	Connection variant	Symbol
IN 13/14/15 IN 16/17/18	3× binary input (potential-free contact)	

6.4.6 Digital outputs, power supply unit board



Connector/ terminal	Connection variant	Symbol
OUT 1 OUT 2	Relay Changeover contact	

6 Electrical connection

6.4.7 Digital outputs, optional boards



Slot	Option/connection variant	Symbol
OUT 6/7 OUT 8/9 OUT 10/11 OUT 12/13	Relay Changeover contact	
	2× relay Normally open contact	
	Solid state relay triac 230 V/1 A	
	2× solid state relay PhotoMOS®[a]	
	Digital output 0/22 V	
	2× binary output 0/12 V	

[a] PhotoMOS® is a registered trademark of Panasonic.

WARNING!
Combining a mains voltage circuit with a protective low-voltage circuit on the option "dual normally open contacts" is not permissible.

6.4.8 Mains power connection



Connector/ terminal	Connection variant	Symbol
PWR IN	Mains power input	L1 — L1 N — N PE — PE

6.4.9 Voltage supply outputs

Optional board



Slot	Connection variant	Symbol
OUT 8/9	Voltage supply DC 24 V for external transmitters 24 V	+ 1 $U_=$ - 2
	DC ±5 V voltage supply (e.g. for ISFET sensors or JUMO digiLine)	+ 3 $U_=$ ⊥ 4 - 5

6.4.10 Interfaces for data and bus communication

NOTE

When installing the bus cabling for digital sensors, heed the information regarding line length and number of sensors in the Annex.

⇨ Chapter 24.2 "Planning the cabling for digital sensors", page 441

Interfaces for data and bus communication - Base unit



Connector/ terminal	Connection variant	Wire (color)	Potential	Terminal			Symbol
				OUT 8/9[a]		COM 1	
				DC ±5 V	DC 24 V		
COM 1	RS-485	RxD/TxD+	RxD/TxD+	-	-	1	RxD/TxD+
		RxD/TxD-	RxD/TxD-	-	-	2	RxD/TxD-



Connector/ terminal	Connection variant	Wire (color)	Potential	Terminal			Symbol
				OUT 8/9[a]		COM 1	
				DC ±5 V	DC 24 V		
COM 1	Digital sensors (Connection to the JUMO M12 master connecting cable)	A (gray)	RxD/TxD+	-	-	1	
		B (black)	RxD/TxD-	-	-	2	
		C (brown)	+5 V	3	-	-	
		D (blue)	GND	4	-	-	
		E (blue)	GND	-	2	-	
		F (white)	+24 V	-	1	-	
		G(black with cable lug for connecting to the grounding)	Shield	Connection screw on the rear sheet metal wall of the device			
	For connection of a JUMO digiLine bus line to operate digital sensors, JUMO offers 5-wire M12 digiLine Master connecting cable. A total of up to 6 digital sensors (JUMO ecoLine/tecLine or sensors with JUMO digiLine electronics) can be operated over a JUMO digiLine bus. The voltage supplies of DC 5 V and DC 24 V for the sensors on the bus are provided by the voltage supply outputs on the device (optional board)[b]. ⇨ Chapter 6.4.9 "Voltage supply outputs", page 62						

[a] To provide power to the digital sensors, the optional board for power supply voltage (Part No. 00592963) must be installed in the device.

[b] If appropriate, use a JUMO digiLine hub bus distributor for digital sensors (PG 203590). ⇨ Chapter 24.2 "Planning the cabling for digital sensors", page 441



USB device	USB device Type Mini-B (socket)	
USB host	USB host Type A (socket)	

6 Electrical connection

Interfaces for data and bus communication - Optional boards



Slot	Option/connection variant	Wire/pin (color)	Potential	Terminal			Symbol
				OUT 8/9[a]		COM 2	
				DC ±5 V	DC 24 V		
COM 2	RS422 terminating resistors with DIP switches on optional board configurable	RxD+	RxD+	-	-	1	
		RxD-	RxD-	-	-	2	
		TxD+	TxD+	-	-	3	
		TxD-	TxD-	-	-	4	
	RS485 terminating resistors with DIP switches on optional board configurable	RxD/TxD+	RxD/TxD+	-	-	3	
		RxD/TxD-	RxD/TxD-	-	-	4	



Slot	Option/connection variant	Wire/pin (color)	Potential	Terminal			Symbol
				OUT 8/9[a]		COM 2	
				DC ±5 V	DC 24 V		
COM 2	Digital sensors Connection to optional board: RS422/485 serial interface with JUMO M12 master connecting cable	A (gray)	RxD/TxD+	-	-	3	
		B (black)	RxD/TxD-	-	-	4	
		C (brown)	+5 V	3	-	-	
		D (blue)	GND	4	-	-	
		E (blue)	GND	-	2	-	
		F (white)	+24 V	-	1	-	
		G(black with cable lug for connecting to the grounding)	Shield	Connection screw on the rear sheet metal wall of the device			
	For connection of a JUMO digiLine bus line, JUMO offers 5-wire M12 digiLine master connecting cable. Up to 6 digital sensors (JUMO ecoLine/tecLine or sensors with JUMO digiLine electronics) can be operated over a JUMO digiLine bus. The voltage supplies of DC 5 V and DC 24 V for the sensors on the bus are provided by the voltage supply outputs on the device (optional board)[b]. ⇨ Chapter 6.4.9 "Voltage supply outputs", page 62						
	Located on the front of the serial interface RS422/485 optional board are DIP switches for setting the terminating resistors: with terminating resistors  without terminating resistors 						



Slot	Option/connection variant	Wire/pin (color)	Potential	Terminal			Symbol
				OUT 8/9[a]		COM 2	
				DC ±5 V	DC 24 V		
COM 2	PROFIBUS-DP 3 = RxD/TxD-P 5 = DGND 6 = VP 8 = RxD/TxD-N	3	RxD/TxD-P	-	-	-	
		5	DGND	-	-	-	
		6	VP	-	-	-	
		8	RxD/TxD-N	-	-	-	
	Ethernet Type RJ 45 (socket)	-	-	-	-	-	
	PROFINET IO 2 switch ports RJ-45 (sockets)	--	-	-	-	-	

[a] To provide power to the digital sensors, the optional board for power supply voltage (Part No. 00592963) must be installed in the device.

[b] If appropriate, use a JUMO digiLine hub bus distributor for digital sensors (PG 203590). ⇨ Chapter 24.2 "Planning the cabling for digital sensors", page 441

NOTE

Only 1 serial interface per device can be used for JUMO digiLine (⇨ Chapter 10.21 "Serial interfaces", page 218).
A maximum of 6 sensors can be connected to the selected interface.

6 Electrical connection



WARNING!

Prior to startup, ensure that the device has been installed and connected properly and
in compliance with the installation instructions. Observe the safety instructions in this description.
⇨ Chapter 1 "Safety information", page 15



CAUTION!

A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!



CAUTION!

The touchscreen must not be operated with sharp or pointed objects, as these could damage the protective film and the touchscreen.

7.1 Initial startup

Step	Action
1	Switch on the supply voltage to the device and wait until it has booted up.
2	Select the operating language.
3	Log in as user "Master" or "Service" in order to have access to the configuration in the device menu. ⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
4	Set the date and time. ⇨ Chapter 9.1 "Date and time", page 131
5	Make the basic settings for the device. ⇨ Chapter 10.2 "Basic settings", page 138
6	Configure the analog and digital inputs you wish to use. ⇨ Chapter 10.5 "Analog inputs", page 143 ⇨ Chapter 10.7 "Digital inputs of base unit and optional boards", page 158
7	Check the hardware functions of the device. ⇨ Chapter 7.3 "Function test", page 77
8	Calibrate the analysis sensors connected to the device if necessary. ⇨ Chapter 12 "Calibration in general", page 235
9	The device is now ready for use. You can configure the displays and functions of the device according to your needs.

⇨ ⇨

7 Startup

7.2 Digital sensors

NOTE

For operation of digital sensors, you need the extra code "JUMO digiLine protocol activated“ (⇨ Chapter 4.2 "Order details", page 24)

7.2.1 Initial startup

Sensors with JUMO digiLine electronics

NOTE

Only one serial interface of the device can be configured for operation of digital sensors. If your device has 2 serial interfaces (base unit and possibly an optional board), select 1 interface for connection of digital sensors and set its protocol to "Modbus digital sensors".

Thanks to plug & play, startup of sensors with JUMO digiLine electronics is very simple. As soon as a JUMO sensor with digiLine electronics is connected to the bus, the JUMO AQUIS touch P detects and links it to an available (not yet linked) and suitably configured input for digital sensors. The status of the link can be checked in the assignment table. If, prior to connection of the sensor, no input for digital sensors was configured with a suitable sensor type, this can also be done after connection of the sensor. Automatic linking of the sensor to the input for digital sensor occurs here as well. If several sensors of the same kind need to be put into operation, they must be put into operation individually in succession or the link must be established manually in the device menu.
For a sensor to be linked automatically to an input for digital sensors, the following conditions must be met:

- An available (unlinked) input for digital sensors must be configured for the sensor type of the sensor being connected. This can be checked by viewing the assignment table. All configured inputs for digital sensors are listed there with configuration information and link status.
- The sensor type listed for the configured input for digital sensors must match the type of sensor being connected.
- If "TAG check" is activated in the configuration of linkable inputs for digital sensors, the "Sensor TAG" must match the "TAG number" in the JUMO digiLine electronics of the sensor.

Viewing the assignment table:
⇨ Chapter 8.2.7 "Digital sensors", page 99
Manual linking:
⇨ Chapter "**Procedure for manual linking of digital sensors**", page 102
Configuring the inputs for digital sensors:
⇨ Chapter 8.2.7 "Digital sensors", page 99

The following table describes the startup procedure for an individual JUMO sensor with JUMO digiLine electronics.

Step	Action
1	Log in as user "Master" or "Service" in order to have access to the configuration in the device menu. ⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
2	Ensure that the serial interface being used for operation of digital sensors is configured correctly. The protocol must be set to "Modbus digital sensors".
3	Open the configuration of the digital sensors, select an available output for digital sensors and enter the type information for the sensor being connected. Open the configuration of the digital sensors: Device Menu > Configuration > Digital Sensors 1 to 6 > General
4	Open the assignment table for the digital sensors and check whether an entry exists for the input for digital sensors that was just configured. The line number must match the number of the input for digital sensors and the assignment table entry must show the status "Installation". The status is visualized by symbols in the right column of the assignment table. Open the assignment table: Device Menu > Digital Sensors ⇨ Chapter 8.2.7 "Digital sensors", page 99
5	Connect the sensor with JUMO digiLine electronics to the bus.
6	Check whether the assignment table entry has changed from "Installation" to "linked". If this is not the case after a waiting period of about 10 seconds, linking has failed. In case of an error, check the correctness of the configuration and bus cabling (⇨ Chapter 24.1 "Troubleshooting and remedies for digital sensors", page 435). For diagnosis, it is helpful to display more information about the assignment table entry. To display the information, press the "Info" button. This opens a text window in which, among other things, the most recent bus fault is displayed. ⇨ Chapter 8.2.7 "Digital sensors", page 99

Digital JUMO ecoLine and tecLine sensors

NOTE
Only one serial interface of the device can be configured for operation of digital sensors. If your device has 2 serial interfaces (base unit and possibly an optional board), select 1 interface for connection of digital sensors and set its protocol to "Modbus digital sensors" and the baud rate to "9600".

Digital JUMO ecoLine and tecLine sensors can communicate with the JUMO AQUIS touch P over the JUMO digiLine bus just like sensors with JUMO digiLine electronics. However, they do not support plug & play and must be put into operation in another way. The following table describes the startup procedure for an individual digital JUMO ecoLine or tecLine sensor.

Step	Action
1	Log in as user "Master" or "Service" in order to have access to the configuration in the device menu. ⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
2	Ensure that the serial interface being used for operation of digital sensors is configured correctly. The required settings are: **Protocol:** Modbus digital sensors **Baud rate:** • JUMO ecoLine: 9600 • JUMO tecLine: 9600, 19200 or 38400 (automatic) **Data format:** 8 - 1 - no parity
3	In the configuration, select an available input for digital sensors and enter the type information in the "General" folder of the sensor being connected. Open the menu: Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > General ⇨ Chapter 7.2 "Digital sensors", page 72
4	Open the assignment table for digital sensors in the device menu. Open the assignment table: Device Menu > Digital Sensors ⇨ Chapter 8.2.7 "Digital sensors", page 99
5	Localize the entry whose number (1 to 6) matches that selected in step 1 and in the configured input for digital sensors.

Step	Action
6	Check whether this entry has the status "Installation". If this is not the case, check the configuration of the selected input for digital sensors. Example of view showing the status of assignment table entries:  ⇨ Chapter 8.2.7 "Digital sensors", page 99
7	Connect the sensor to the JUMO digiLine bus.
8	Highlight the prepared assignment table entry (status "Installation") by tapping it.
9	Open the "Link" submenu and highlight the assignment table entry that was just created by tapping it.  ⇨ Chapter 8.2.7 "Digital sensors", page 99
10	Using the "Scan Button", start a sensor scan and wait until the sensors scan is completed. If the sensor was detected, it will appear in the list of this menu with its status.  ⇨ Chapter 8.2.7 "Digital sensors", page 99
11	Leave the "Link" submenu by pressing the "Exit" button. This takes you back to the display of the assignment table.

Step	Action
12	Check whether the assignment table entry has changed from "Installation" to "linked". If this is not the case after a waiting period of about 10 seconds, linking has failed. In case of an error, check the correctness of the configuration and bus cabling (⇨ Chapter 24.1 "Troubleshooting and remedies for digital sensors", page 435). For diagnosis, it is helpful to display more information about the assignment table entry. To display the information, press the "Info" button. This opens a text window in which, among other things, the most recent bus fault is displayed. ⇨ Chapter 8.2.7 "Digital sensors", page 99

7.2.2 Restarting

Sensors with JUMO digiLine electronics

A JUMO digiLine electronics assembly that was disconnected from the bus for maintenance and repair is detected again automatically upon reconnection, linked to its original assignment table entry and resumes operation.
When replacing JUMO digiLine electronics assemblies, each electronics assembly must be replaced individually before the next one is disconnected from the bus. In this way, each new JUMO digiLine electronics assembly is linked automatically with the original assignment table entry.

JUMO ecoLine and JUMO tecLine sensors

A digital **JUMO ecoLine or JUMO tecLine sensor** that was disconnected from the bus for maintenance and repair is detected again automatically upon reconnection, linked to its original assignment table entry and resumes operation.
When replacing digital **JUMO ecoLine or JUMO tecLine sensors**, it is necessary to follow the initial startup procedure to put the new digital sensors into operation (⇨ Chapter 7.2.1 "Initial startup", page 72).

7.3 Function test

Important hardware information is displayed in the "Device Info" menu.
The functionality of the device can be checked from here.

7.3.1 Checking the optional boards

Open the hardware information for the installed optional boards as follows:
Device Menu > Device Info > Slots
A tab with hardware and software information for each correctly installed optional board now appears.

Sample screen: Hardware Information for an optional board "Universal input"



If no tab appears for an optional board, the board was not recognized and there is a hardware problem. In such cases, check whether the optional board concerned was installed correctly.

⇨ Chapter 11.1 "Installing optional boards", page 227
If this is not successful, contact Technical Support at JUMO.
The contact data can be found on the back of these installation instructions.

7.3.2 Checking sensors and inputs/outputs

To check correct operation of all inputs/outputs, you can display the current analog and binary values.

Device Menu > Device Info > Inputs/Outputs

Depending on the type of input, up to 2 columns will be visible in the Device Info screens for inputs.

- **Compensated:** Display value that is calculated from the value measured by the sensor through use of an appropriate compensation method and after taking the corresponding calibration values into account.
  This suppresses incorrect measured values that can be caused by outside factors (e.g. temperature) or sensor wear (e.g. a dirty electrode).
- **Uncompensated:** Value measured by sensor (raw value of the measurement input, e.g. pH measuring chain voltage)

These sensor values are subject to distortion caused by outside factors. Display of uncompensated values is used primarily for diagnostic purposes. The compensated values are used for the actual measurement of analysis variables.

The following example considers analysis inputs in the form of a conductivity measurement input and a pH measurement input.
The device calculates the (compensated) values of the process variable from the (uncompensated) raw measurement data.

Sample screen:
IN 7 measures conductivity
IN 8 measures pH value

IN 9 to 10 are available only



8.1 Operating concept

This chapter explains how to use the functions at the operating level (e.g. controller and data monitor) and access the menu structure for editing device settings. The JUMO AQUIS touch P is operated by means of the touchscreen, using either a finger or stylus with a soft, rounded plastic tip.



CAUTION!

The touchscreen must not be operated with sharp or pointed objects, as these could damage the protective film and the touchscreen.



CAUTION!

Use only a soft cloth to clean the touchscreen. Commercially available cleaners may contain substances that damage the protective film and the display.



NOTE

Operation depends on the user's rights. Operating and setting options are restricted, depending on the user who is logged in.

The "Master" and "Service" users have access to all menus and functions (default setting).

⇨ Chapter 8.1.1 "Passwords and user rights", page 79

8.1.1 Passwords and user rights

The device has 4 users with factory-configured user names, passwords, and user rights. The passwords can be changed in the device.

⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

The JUMO PC setup program is needed to change user names and user rights.

⇨ Chapter 22.8.3 "User list", page 363

The following table provides an overview of the factory-set user accounts.

Factory-set passwords

Users	Everyone	User 2	User 1	Service	Master
Factory-set password	-	20	110	3000	9200

Factory-set user rights

Users / User rights	Every-one	User 2	User 1	Service	Master
Display of: • Current measuring values on overview and detailed screens • Configuration data • parameters • Device info	X	X	X	X	X
Display of: • History of measurement data in the record-ing function • Event and alarm list • Service data **User actions** • Acknowledge alarms • Calibration • Read out history of measurement data in the recording function • Display and change user level parameters • Read out service data • Link digital sensors manually		X	X	X	X
User actions • Operate control functions **Change settings** • Changing the settings at the perimeter level • Set date and time **Configuration** • Initialize calibration			X	X	X
Configuration • Configuration of all functions • Activate extra codes				X	X

8.1.2 Display and control elements



(1) Title bar

(2) Touchscreen

(3) Toolbar with buttons for operation

(4) "Device menu" button with display of:

- Date and time
- Logged-in user
  ("Master" in the example)
- Remaining memory display in percent for recording function
  (in the example: 100 %)

(5) "Alarm/Event List" button

(6) "Select operator screen" button (direct selection of the desired operation screen)

(7) "Home" button (back to main screen)

(8) Placeholder for context-sensitive buttons
Assignment depends on the particular operator screen.
Specific buttons are shown in the placeholders on the operation screens for the controller and recording functions.

(9) "Next operation screen" button (for scrolling through operator screens)

8.1.3 Menu structure

At the **operating level,** 3 different navigation buttons are available to select appropriate screens for display and control of device functions.
The **"Device menu"** and **"Alarm/event list"** menu levels are also displayed by means of corresponding buttons. The device menu contains submenus for setting, servicing, and diagnosing the device and its functions.
The **memory manager** opens automatically as soon as a USB flash drive is inserted into the USB host interface. It exchanges data between the device and the flash drive.

Overview of the menu structure





NOTE

The "Recorder Update to USB" and "Recorder Backup to USB" items appear in the "Memory Manager" menu only if the extra "Recording function" is enabled.

⇨ Chapter 4.2 "Order details", page 24

Operation screens in the operation loop in the example



Figure	Operator screen	Description
(1)	General screen 1	User configurable overview display of measuring values and digital signal states The overviews can be configured as a 2-part screen or a 4-part screen. **2-part screen:** Display of 2 primary and 2 secondary measured values per screen, 1 additional measured value and 3 binary values. **4-part screen:** Display of 4 primary and 4 secondary measured values per screen, 1 additional measured value and 3 binary values.
(2)	General screen 2	

Figure	Operator screen	Description
(3)	Detailed screen 1	User configurable large-section screen Display of 1 main measuring value, 1 second measuring value, 1 additional value and up to 3 binary values, as well as additional visualization of the main measuring value and the alarm limits for an analog input with a bar graph
(4)	Detailed screen 2	
(5)	Detailed screen 3	
(6)	Detailed screen 4	
(7)	Detailed screen 5	
(8)	Detailed screen 6	
(9)	Diagram group 1	Up to 4 analog measured values and 3 binary functions can be displayed on a configurable recorder screen (group). Up to 4 groups can be set up. Diagrams of disabled groups are not available in the operation loop (here in the figure this applies to groups 3 and 4).
(10)	Diagram group 2	
(11)	Process screens 1 to 8	User-defined visualization screen that is user configurable by means of an editor in the PC setup program ⇨ Chapter 22.8.11 "Process images", page 381 Operating Manual JUMO AQUIS touch P With the aid of static and dynamic graphic and display elements for analog and binary values, it is possible to create a screen that displays the process flow concerned in an especially vivid manner. If no process screen is configured, none is available for the operation loop.
(12)	Controller overview	The active controller channels are visualized here in an overview display. The controller overview becomes available as part of the operating loop only if at least 2 controllers are activated. The current setpoint values, actual values and output levels are displayed for all active controllers. In addition, the operating states of the controllers are displayed (manual mode, hold, self-optimization).
(13)	Controller screen Controller 1	The controllers are visualized in detail on the controller screens. The controller screens are available as part of the operation loop only for the respectively configured channels. The information displayed includes the current setpoint value, actual value and output level. The binary values of switching controller outputs are visualized. In addition, controls for setpoint value entry, manual output level control and self-optimization are available. Access to the operating functions depends on the user rights of the logged-in user.
(14)	Controller screen Controller 2	
(15)	Controller screen Controller 3	
(16)	Controller screen Controller 4	

Display of invalid values

Invalid input signals/measured values or errors in the analog input configuration are detected and shown in the measured value displays as follows:

Type of error	Display
underrange: measuring range underflow	<<<<<
overrange: measuring range overflow	>>>>>
Compensation error: An error occurred when compensating for factors affecting the measurements of the analysis. It is necessary to check the measuring circuits and settings of the compensation signals and the configuration of the analysis measurement input affected.	+++++
Invalid display value Possible errors include: **Incorrect input signal:** An analog input has an incorrect signal or an analog input was selected for which an optional board is not even present. **Errors with digital sensors:** A digital sensor does not deliver valid values because it either is not correctly linked or a scan is in progress on the JUMO digiLine bus. **Error in the formula used by the mathematics module:** The result from a formula is invalid (e.g. division by zero)	-----
Display overrun: The value to be displayed is outside the limits of -99999 to 99999.	*****

Example of display of invalid values:



8.1.4 Entry of text and numbers

Dialogs for entry of text or numbers appear automatically when the corresponding entry field is tapped.

Text entry dialog

There are 2 special features in addition to conventional entry of characters:

- **Special characters** appear for selection automatically at those buttons that contain special characters.
- **The text list** simplifies entry of frequently used character strings. A history of character strings entered is stored internally in the device. These are then available for selection in the text list and can be copied simply by tapping the line for the entry.



Number entry dialog

This dialog opens if an entry field for numerical values is tapped.
Special feature: The **"Exp" button** permits entry of an exponent as a power of ten.
Procedure:
Enter the numerical base value > Tap "Exp" > Enter the exponent > Confirm the entry



Entry dialog buttons

Explanation	Button
Confirm entry (the value entered is accepted and the dialog closed)	
Cancel entry (the value entered is discarded and the dialog closed)	
Delete 1 character	
Delete entry line completely	
Open text list (select from a history of character strings entered)	
Entry of an exponent as a power of ten	

8 Operation

8.2 Device menu

NOTE

Operation depends on the user's rights. Operating and setting options are restricted, depending on the user who is logged in.

The "Master" and "Service" users have access to all menus and functions (default setting).

⇨ Chapter 8.1.1 "Passwords and user rights", page 79

The device menu contains submenus for setting and configuring all device functions.

To open one of the submenus in the device menu, tap the corresponding entry.

The device menu is opened by tapping the "Device menu" button at the operating level.

⇨ Chapter 8.1.2 "Display and control elements", page 81

⇨ Chapter 8.1.3 "Menu structure", page 82



"Device menu" button

Device menu items	Description
Log-on/Log-out	The user logs on and out here. In addition, passwords can be changed here. ⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
Calibration	Sensor calibration can be configured and performed here. In addition, current calibration values and the calibration logbook are displayed. ⇨ Chapter 12 "Calibration in general", page 235

Device menu items	Description
User levels	User levels permit fast and simple access to a selection of up to 50 frequently needed parameters per user level from the parameter level and the configuration level. Up to 16 user levels can be set up. No user level is configured at the factory. The user level must be configured and loaded into the device with the aid of the JUMO PC setup program. The "User Levels" entry does not appear in the device menu as long as no user level is configured. ⇨ Chapter 8.2.2 "User levels", page 94
Configuration	Basic operation of the device inputs and outputs and the device functions is set here. ⇨ Chapter 10.14 "Controller", page 202
Parameterization	Setting the date/time and controller parameter sets, as well as pre-setting controller setpoint values. Fixed numerical values can be defined in the "Manual values" submenu. ⇨ Chapter 9 "Parameterization", page 131
Functional level	Manual operation of certain functions for testing and diagnostic purposes (e.g. start wash contact or reset counter) ⇨ Chapter 8.2.3 "Functional level", page 95
Device info	Information about the device hardware and software, viewing of current analog and binary values for all device functions, inputs, and outputs ⇨ Chapter 8.2.4 "Device info", page 97
Service	Displaying and reading service data for diagnostic purposes, saving and loading a default configuration, input of the calibration values from the Final Inspection Protocol of the JUMO digiLine O-DO H10/H20, input of the fine adjustment data of the JUMO flowTRANS US W02 dL ? Chapter 8.2.5 "Service", page 98
Calibrate Touchscreen	Calibration of the touchscreen to ensure the reliability and convenience of touch control ⇨ Chapter 8.2.6 "Calibrating the touchscreen", page 99
Digital sensors	Open an overview of all configured digital sensors (Assignment table), check the link status of the sensors and manually link sensors that are not linked ⇨ Chapter 8.2.7 "Digital sensors", page 99

To navigate in submenus, menu items are opened by tapping the folder icons identified with a plus sign. Open menu structures are identified with a minus sign and can be closed again by tapping the folder icon.
Currently open windows can be left either by tapping "Exit" or the "Close window" button. Data are saved automatically when an open window is closed. Settings that were changed in the submenus take effect.



(1) Close window
(2) Closed menu structure (plus sign)
(3) Open menu structure (minus sign)

8.2.1 Log-on/Log-out

To access the "Log-on/Log-out" menu, tap the "Device menu" button and then select the "Log-on/Log-out" menu item. The user can log on/off here and change passwords for the
currently configured user accounts.



An overview of the factory-configured users and their rights can be found in the "User Management" chapter.

⇨ Chapter 8.1.1 "Passwords and user rights", page 79

After the re-authentication time has elapsed, a logged-on user is logged off automatically. It is then necessary to log on again.
The re-authentication timeout does not take effect if:

- The logon/logoff dialog is open
- The memory manager is open
- During calibration of analysis sensors
- During calibration of the touchscreen

The re-authentication time is set using the JUMO PC setup program.

⇨ Chapter 22.8.3 "User list", page 363

8.2.2 User levels

A user level consists of a user-defined list of parameters and configuration settings. Up to 16 such user levels can be set up. You need the JUMO PC setup program to configure the user level.

⇨ Chapter 22.8.6 "User levels", page 374

User levels can be opened from the device menu only if they have been configured beforehand with the aid of the PC setup program. If this has not been done, there is no user level in the device menu.
Opening a user level provides easy and uncomplicated access to the selected parameters and settings. These can be edited from here. The entry dialog is opened by tapping the display field for a desired data point.

View of a user level (example)



NOTE
Changing the date/time settings and the configuration data that are relevant for recording of measurement data initiates a restart of measurement data recording by the data monitor or recording function. This is also the case if the change is made from a user level. The restart terminates the current recording of measurement data. In the case of the "Data monitor" function, the content of the screen is deleted.

8.2.3 Functional level

The functional level is used primarily for testing and diagnostic purposes. Analog and binary values of the outputs can be controlled manually here. This may be useful, for instance, for checking an individual piece of equipment in a plant. When performing maintenance and repair work, counters for operating hours, switching actions and flow rates can be reset.



WARNING!

When manually controlling equipment in a system, it is absolutely essential to take appropriate measures to prevent personal injury and property damage.

Ensure that only qualified personnel has access to the functional level. The factory settings restrict access to just "Master" and "Service" users.

Functional level menu items:

- **Flow:** Display the current flow rate, display and reset the total quantity counter
- **Washtimer:** Manually start the wash process, display the time remaining until the wash process and the current binary value
- **Analog outputs:** Read and manually control the current values of analog outputs
- **Digital outputs:** Read current binary values, manually control digital output outputs
- **Counters:** Reset the counters (operating hours and service counters)



NOTE

Manual control of analog and binary outputs is possible only if the "Enable menu. mode" option is activated for the specific output in the configuration. In general, actions at the function level can be executed only by the "Master" and "Service" users.

⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157
⇨ Chapter 10.8 "Digital outputs of base unit and optional boards", page 159
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

Manual control of analog/digital outputs

Activate the configuration setting "Enable menu mode" for the outputs you wish to control manually. "Manual mode buttons" buttons for manual control for these outputs then appear at the functional level. To adjust output values manually, proceed as follows:

Select Device Menu > Functional Level > Analog or Digital Output tab > Tap "Manual mode" button > Tap Output Display field > Entry dialog opens > Enter value > Confirm

An activated manual mode can be recognized by the green background of the particular output value display at the functional level.

View of functional level analog outputs (example)



(1) "Manual mode" button
(2) Yellow background: Manual mode off
(3) Green background: Manual mode active

Once "Manual mode" has been switched off, the output immediately returns to the value assigned in its configuration. The output display is once again yellow.

8.2.4 Device info

For testing and diagnostic purposes, the "Device info" menu provides access to extensive data about the hardware and software of the device, as well as current analog and binary values.

Device Info menu items:

- **General:** Information about the main board, device software and Ethernet configuration
- **Slots:** Equipping overview of expansion slots, display of diagnostic and version information for the installed optional boards
- **Inputs/outputs:** Overview of all analog and binary values of the inputs and outputs of the device
- **Functions:** This menu is particularly helpful when checking functions after configuration changes. It contains detailed information about all internal functions (math/logic, flow, limit value, timer, washtimer, counter, and controller) via their current status.
- **Ethernet info:** Ethernet communication statistics for diagnosis by trained personnel
- **PROFINET:** If the device is equipped with a PROFINET I/O interface, information on the status of the interface can be viewed here. More detailed information on the data displayed can be found in the PROFINET IO interface description for the device.
- **Digital sensors**: Indication of the connection status of all configured digital sensors 1 to 6 as well as all current values and version information of linked sensors

8.2.5 Service

The "Service" menu is primarily used for in-device troubleshooting and diagnostics. It is intended primarily for trained personnel. When troubleshooting together with Service, the operator can access data that the JUMO service technicians need for diagnosis.

The “Service” menu is also used to acquire the following data:

- Entering the calibration values from the Final Inspection Protocol when changing a sensor cap for the JUMO digiLine O-DO H10/H20 oxygen sensor.
- Input of the fine adjustment data for the ultrasonic flowmeter JUMO flowTRANS US W02 dL.

NOTE

The Service menu appears in the Device menu only if a user with corresponding user rights is logged in.

⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

Service Menu items

- **Default-configuration:** The operator can store the current device configuration in the device's memory. This configuration can be reloaded as the active configuration at any time. This is important, for instance, to return to the initial configuration after configuration changes made for testing purposes.



Configurations can also be saved with the PC setup program or on a USB flash drive with the aid of the Memory Manager.

⇨ Chapter 8.4 "Memory Manager (USB flash drive)", page 112

- **Debug Window:** The Debug window can be used to check the behavior of the device software in detail. Data are displayed to assist the JUMO service technicians during troubleshooting.

- **Sensor data 1 to 6:** For each digital sensor that is operating on the device, a menu with the following functions is displayed here, depending on the sensor type:
- Reset calibration data of the sensor to default settings
- Enter calibration data from the Final Inspection Protocol after changing the sensor cap (JUMO digiLine O-DO H10/H20).
- Enter fine adjustment data (JUMO flowTRANS US W02 dL).
- **Service data: Status information** that can be evaluated by JUMO service personnel for diagnostic purposes can be read here.
  In addition, the **"Service count."** and **"Internal data"** are displayed. The service counters record the number of switching operations executed by the binary outputs. The **voltage of the buffer battery** and the **board temperature** are shown in the "Internal data".



CAUTION!

A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

8.2.6 Calibrating the touchscreen

To ensure precise and reliable operation of touchscreen control, you can open the "Calibrate touchscreen" menu.
The device then prompts you tap 4 points on the touchscreen.
Simply follow the instructions on the display.

8.2.7 Digital sensors

The assignment table (list of all configured inputs for digital sensors) is displayed here. Up to 6 digital sensors can be connected and operated via the selected serial interface. The link status of the configured sensors is displayed in the form of a symbol in the right column.



Link status symbols for the assignment table entries

Status	Explanation	Symbol
linked	Communication between the sensor electronics and the JUMO AQUIS touch P has been successfully established. The sensor is operating.	
Installation	The device searches for the individual assignment table entry of a linkable sensor. A new sensor can be linked manually or automatically if the following prerequisites are met: • The sensor type must match the settings of the assignment table entry. • The sensor version must be compatible • Operation of bus communication must be assured through correct interface settings (with JUMO digiLine electronics, the interfaces are configured automatically during the scan) Known sensors are identified and assigned and linked with the known entry After successful assignment, the status changes from "Installation" to "linked" following connection of the sensor to the bus. If a sensor cannot be linked, the status remains "Installation". If the status has not changed from "Installation" to "linked" after a waiting period of about 15 seconds, linking of the sensor electronics has failed. A description of the startup procedure for digital sensors can be found in the chapter on startup. ⇨ Chapter 7.2 "Digital sensors", page 72	

In addition to the "Exit" button, this view also has "Info" and "Link" buttons. The following table explains the function of these buttons.

Explanation	Button
The "Info" button opens an overview of important information to more easily identify the individual sensor connected.	
With the "Link" button, you can access the submenu for linking sensors that are not linked. Digital **JUMO-ecoLine and JUMO-tecLine sensors** must be linked by means of this button during startup. When errors occur during the startup of digital sensors, you usually have the ability here to detect connected digital sensors by means of a bus scan and then to link the detected sensors manually. Help for problems when sensor electronics cannot be detected or linked can be found in the Annex. ⇨ Chapter 24.1 "Troubleshooting and remedies for digital sensors", page 435	

Submenu for linking

In this menu, the bus can be "scanned" for connected sensors. The sensors detected are displayed in a list. Sensors that are not detected cannot be linked here manually. In addition to the "Exit" button, this view also has "info", "Scan" and "Link" buttons. The following table explains the function of these buttons. In this menu, the bus can be "scanned" for connected sensors. Corresponding user rights are needed to access the "Link" submenu. The default settings authorize the "Master", "User 1", "User 2" and "Service" users for this.

⇨ Chapter 8.1.1 "Passwords and user rights", page 79

The following table explains the function of these buttons.

Explanation	Button
The "Info" button opens an overview of important information to more easily identify the individual sensor connected.	
Pressing the "Scan" button starts the search for sensors connected to the bus. Detected sensors are listed on conclusion of the bus scan. The digital sensors connected do not provide any measurement data for the duration of the scan. Instead of the measured values, the "Invalid display value" symbol appears in the associated measured value displays (⇨ Chapter "Display of invalid values", page 87).	
Detected sensors can be linked manually with the "Link" button in this menu. It appears in this view when one of the detected sensors in the list has been highlighted by a tapping it in this menu. The procedure is described at the end of this table. Help for problems when digital sensors cannot be detected or linked can be found in the Annex. ⇨ Chapter 24.1 "Troubleshooting and remedies for digital sensors", page 435	

Procedure for manual linking of digital sensors

Step	Action
1	In the "Digital Sensors" menu, highlight the assignment table entry to be linked.
2	Open the "Link" submenu by tapping the corresponding button in the "Digital Sensors" menu.
3	Open the "bus scan" by pressing the "Scan" button (magnifying glass).
4	In the list of detected sensors, highlight the one that you wish to link with the previously highlighted assignment table entry. Sensors with JUMO digiLine electronics can be identified by the hardware address on the nameplate of the JUMO digiLine electronics. It is also displayed in the list of detected sensors and in the sensor information ("Info" button).
5	The "Link" button now appears above the table. Press this button to link the selected assignment table entry with the sensor selected from the list of detected sensors.
6	If the link was successful, the previously selected entry now has the status "linked" in the assignment table. If the digital sensor could not be linked, an error message appears. The error message displays a table with information about the selected assignment table entry and the sensor selected from the list of detected sensors. The error message is displayed in the lower area. **Example of an error message:** No assignment table entry was selected before the "Link" submenu was opened. 

Bus status display

The operating status of the JUMO digiLine bus is visualized in the title bar. The symbols and their meanings are explained in the following table. The symbols and their meanings are explained in the following table.

Green There are no bus errors. All sensors are linked and functioning.	
Red This symbol appears in the title bar when connecting sensor electronics that have not yet been linked with the device. As soon as the sensor electronics are linked, the bus status changes from "Yellow" to "Green". In addition, the status "Red" is also displayed during a bus scan.	
Yellow The "Yellow" status appears in the title bar when digital sensors are not linked, e. g. As the result of defective components in the bus or a faulty configuration (⇨ Chapter 24.1 "Trouble-shooting and remedies for digital sensors", page 435).	

8.3 Alarm/Event list

The JUMO AQUIS touch P offers the option of configuring alarm functions and event functions in numerous functions. In addition, the electronics of the JUMO AQUIS touch S are self-monitoring and trigger corresponding preprogrammed alarms and events in case the internal device malfunctions.
Alarms and events appear in the lists in chronological order. The respective list is opened from the "Alarm/Event List" menu.
The alarm/event list is opened by tapping the "Alarm/event list" button at the operating level.

⇨ Chapter 8.1.2 "Display and control elements", page 81
⇨ Chapter 8.1.3 "Menu structure", page 82



8.3.1 Alarm list

The alarm list displays the current alarms. Alarms are cleared upon elimination of the alarm condition. Each alarm triggers a "collective alarm". The alarm list view contains buttons for viewing details about alarms and acknowledging collective and dosing alarms.
⇨ Chapter "Acknowledging collective/dosing alarms", page 107

Example: Alarm list



Alarms are visualized further by the color of the bell icon on the "Alarm/event list" button, in the "Alarm list" menu item of the "Alarm/event list" menu and in the title bar of the operation screens. The symbols used for visual signaling of alarms are listed in the following table.

Meaning	Symbol
at least 1 alarm present Details can be viewed in the "Alarm list" and in the "Event list".	
no alarms	

Visualization of alarms in the title bar can be activated in the configuration. The most recently occurring alarm then flashes red in the title bar of the operation screens.
⇨ Chapter 10.3.1 "General information", page 139

If the alarm from a measurement input disappears, the color of the respective measuring-value display changes in accordance with the color settings.
⇨ Chapter 10.3.3 "Colors", page 140

All alarms are available in the binary selector. In this way, digital outputs or other internal functions of the device can be controlled via alarms.

Acknowledging collective/dosing alarms

The **collective alarm** combines all alarms in the alarm list. It simplifies signaling of one or several active alarms with external indicating devices or to control rooms. The binary signal for the collective alarm is available in the binary selector in 2 versions:

- **Collective alarm:** Is triggered by the occurrence of any alarm and disappears only after all alarms in the alarm list have been cleared.
- **Collective alarm ack.:** Is triggered by the occurrence of any alarm and disappears when the alarm is acknowledged.

Selection of a collective alarm when configuring device functions and digital outputs:
Binary selection > Alarm and Internal Signals >
Collective Alarm/Collective Alarm Ack.

Dosing alarms are triggered by the controllers when the control deviation is greater than the "alarm tolerance". An "alarm delay" can be set for each dosing alarm. Dosing alarms and acknowledgment of them must be activated in the controller configuration. The "alarm tolerance" and "alarm delay" settings are made in the controller parameters.
⇨ Chapter 10.14.1 "Configuration of the controllers", page 202
⇨ Chapter 9.2 "Parameter Sets (Controller parameter)", page 132

Selection of a dosing alarm when configuring internal functions and digital outputs:
Binary Selection > Controller > Dosing Alarm, Controller 1 to 4

Collective and dosing alarms can be acknowledged with the "Confirm" button.

8.3.2 Event list

A number of situations that are essential for tracking and diagnostic purposes are logged in the event list. The entries are identified with corresponding icons on the basis of the type of event. In addition, events are logged with an icon in the data monitor/recording function.
Detailed information on the data monitor/recording function
⇨ Chapter 8.6 "Operation of the data monitor/recording function", page 121



The following table provides an overview of the possible entries in the event list.

Events	Symbol
Power on	
Power off	
Alarm occurred	
Alarm cleared	
• Configured event (condition occurred) • Calibration start • Timer start • Wash contact start • Controller manual mode on • Controller self-optimization started	
• Configured event (condition ended) • Calibration stop/cancel • Timer stop • Wash contact stop • Controller manual mode off • Controller self-optimization ended	
• Switch DST • No connection to an input module • Configuration change • Reset counter • Reset flow rate measurement • Confirm collective alarm • E-mail sent (with indication of the e-mail index 1 to 5) • E-mail error (with indication of the e-mail index 1 to 5[a] and error number[b])	No symbol

[a] Up to 5 event-controlled e-mail notifications can be set up in the JUMO PC setup program. The notifications are numbered consecutively with an index from 1 to 5. The index corresponds to the tab number on an e-mail template in the JUMO PC setup program. The index corresponds to the tab number on an e-mail template in the JUMO PC setup program.

[b] The meaning of each error number is listed in the following table.

Error codes in the event list when sending an e-mail via modem and Ethernet

Error number	Meaning
120	Step error in state automation
121	Invalid response length
122	No CONNECT from modem
123	FCS checksum incorrect
124	Unexpected value or response
125	Conf request not accepted
126	No conf request from opposite end
127	No CHAP request from opposite end
128	Response timeout
129	Unknown modem response
130	Unexpected OK from modem
131	Unexpected CONNECT from modem
132	Unknown frame received
133	Unexpected PROTOCOL from modem
134	Unexpected COMPRESS from modem
135	Invalid PPP packet received
136	Unexpected BUSY from modem
137	Unknown authentication protocol
138	Ignored LCP option
139	Unexpected DELAYED from modem
140	Unexpected NODIALTONE
141	Unknown PPP protocol
142	Unknown PAP code
143	Ignored IPCP option
144	Ignored IPCP code
145	Unknown CHAP code
146	IP checksum incorrect
147	Unknown IP protocol
148	Unknown ICMP type
149	Unknown LCP type
150	Received as client DNS request
151	Unknown DNS error
152	DNS response is split
153	No IP received via DNS
154	Unknown UDP port
155	TCP checksum incorrect
156	Incorrect TCP port
157	Unknown TCP-SYN option
158	TCP port not used
159	Unknown POP3 response
160	Unknown SMTP response
161	Unknown DNS name

162	No MD5 requested for CHAP
163	Authentication error
164	Canceled from opposite end
165	Error creating TCP socket
166	Error binding TCP socket
167	Error during TCP connect
168	Error sending TCP telegram
169	Error closing TCP socket
170	Error during TCP listen
171	Reset during TCP accept
172	Error during TCP accept
173	SMTP server reports syntax error
174	TCP socket is already closed
175	Incorrect frame configuration
176	Already sent from the gateway

8.4 Memory Manager (USB flash drive)



The Memory manager is used to transfer data between the JUMO AQUIS touch P and a USB flash drive. To open the memory manager, close all windows and insert the USB flash drive into the USB host interface. The memory manager will then open automatically. You require the relevant user rights for access to the menu options "USB->Configure devices and "Software update". The factory settings authorize the "Master" and "Service" users for this.

⇨ Chapter 8.1.1 "Passwords and user rights", page 79

Memory Manager menu items:

- **Safely remove hardware:** To prevent hardware damage or loss of data, it is necessary to select this menu item before removing and inserted USB flash drive. Please follow the instructions on the device's display.
- **Recorder Update -> USB:** Use this function for **regular retrieval of recorder data** and **continuous archiving** of measured-data histories.
  Measurement data that have not yet been retrieved are stored on the flash drive together with their configuration data.
  The measurement data are stored in DAT files and the configuration data in SET files. These files can be opened and evaluated with the aid of the JUMO PCA3000 evaluation software. Data that has been extracted is marked internally as retrieved and the available memory display is set to 100 %.

CAUTION!

Ensure that recorder updates are performed in a timely manner!

When the ring memory is full (display of remaining memory in device reads 0 %), measurement data in the ring memory is lost (starting with the oldest).

- **Recorder Backup -> USB:** This function is used to **back up** the recorder data to **prevent data loss**.
  All measurement data in the ring memory (also data already retrieved) are transmitted to the flash memory together with their configuration data.
  The measurement data are stored in DAT files and the configuration data in SET files. These files can be opened and evaluated with the aid of the JUMO

PCA3000 evaluation software.
In contrast to Recorder Update, there is no internal marking of recorder data and no resetting of the available memory display.

NOTE
The "Recorder Update" and "Recorder Backup" functions are available only if the extra code "Recording" is enabled.

NOTE
A measuring data recording session is closed by changing configuration data that are relevant to the data monitor or registration function (e.g. scaling or description of an analog channel). The measurement data accumulated since the beginning of the current recording session are stored in the device in a file with the extension "DAT" together with an additional file with the extension "SET". A new recording session begins as soon as the new configuration goes into effect. One DAT file and one SET file are created for each recording session when recorder data are retrieved via Update or Backup.

- **Device Config. -> USB:** The complete, current configuration of the device is transmitted to the flash drive and saved in a file with the name "KONF304.SET". If the flash drive already contains a configuration file, a security prompt appears asking whether you are sure you want to overwrite this file. Pressing the "OK" button saves the current configuration to the flash drive and overwrites the previous file.

- **USB -> Device config.:** A configuration that is saved on the flash drive is loaded into the device and activated as the current configuration. Only the currently active configuration is overwritten. The
previous default configuration is retained. If desired, the current configuration can be saved as the default configuration.
⇨ Chapter "Service Menu items", page 98



NOTE

A check of version compatibility is performed when transferring device configurations from the USB flash memory to the device. If the device setup on the USB flash drive is incompatible with the version of the device software of the destination device, the transfer is terminated. The second term of the device version number must be greater than or equal to the second term of the device version number used to create the device setup file.

Examples of combinations of version levels:

Device software version used to create the configuration = 304.**02**.xx, device software version of the destination device = 304.**02**.xx,
The versions are compatible

Device software version used to create the configuration = 304.**01**.xx, device software version of the destination device = 304.**02**.xx,
The versions are compatible

Device software version used to create the configuration = 304.**02**.xx, device software version of the destination device = 304.**01**.xx,
The versions are not compatible

- **Service data -> USB:** A data record with service-relevant information about the device is transmitted to the flash drive and saved in a file with the name "DEBUG304.SET". The information can be used by JUMO Service for diagnostic purposes.
- **Software Update:** The device software can be updated with the aid of a USB flash drive. To do so, an appropriate update file must have been saved on
the flash drive in advance; this file can be obtained from JUMO Service.



CAUTION!

It is strongly recommended that the configuration and recorder data be backed up
prior to performing a device software update.

8.5 Operating the controllers

NOTE

Since the automatic control mode is of prime importance in the case of controllers,
correct configuration of the individual controller and its parameterization (adjustment of the control response) are very important for achieving good process
value stability.
Before starting up a controller channel, ensure that all settings in the configuration and the parameterization are
correct.
⇨ Chapter 8.5 "Operating the controllers", page 115
⇨ Chapter 9.2 "Parameter Sets (Controller parameter)", page 132

NOTE

In most cases, the parameterization are made automatically with the aid of self-optimization. In exceptional cases, however, it may be necessary to determine
the controller parameters experimentally or to calculate them and then enter them into the controller's parameter sets manually.

How to operate the 4 different operating modes (automatic mode, manual mode, hold mode and self-optimization) is described in the following 4 subchapters.

8.5.1 Automatic control mode

The automatic control mode is the normal operating mode used by the controller to
maintain the actual value of a process variable at the specified setpoint. The controller evaluates the control deviation and controls the output such that the actual value of the process approaches the setpoint. Changes to the current setpoint can be made in the controller operator screen or in the "parameterization". Two setpoints are stored for each controller in the parameterization. Setpoint 1 is active by default. Setpoint 2 can be activated instead of Setpoint 1 in each controller by means of "Setpoint selection". Setpoints can also be specified by external sources and transmitted to the controllers in the JUMO AQUIS touch S via analog inputs. "Setpoint selection" and the configuration of external setpoints are set in the "Setpoint configuration".

⇨ Chapter 9.3 "Setpoint values", page 135
⇨ Chapter 10.15 "Setpoint value configuration", page 209

On the operator screen of each controller, it is possible to change the current controller setpoint value, switch to the "Manual mode" or start "Self-optimization".



(1) Display of the digital controller output signals as indicator lights

(2) "Manual entry" button for changing the current setpoint value
A change to the currently active setpoint value is transferred to the controller parameters. When external setpoint values are used, this button is hidden.

(3) Bar graph to display the current output level

(4) Start/cancel "self-optimization" button
Self-optimization is used to determine the optimal controller parameters automatically.

(5) "Manual mode" on/off button
When manual mode is activated, the output level assumes a preconfigured
value and can then be changed manually.
⇨ Chapter 8.5.2 "Controller in the manual mode", page 118

(6) Numerical display of the current output level

(7) Display of the current setpoint value

(8) Display of the current actual value

8.5.2 Controller in the manual mode

In manual mode, the user can manually control the controller outputs. The controller outputs can be controlled in two ways:

- **Entry of a numerical value:** Using the "Manual entry" button, the user can open a dialog to enter a fixed numerical value for the output.
- **Jogging mode:** Pressing and holding the arrow buttons sets the output to ±100 % or the corresponding digital controller output to "on" depending on the controller configuration. After the button is released, the output level returns to 0 % or the corresponding digital controller output level back to "off". This function is used to operate actuators (e.g. solenoid valves, dosing pumps or motorized positioners) manually. To protect the actuators, the output does not change abruptly when the button is pressed, but rather in a continuous manner.

It is also possible to specify a manual output level in the configuration in order to ensure that a "safety output level" is generated when changing to the manual mode.
The manual output level is preset in the controller configuration.
⇨ Chapter 10.14 "Controller", page 202



(1) Display of the digital controller output signals as indicator lights
(2) Display of active manual mode
(3) "Manual entry" button for entering the manual output level
(4) "Jogging mode" button for manual control of the output level and the controller outputs
(5) "Manual mode" on/off button
(6) Bar graph to display the current output level
(7) Numerical display of the current output level

8.5.3 Hold mode

The hold mode of a controller is activated in two ways:

- Calibration of the actual-value input
- Hold signal for the individual controller (specified in the controller configuration)

In the hold mode, automatic control is suspended. The controller generates the preconfigured value as output level unless acceptance of the hold output is disabled in the configuration. In this case, the output level is frozen.
Only the setpoint value can be changed in this operating mode. In the hold mode, however, the setpoint value change has no effect. The changed setpoint value takes effect only when the controller returns to the automatic control mode.
The hold mode has priority over the manual mode. If the hold mode is activated while the controller is in the manual mode, the controller changes from manual mode to hold mode and then returns to manual mode when hold mode is deactivated.
The hold output level is preset and the digital signal for activating hold mode is set in the controller configuration.
⇨ Chapter 10.14 "Controller", page 202



(1) Display of active hold mode

(2) "Manual entry" button for changing the current setpoint. The change to the currently active setpoint is transferred to the controller parameters. However, the output remains frozen during the hold mode. When external setpoint values are used, this button is hidden.
To configure external setpoint values:
⇨ Chapter 10.15 "Setpoint value configuration", page 209

8.5.4 Optimizing controllers

The control response can be optimized by entering known controller parameters manually or automatically by means of "self-optimization". During self-optimization, the individual controller determines the mathematical parameters for a process. The controller changes the output level (step change) and evaluates the response of the actual value in the process (step response). Following successful self-optimization, the controller parameters determined in this way are adopted in the "Parameterization" function

⇨ Chapter 9.2 "Parameter Sets (Controller parameter)", page 132

WARNING!
During self-optimization, the controller outputs assume unpredictable values! Before a self-optimization starts, it must be ensured that greater deviations between the actual value and the set setpoint value do not cause property damage or physical injury.



(1) Display of active self-optimization
(2) Start/cancel "self-optimization" button
(3) Button for changing the current setpoint value
Changing the setpoint values during self-optimization is not possible.
(4) Bar graph to display the current output level
(5) Numerical display of the current output level
(6) Display of the current setpoint value
(7) Display of the current actual value

8.6 Operation of the data monitor/recording function

The standard version of the JUMO AQUIS touch P is equipped with a data monitor. It is used to record and view the analog measuring value and signal states of digital functions. Four groups are available, each of which can record up to 4 analog values and 3 binary values and display them in the form of a line recorder diagram. There is a separate diagram for each group in the operation loop. The recording function represents an Add-On to the data monitor and is available as an extra code.
⇨ Chapter 4.2 "Order details", page 24

The features of the data monitor and recording function are listed in the following table:

Function / Properties	Data monitor	Recording
Measured-data recording Recording of the measuring values from up to 4 analog channels and display of the measuring values in the form of a line recorder diagram	X	X
Digital data recording Recording of the binary values from up to 3 digital channels and display of the digital data in the form of a binary channel	X	X
Displaying events Event list entries are shown as icons in the line recorder diagram	X	X
History function For scrolling the line recorder diagram to the past to view measurement data and events from farther back in time		X
Zoom function The time range is compressed to view measured-data histories over longer periods in one area of the screen		X
Measurement data retrieval for archiving recorded measurement data and evaluating the data via JUMO PCC/PCA3000		X

8.6.1 Data monitor/recording function control elements



(1) 3-channel binary channel diagram (visualization of the recorded signal states of up to 3 binary values)

(2) "Next Channel" button for scrolling through the stylus trace views (graphical representations of a scale with a stylus) for the individual Channels 1 to 4
⇨ Chapter "Stylus trace view", page 123

(3) **Only with the recording extra code:**
"History" button for viewing all saved measurement data and events
The user must be logged in with corresponding user rights to display the "History" button.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

(4) 4-channel line recorder chart
(visualization of the recorded measurement data from up to 4 analog channels and display of events as icons)

(5) Diagram header: Field for displaying the numerical value of the current measured values of the analog channels 1 to 4

Stylus trace view

The "Next channel" button is used to scroll through the individual stylus trace views. For the particular channel selected, the appropriate scale with stylus trace appears in the stylus trace view. The position of the stylus corresponds to the current measured value of the channel.



(1) Stylus
The position on the scale corresponds to the current measuring value of the channel.

(2) "Next Channel" button for scrolling through the stylus trace views (graphical representations of a scale with a stylus) for the individual channels 1 to 4

(3) Scale
The beginning and end of the scale correspond to the "display range" in the configuration of the source of the analog value (e. g. analog input or mathematical formula).

Scrolling through the stylus trace views

The sequence of views that appear with repeated tapping of the "Next Channel" button can be seen in the graphic below.



8.6.2 History function

The history function is available only in the recording function. It permits the user to view all recorded data in the ring memory on the device's display. The history is opened by tapping the "History" button on the operator screen for the respective group. The scroll and zoom functions can be used to put the view in the desired form.

- **Scroll:** The diagram can be scrolled forward and backward with the aid of the "Scroll" buttons.
- **Zoom:** The time range in the display can be compressed with the aid of the "Zoom" button. This permits viewing of measurement curves over a longer period of time in a single area of the screen.

The "Exit" button is used to leave the history view; the display then returns to the operator screen for the corresponding group.



(1) Title bar with indication of the cursor position (time and date), Zoom factor and memory cycle time

(2) "Exit" button for leaving the history view

(3) "Zoom" button for compressing the time range in the area of the screen

(4) "Scroll" buttons for scrolling forward and backward in the History

(5) Cursor

8.7 Online visualization

Using a web browser, all operation screens of the operation loop, the alarm/event list, the measurement data history of the recording function and the calibration logbooks can be opened and viewed online. This requires the "Standard online visualization" to set as online visualization in the basic settings.
⇨ Chapter 10.2 "Basic settings", page 138
A PC with Microsoft® Windows® operating system and Microsoft® Silverlight® installed is required to use this function. Microsoft® Silverlight® is supported only by Microsoft® Internet Explorer®. Thus, Microsoft® Internet Explorer® is required to display the online visualization.

Actions involving the device functions (e.g. setpoint value entry or operating a controller manually) are not possible from a web browser and must take place directly on the device. Device settings can be made only on the device itself or via the JUMO PC setup program. In the online visualization, the "Device menu" button opens only the calibration logbook. In the recording function, the measured-data history can be opened.

Detailed information on the above-mentioned views:
⇨ Chapter "Operation screens in the operation loop in the example", page 85
⇨ Chapter 8.3 "Alarm/Event list", page 104
⇨ Chapter 12.3 "Calibration logbook", page 237

The online visualization can be opened by up to 5 clients simultaneously.



NOTE

The web server can also be configured and activated as an alternative to online the visualization. When a web server is active, the website of the web server is displayed in the web browser instead of the online visualization.

The website is opened in exactly the same manner as the online visualization, i.e. by entering the IP address or the URL of the device. Up to 5 clients have simultaneous access. The user needs the web server password to open the website.

Operation of the web server visualization depends on the specific layout of the website stored in the device.
⇨ Chapter 22.8.13 "Web server", page 402

The online visualization is open with a web browser.
Enter either the IP address or the URL of the JUMO AQUIS touch P in the address bar of your web browser.
⇨ Chapter 10.20 "Ethernet", page 217

When the website opens, it is possible to select between "Visualization" and " Quad View".

The visualization displays a view identical in appearance to the device. A request for a password appears next. The web server password specified in the web server configuration must be entered here.
⇨ Chapter 22.8.13 "Web server", page 402

As on the device, an operator screen can now be selected from the operation loop.
⇨ Chapter "Operation screens in the operation loop in the example", page 85

Access to the device menu remains blocked. Only the calibration logbooks are displayed when the "Device menu" button is pressed.
⇨ Chapter 12.3 "Calibration logbook", page 237



313.01.01-022

Quad View enables the user to open 4 different and independent views of the device. The open Quad View displays 4 plus signs for this purpose. Clicking on any one opens a request to enter the IP address of the JUMO AQUIS touch P. After the IP address has been entered, the selected view opens and can be controlled exactly as in the "Visualization" view.
Clicking on the minus sign at the upper left above one of the four views resets the Quad View.



[+] [+]

Example of a Quad View:





313.01.01-022



313.01.01-022



313.01.01-022



313.01.01-022

8 Operation

Control variables (parameters) for the device's functions are set here.
These include:

- Date and time
- Controller parameters (two parameter sets per controller)
- Controller setpoint values (two setpoint values per controller)
- manual values (for storing fixed numerical values, e.g. altered equipment data or conversion factors)

9.1 Date and time

The following table explains the parameters for setting the date and time. "Date and time" parameter list

Parameter	Selection/ Value range	Explanation
Current date/time	Date/time entry dialog	Setting the current date and time
Time zone GMT	-720 to +720 min	Difference between local time and GMT
Switch daylight saving time	inactive, automatic	activate/deactivate daylight saving time automatically
Start DST		
• Switch time Month	January to December	Month for switch to daylight saving time
• Switch time Weekday	Monday to Sunday	Weekday for switch to daylight saving time
• Day in month	First to fourth, last	Number of the selected weekday for switch to daylight saving time in the respective month
• Switch time	hh:mm:ss	Time to switch to daylight saving time
End DST		
• Switch time Month	January to December	Month to switch to standard time
• Switch time Weekday	Monday to Sunday	Weekday to switch to standard time
• Day in month	First to fourth, last	Number of the set weekday for switch to standard time in the month concerned
• Switch time	hh:mm:ss	Time to switch to standard time



NOTE

The date and time are set in the online parameters in the JUMO PC setup program.

⇨ Chapter 22.10.1 "Date and time", page 407

9 Parameterization

9.2 Parameter Sets (Controller parameter)

The parameters for the controller channels determine the control response of the individual control circuits. For stable control response, these parameters must be matched to the prevailing process conditions. Each controller channel has two parameter sets; the selection is made by means of a digital signal. "Parameter set 1" is active by default. The second set can be activated as an alternative via the digital signal. In this way, it is possible to match each control channel to the changing process conditions to maintain a stable control response.
The best parameter settings can usually be found by the controllers' self-optimization function. This approach, however, works only with linear processes.
⇨ Chapter 8.5 "Operating the controllers", page 115

For non-linear processes (control paths), it is advisable to set the parameters manually.

The following table provides an overview of the parameter sets for the controller channels. Depending on the configuration of the particular controller channel, only valid parameters are active for entry. Those not used appear in light gray, but cannot be edited. Duplicate parameters refer to the first and second controller output.

Open: Device menu > Parameterization > Parameter sets >
Controller 1 to 4 >Parameter set 1 and 2

Parameter (Formula sym.)	Possible settings	Explanation
Proportional band 1 (X_{p1})	0 to 9999.9 (Unit dependent on the actual value input variable) factory setting: 0.0	Spa of control deviation (actual value - setpoint value) in which the output level is proportional to the control deviation. The smaller the proportional band selected, the larger is the output level change with the control deviation. If the proportional band is set to a value of 0, the controller functions automatically as a limit monitor without a PID controller structure.
Proportional band 2 (X_{p2})		
Derivation time 1 (T_{v1})	0 to 9999 s customer: 80.0 s	Affects the derivative component (D-term) of the controller output signal. The purpose of the D-term is to damp the change of the actual value with time, and thereby suppress the hunting tendency. The effect of the D-term increases as the derivation time increases
Rate time 2 (T_{v2})		
Reset time 1 (T_{n1})	0 to 9999 s factory setting: 350.0 s	Affects the integral component (I-term) of the controller channel. The purpose of the I-term is to minimize the remaining control deviation. The larger the reset time the lower the effectiveness of the I component.
Reset time 2 (Tn2)		

Parameter (Formula sym.)	Possible settings	Explanation
Switching period 1 (C_{y1})	0 to 9999 s factory setting: 20.0 s	If an output of a controller channel is configured as a Pulse length output, the period between the switching pulses is fixed. The cycle time should be selected such that, on the one hand, the cyclic controller output signal (e.g. for heating, cooling, feeding etc.) does not cause any disturbing fluctuations of the actual value, while, at the same time, the switching outputs and the equipment being controlled are not stressed unduly.
Switching period 2 (C_{y2})		
Contact distance (X_{sh})	0 to 999.9 (Unit dependent on the actual value input variable) factory setting: 0.0	Minimum control deviation at which switching controller outputs become active Used to protect switching outputs and the connected equipment when controlled by modulating and continuous controllers with pulse outputs. With very small control deviations, switching of the controller output is suppressed.
Switching hysteresis 1 (X_{d1})	0 to 999.9 (Unit dependent on the actual value input variable) factory setting: 1.0	Switching distance between the output states (on/off) In switching controllers (proportional band = 0) The switching hysteresis should be selected such that the actual value resulting from the switching controller output signal does not vary too much, while, on the other hand, the switching outputs and the equipment being controlled are not stressed unduly.
Switching hysteresis 2 (X_{d2})		
Actuator runtime (TT)	5 to 3000 s factory setting: 60 s	Time required by an actuator to cover the entire output level range.
Working point (Y0)	-100 to +100% customer: 0%	constant value used to correct the controller working point The set value corresponds to the output level when the actual value and setpoint value are identical (control deviation = 0). In control structures without an I-term, serves as manual output level offset to correct remaining control deviations.
max. output level (Y1)	0 to 100% customer: 100%	maximum output level not active, limit monitor response (proportional band = 0)
Min. output level (Y2)	-100 to +100% customer: -100%	minimum output level not active, limit monitor response (proportional band = 0)

Parameter (Formula sym.)	Possible settings	Explanation
Min. relay switch-on time 1 (T_{k1})	0 to 60 s customer: 0.0 s	Depending on the Min. relay pick-up time, a lower limit is set for the pulse length or an upper limit is set for the pulse frequency. This limits the switching frequency for switching outputs.
Min. relay switch-on time 2 (T_{k2})		
max. pulse frequency 1	0 to 240 min^{-1} factory setting: 60 min^{-1}	**for continuous controllers with a pulse frequency output:** Maximum pulse frequency
max. pulse frequency 2		
Switch-on delay 1	0 to 999.9 s Customer: 0.0 s	Delay of the energizing edge with limit monitor response (proportional band = 0)
Switch-up delay 2		
Switch-off delay 1	0 to 999.9 s Customer: 0.0 s	Delay of the drop-out edge with limit monitor response (proportional band = 0)
Switch-off delay 2		
Alarm tolerance	0 to 999.9 (Unit dependent on the actual value input variable) factory setting: 0.0	maximum value of the control deviation without triggering an alarm, if this value is exceeded, the controller monitoring function triggers a "Dosing alarm"
Alarm delay	0 to 9999 s factory setting: 0 s	Delay of the dosing alarm allows violation of the alarm tolerance for a limited time.

9.3 Setpoint values

The "Setpoint values" submenu allows two setpoint values for each controller channel to be entered. As with the parameter sets, it is also possible to switch between setpoint values by means of a digital signal. "Setpoint value 1" is active by default. The second setpoint value can be activated as an alternative via the digital signal. The setpoint value that is currently active can be changed from the corresponding "controller screen".

Open: Device menu > Parameterization > Setpoint values > Setpoint value controller 1 to 4

Setpoint changeover via a digital signal is set in the Setpoint value configuration.
⇨ Chapter 10.15 "Setpoint value configuration", page 209
⇨ Chapter 8.5 "Operating the controllers", page 115

9.4 Manual values

Up to 16 constant numerical values that are available for device functions can be stored here. The "Manual values" menu provides simple and clearly organized access to stored numerical values in order to change them as necessary.

Open: Device menu > Parameterization > Manual values

For "Manual values", settings such as comma format, unit etc. must be made in the configuration.

⇨ Chapter 10.25 "Manual values (configuration)", page 222

Examples of practical use of "Manual values":

- "Mathematical formula" are used to control a process. These contain process-relevant equipment information (e.g. tank capacities). If the equipment configuration is modified, these data can be changed in the "Manual values" menu and even edited from the user level.

  ⇨ Chapter 8.2.2 "User levels", page 94

- Another application example is the storage of constant process values (e. g. the duration of a chemical reaction), the value of which is also known without a measurement. If the process conditions change (e.g. through use of a catalyst), the stored process values can be modified accordingly.

9 Parameterization

10.1 Notes



WARNING!

After every configuration change, the device restarts functions affected by the changes. Analog and digital outputs can assume undesired states during start-up.

Therefore, configuration changes must never be made while equipment is operating!



CAUTION!

Besides incorrect installation, incorrectly set values on the device can impair performance of the connected process or cause damage. Therefore, always provide safety devices independent of the device and allow only qualified personnel to make settings.



CAUTION!

When changing configuration data that are relevant for the data monitoring and recording function, data recording is terminated and a new recording session begun.



NOTE

Changes to the configuration settings described in this chapter can be made directly on the device or via the JUMO PC setup program.



NOTE

Settings in the "Configuration" menu can be changed only if a user with corresponding user rights is logged in.

⇨ Chapter 8.1.1 "Passwords and user rights", page 79



NOTE

Changes to the configuration go into effect only after you leave the configuration menu ("Exit" menu item or "Close window" button).

10 Configuration

10.2 Basic settings

Open: Device Menu > Configuration > Basic Settings

Configuration point	Selection/ setting option	Explanation
Device name	Up to 20 text characters	Device ID, e.g. for identification of exported measurement data in the JUMO PCA 3000 evaluation software
National language	German English	Setting the operating language Additional languages can be installed on the device using the setup program. ⇨Chapter 22.8.4 "Country settings", page 366
Language select after power on	Yes No	Specifies whether a prompt for selecting the operating language should appear when the device is switched on
Power frequency	50 Hz 60 Hz	Supply frequency of the electric power grid serving the mounting site The supply frequency must be specified to suppress EMC interference caused by the mains voltage. Setting the correct supply frequency is thus also necessary when supplying the device with direct voltage.
Device temp.	Degrees Celsius Degrees Fahrenheit	Setting the default on the temperature unit for all temperature values in the device
Interface temperature	Degrees Celsius Degrees Fahrenheit	Setting the default on the temperature unit for all temperature values communicated via interfaces
Memory alarm limit	0 to 100 %	If the available memory display reaches this value, the memory alarm is triggered.
The following settings can be edited only with the aid of the JUMO PC setup program		
Setup quick info	up to 20 text characters	Brief information text about setup
Setup info	Up to 501 text characters	Detailed information text about setup
Version online-visualization	No online-vis. Standard online-vis.	Selection of a saved online-visualization Online-visualization permits remote control of the operation screens via a web browser ⇨ Chapter 8.7 "Online visualization", page 126 When the webserver is active on the device, the website of the webserver is displayed in the web browser instead of the online-visualization. ⇨ Chapter 22.8.13 "Web server", page 402

10.3 Display

10.3.1 General information

Open: Device Menu > Configuration > Display > General

Configuration point	Selection/ setting option	Explanation
Lock touchscreen	Selection from binary selector	Digital signal that blocks operation of the touchscreen (e.g. key switch for locking operation)
Simulation of inputs	Yes No	When this function is activated, alternating on/off signals are simulated automatically at the binary inputs and continuous value changes at the analog inputs This function is used for troubleshooting. Deactivate it during normal operation.
Main view	Selection of an operation screen from the operation loop	Selection of the operation screen as main screen The main screen appears after the device has been switched on or the "Home" button has been pressed.
Display 1 and 2 general screen	Yes No	Individual operation screens can be shown or hidden in the operation loop here.
Show detailed screen 1 to 6		
Show diagram 1 and 2		
Show process screen 1 to 8		
Show controller overview		
Show controller 1 to 4		
Show alarms	Yes No	Activation or deactivation of alarm visualization in the title bar of the operation screens
Window change	Active Inactive	Activation of automatic scrolling through the operator screens of the operating loop.
Window change waiting period	10 to 9999 s	Period that an operator screen is displayed until continued scrolling with an active window change

10.3.2 Screen

Open: Device Menu > Configuration > Display > Screen

Configuration item	Selection/ setting option	Explanation
Activation of screen-saver	Inactive Time to switch off Control signal	Type of screensaver activation
Wait time for screen-saver	10 to 32767 s	**only with activation of the screensaver after wait time:** Time to wait before displaying the screensaver when there is no activity on the device
Signal screensaver	Selection from binary selector	**only with control signal screensaver activation:** Signal for activating the screensaver
Brightness	1 to 10	Display brightness (10 levels)

10.3.3 Colors

Open: Device Menu > Configuration > Display > Colors

Configuration point	Selection/ setting option	Explanation
Alarm 1 to 2	Selection from color palette	Color setting for signaling alarms 1 to 2 of the measuring inputs Upon reaching the set alarm values, the measured value displays and bar graphs appear in the set colors.
Recording: Analog channel 1 to 4 Binary channel 1 to 3 Background, analogue Background, binary Color t-stamp diagr Color diag. traces	Selection from color palette	Color setting for the visualization elements of the individual recorder screens
Controller Background Setpoint value Actual value Output level Heating contact Cooling contact	Selection from color palette	Color setting for the visualization elements of the individual controller screens

10.4 Operation loop

10.4.1 General screens

Open: Device Menu > Configuration > Operation Loop > General Screen > General Screen 1 to 2

Configuration point	Selection/ setting option	Explanation
Gener. screen type	2-part screen 4-part screen	Selection of the type of overview screen; **2-part screen:** Display of 2 main values, 2 second values, 1 additional value and 3 binary values; **4-part screen:** Display of 4 main values, 4 second values, 1 additional value and 3 binary values
Screen title	Up to 31 text characters	Title of the overview screen
Value title 1 to 2(4)	Up to 20 text characters	Titles of the individual main value display fields
Signal main value 1 to 2(4)	Selection from analog selection	Signal source of the analog value for each main value displayed
Color main value 1 to 2(4)	Selection from color palette	Color of the measured value display for each main value
Signal sec. value 1 to 2(4)	Selection from analog selection	Signal source of the analog value for each second value displayed
Color sec. value 1 to 2(4)	Selection from color palette	Color of the measured value display for each second value
Title additional value	Up to 20 text characters	Title of the additional value display field
Signal add value	Selection from analog selection	Signal source of the analog value displayed as additional value
Color addit. value	Selection from color palette	Color of the measured value display for the additional value
Title binary value	Up to 20 text characters	Title of the binary value display field
Signal binary val. 1 to 3	Selection from binary selector	Signal sources of the binary values visualized in the binary value display field

10.4.2 Detailed screens

Open: Device menu > Configuration > Operation Loop > Individual screen > Individual screen 1 to 6

Configuration point	Selection/ setting option	Explanation
Screen title	Up to 31 text characters	Title of the individual screen
Input signal main value	Selection from analog selection	Signal source of the analog value displayed as the main value and visualized as a bar graph
Color main value	Selection from color palette	Color of the measured value display and the bar graph for the main value
Second value input signal	Selection from analog selection	Signal source of the analog value displayed as the second value
Color sec. value	Selection from color palette	Color of the measured value display for the second value
Title additional value	Up to 20 text characters	Title of the additional value display field
Additional value	Selection from analog selection	Signal source of the analog value displayed as additional value
Color addit. value	Selection from color palette	Color of the measured value display for the additional value
Title binary value	Up to 20 text characters	Title of the binary value display field
Signal binary val. 1 to 3	Selection from binary selector	Signal sources of the binary values visualized in the binary value display field

10.5 Analog inputs

10.5.1 Base unit temperature inputs

Base unit temperature inputs: IN 4/5

Open: Device Menu > Configuration > Analog Inputs > Temperature Inputs 1 to 2

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation for the input
Signal type	**IN 4/5:** Pt100 Pt1000 400 Ω 4000 Ω	Type of sensor connected For **Pt100, Pt1000 and NTC,** corresponding linearizations are provided. For **400 Ω, 4000 Ω and 100 kΩ**, a customer-specific linearization must be configured. For **resistance transmitters**[a] a customer-specific linearization can be configures if necessary. ⇨ "Customer-specific linearization" in this table
	IN 5 : 100 kΩ NTC 8k55 NTC 22k Resistance potentiometer[a]	
Connection type	2-wire, 3-wire	**only for signal types Pt100, Pt1000, 400 Ω, 4000 Ω, 100 kΩ and NTC:** Connection variants for the connected resistance thermometer
Customer-specific linearization	Selection of a linearization table	**only for signal types 400 Ω , 4000 Ω , 100 kΩ or resistance transmitters[a]:** Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Start of display range	-99999 to +99999[b]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[b]	
Comma format	Auto, Fixed decimal place format	Decimal points in the display
Offset	-999 to +999[b]	Correction value added to measuring value This value can be used, for instance, to compensate for measurement errors resulting from the resistance of wires.
Filter time constant	0.0 to 25.0 s	Optimization of measuring value updating The higher the value of the filter time const., the slower the measured value is updated.

Configuration point	Selection/ setting option	Explanation
Ra	0 to 99999 Ω	**only for IN 5:** Resistance value between the slider (S) and start point (A) in a resistance transmitter/potentiometer[a] when the slider is at the start point.
Rs	6 to 99999 Ω	**only for IN 5:** Span of the variable resistance value between the slider (S) and start point (A)
Re	0 to 99999 Ω	**only for IN 5:** Resistance value between the slider (S) and end point (E) in a resistance transmitter/potentiometer[a] when the slider is at the end point.
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

[a] Resistance transmitter

[b] The temperature unit specified in the basic settings appears in the entry field.
⇨ Chapter 10.2 "Basic settings", page 138

10.5.2 Universal inputs of base unit and optional boards

Base unit universal input: IN 6
Optional board universal inputs: IN 11/12

Open: Device Menu > Configuration > Analog Inputs > Universal Input 1 to 3 > Configuration

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation for the input
Operating mode	Linear scaling, Temperature measurement, pH-value measurement, Conductivity measurement, Free chlorine pH/T-compensated	Type of measuring **Linear scaling:** Standard signals (for IN 11/12 and resistance transmitter[a]) with linear measurement characteristic line or customer-specific linearization For standard signals the scale start point, scale end point and unit must be specified. **Temp. measurement:** Measurement made with a resistance thermometer The type of sensor is selected in the "Signal type" configuration item. The unit for the temperature is specified in the "Basic Settings" menu. ⇨ Chapter 10.2 "Basic settings", page 138 **pH value, conductivity, and free chlorine:** The values measured by the individual analysis sensors are received in the form of a standard signal. Outside factors affecting the individual analysis process variables are compensated. It is thus necessary to make appropriate compensation settings in the configuration of the universal input.
Signal type	**IN 6/11/12:** 0 to 20 mA 4 to 20 mA 20 to 0 mA 20 to 4 mA	Type of sensor connected Correct scale settings are required for the **standard signals**. ? "Scale start/end" in this table. Appropriate linearizations are available for **Pt100, Pt1000 and resistance transmitters**[a]. For **400 Ω and 4000 Ω**, a customer-specific linearization must be configured. ⇨ "Customer-specific linearization" in this table
	only IN 11/12: 0 to 10 V 10 to 0 V Pt100 Pt1000 400 Ω 4000 Ω Resistance potentiometer	

Configuration point	Selection/ setting option	Explanation
Connection type	2-wire, 3-wire	**only for signal types Pt100, Pt1000, 400 Ω and 4000 Ω:** Connection variants for the connected resistance thermometer
Customer-specific linearization	Selection of a linearization table	Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Unit	Up to 5 text characters	Process variable unit not adjustable for pH measurement The temperature unit is specified in the basic settings. ⇨ Chapter 10.2 "Basic settings", page 138
Scaling start	-99999 to +99999[b]	**only for standard signals:** Measured value from sensor (uncomp.) that corresponds to the lower limit of the standard signal range [0 V or 0(4) mA]; Refer to the technical data for the sensor.
Scaling end	-99999 to +99999[b]	**only for standard signals:** only for standard signals: Measured value from sensor (uncomp.) that corresponds to the upper limit of the standard signal range [10 V or 20 mA] Refer to the technical data for the sensor.
Start of display range	-99999 to +99999[b]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[b]	
Comma format	Auto Fixed decimal place format	Decimal points in the display
Offset	-999 to +999[b]	**only for temperature and conductivity measurement:** Correction value added to measured value
Filter time constant	0.0 to 25.0 s	Optimization of measured value updating The higher the value of the filter time const., the slower the measured value is updated.
Ra	0 to 4000 Ω	**only for IN 11/12:** Resistance value between the slider (S) and start point (A) in a resistance potentiometer when the slider is at the start point

Configuration point	Selection/ setting option	Explanation
Rs	6 to 4000 Ω	**only for IN 11/12:** Span of the variable resistance value between the slider (S) and start point (A)
Re	0 to 4000 Ω	**only for IN 11/12:** Resistance value between the slider (S) and end point (E) in a resistance potentiometer when the slider is at the end point.
Manual compensation	Yes No	Activation of manual temperature compensation With manual temperature compensation (setting "yes"), the temperature value set in the configuration item "Manual compensation temperature" is used for temperature compensation. The configuration item "Compensation temperature" is grayed out. With the "no" setting, the temperature value of the signal selected in the configuration item "Compensation temperature" is used and the configuration item "Manual compensation temperature" is grayed out.
Manual compensation temperature	-25.00 up to 150 °C	Temperature value for manual temperature compensation (see configuration item "Manual compensation")
Compensation temperature	Selection from analog selection	Analog input of the compensation thermometer for temperature-compensated measurement of pH value, free chlorine or conductivity (see configuration item "Manual compensation")
Compensation	TC linear, TC-curve, Natural water, Natural waters with expanded temperature range, ASTM neutral, ASTM acid, ASTM alkaline, NaOH 0 to 12 %, NaOH 25 to 50 %, HNO_3 0 to 25 %, HNO_3 36 to 82 %, H_2SO_4 0 to 28 %, H_2SO_4 36 to 85 %, H_2SO_4 92 to 99 %, HCL 0 to 18 %, HCL 22 to 44 %	Type of temperature compensation for conductivity measurement
Reference temperature	15 to 30 °C	**required only for conductivity measurement with "TC linear" or "TC curve" temperature compensation:** Temperature at which the (temperature-compensated) conductivity value displayed was set

Configuration point	Selection/ setting option	Explanation
Compensation pH value	Selection from analog selection	Analog input of the pH-value sensor for pH-compensated measurement of free chlorine
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

[a] Resistance transmitter
[b] The unit for the particular sensor value appears in the entry field.

10.5.3 Calibration timer

Open Calibration Timer Settings Universal Inputs:
Device Menu > Configuration > Analog Inputs >
Universal Input 1 to 3 > Calibration Timer

Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together.
⇨ Chapter 10.13 "Calibration timer", page 201

10.5.4 pH/Redox/NH_3 analysis inputs

Open: Device Menu > Configuration > Analog Inputs > Analysis Input 1 to 4 > Configuration

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation for the input
Electrode type	pH standard pH antimony pH ISFET redox ammonia	Type of electrode connected
Redox unit	mV percent	**mV**: unit for the redox potential **Percent**: concentration percentage that can be derived from the redox measurement This requires a two-point calibration. ⇨ Chapter 14.2.1 "Calibration methods for Redox sensors", page 249
Filter time constant	0.0 to 25.0 s	Optimization of measured value updating The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[a]	
Manual compensation	Yes No	Activation of manual temperature compensation With manual temperature compensation (setting "yes"), the temperature value set in the configuration item "Manual compensation temperature" is used for temperature compensation. The configuration item "Compensation temperature" is grayed out. With the "no" setting, the temperature value of the signal selected in the configuration item "Compensation temperature" is used and the configuration item "Manual compensation temperature" is grayed out.
Manual compensation temperature	-25.00 up to 150 °C	Temperature value for manual temperature compensation (see configuration item "Manual compensation")
Compensation temperature	Selection from analog selection	Analog input of the temperature sensor for compensation of the effect of temperature on the pH-value measurement (see configuration item "Manual compensation")

Configuration point	Selection/ setting option	Explanation
Glass electrode monitoring	Off Minimum impedance Maximum impedance Min./max. impedance	configurable monitoring of pH glass electrodes **without impedance converter** **minimum impedance:** monitoring for soft short/ sensor failure **maximum impedance:** monitoring for aging/pollution/wire break
Reference electrode monitoring	On Off	Activation of reference electrode impedance monitoring A high-impedance symmetrical connection is required.
max. reference impedance	0 to 100 kΩ	upper impedance limit for monitoring a reference electrode
Alarm/Event list	Off Event Alarm	Assignment of sensor failure notification to alarm list or event list
Sensor alarm delay	0 to 999 s	The sensor alarm is suppressed for the set duration of the alarm delay.
Text sensor alarm	Up to 21 text characters	Text for the alarm/event list in case of sensor error
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	
Calibration timer	Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together. ⇨ Chapter 10.13 "Calibration timer", page 201	

[a] The entry field units depend on the configuration items "Electrode type" and "Redox unit".

10.5.5 Calibration timer

Open Calibration Timer Settings Analysis Inputs pH/Redox/NH3:
Device Menu > Configuration > Analog Inputs >
Analysis Input 1 to 4 > Calibration Timer

Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together.
⇨ Chapter 10.13 "Calibration timer", page 201

NOTE

The following points must be observed for correct operation of glass electrode monitoring via impedance measurement (see preceding table):

- Impedance measurements are possible only with glass-based sensors.
- Sensors must be connected directly to an analysis input for pH/Redox/NH_3 on the device.
- Impedance converters must not be installed in the measuring circuit.
- The maximum admissible cable length between sensor and device is 10 m.
- Fluid resistances have a direct impact on the measurement result. It is therefore advisable to activate the impedance measurement in liquids at a minimum conductivity of approx. 100 µS/cm.

10.5.6 CR/Ci analysis inputs (conductive/inductive conductivity)

Open: Device Menu > Configuration > Analog Inputs > Analysis Input 1 to 4 > Configuration

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation for the input
Manual compensation	Yes No	Activation of manual temperature compensation With manual temperature compensation (setting "yes"), the temperature value set in the configuration item "Manual compensation temperature" is used for temperature compensation. The configuration item "Compensation temperature" is grayed out. With the "no" setting, the temperature value of the signal selected in the configuration item "Compensation temperature" is used and the configuration item "Manual compensation temperature" is grayed out.
Manual compensation temperature	-25 to 150 °C	Temperature value for manual temperature compensation (see configuration item "Manual compensation")
Compensation temperature	Selection from analog selection	Analog input of the compensation thermometer for temperature-compensated conductivity measurement (see configuration item "Manual compensation")
Reference temperature	15 to 30 °C	**required only for conductivity measurement with "TDS", "TC linear" or "TC curve" temperature compensation:** The temperature at which the conductivity value displayed was set
Filter time constant	0.0 to 25.0 s	Optimization of measured value updating The higher the value of the filter time const., the slower the measured value is updated.
nominal cell constant	**For CR:** 0.01 to 10 cm^{-1} **For Ci:** 4.00 to 8.00 cm^{-1}	nominal cell constant of the conductivity sensor (can be read from the sensor nameplate) If an ASTM test certificate showing precisely-measured cell constants is available, in addition to entering the nominal cell constants the relative cell constants of all measuring ranges in the calibration values must be manually entered (⇨ Chapter "Manual entry of calibration values", page 236).
Cell type	2 electrodes 4 electrodes	For conductivity sensors with 4 electrodes, pollution detection is made available.

Configuration point	Selection/ setting option	Explanation
Pollution detection	Off On	**possible only for conductive conductivity measurement in a 4-wire circuit:** When this function is activated, a sensor alarm is triggered in case of soiling.
Wire break detection	Off On	**possible only for conductive conductivity measurement:** When this function is activated, a sensor alarm is triggered in case of a sensor wire break.
Alarm/Event list	Off Event Alarm	**possible only for conductive conductivity measurement:** Assignment of the sensor failure notification to alarm list or event list
Sensor alarm delay	0 to 999 s	**possible only for conductive conductivity measurement:** The sensor alarm is suppressed for the set duration of the alarm delay.
Text sensor alarm	Up to 21 text characters	**possible only for conductive conductivity measurement:** Text for the alarm/event list in case of sensor error
Measuring range selection 1	Selection from binary selector	Measuring range selection permits selection of the measuring ranges 1 to 4 by controlling the binary signals. ⇨ Chapter "CR/Ci measuring range switching", page 154
Measuring range selection 2	Selection from binary selector	
Measuring ranges 1 to 4	-	Four ranges each can be configured for conductive/inductive (CR/Ci) conductivity measurements. The settings for all CR-/Ci analysis inputs are explained together. ⇨ Chapter "CR/Ci measuring range configuration", page 155
Alarms 1/2 per measuring range 1 to 4	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

10.5.7 Calibration timer

Open Calibration Timer Settings Analysis Inputs CR/Ci:
Device Menu > Configuration > Analog Inputs >
Analysis Input 1 to 4 > Calibration Timer

Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together.
⇨ Chapter 10.13 "Calibration timer", page 201

10.5.8 CR/Ci measuring ranges

Four configurable measuring ranges are available for each CR/Ci analysis input for measuring electrolytic conductivity. The measuring range is switched by means of 2 selectable digital signals. These signals are specified in the configuration of the individual conductivity measurement inputs.

⇨ Chapter 10.5.6 "CR/Ci analysis inputs (conductive/inductive conductivity)", page 152

CR/Ci measuring range switching

The following table shows which binary value combinations activate the individual measuring ranges:

Active measuring range	**Binary signal Measuring range selection 1**	**Digital signal Measuring range switching 2**
Measuring range 1	0	0
Measuring range 2	1	0
Measuring range 3	0	1
Measuring range 4	1	1

CR/Ci measuring range configuration

Open: Device Menu > Configuration > Analog Inputs > Analysis Input 1 to 4 > Measuring Range 1 to 4

Configuration point	Selection/ setting option	Explanation
TDS factor	0.01 to 2.00	**only for conductive conductivity with TDS compensation:** Conversion factor from measured conductivity to display unit (see configuration item "Unit" in this table)
Compensation	**For CR/Ci analysis inputs:** Off, TC linear, Natural water, Natural water with expanded temperature range	Type of temperature compensation for conductivity measurement
	For CR analysis input only: TDS, ASTM neutral, ASTM acid, ASTM alkaline	
	For Ci analysis input only: TC curve, NaOH 0 to 12 %, NaOH 25 to 50 %, HNO3 0 to 25 %, HNO3 36 to 82 %, H2SO4 0 to 28 %, H2SO4 36 to 85 %, H2SO4 92 to 99 %, HCL 0 to 18 %, HCL 22 to 44 %	
Unit for calculation	**For CR/Ci:** µS/cm mS/cm	Unit in which the conductivity is displayed
	For CR only: kΩ×cm MΩ×cm	
Unit	Up to 5 text characters	**only for conductive conductivity measurement with TDS compensation:** Unit for the process variable to be displayed for TDS measurements or when using customer-specific linearization (e.g. ppm or mg/l)

Configuration point	Selection/ setting option	Explanation
Customer-specific linearization	Selection of a linearization table	Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Start of display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[a]	
Comma format	Auto Fixed decimal place format	Decimal points in the display
Offset	-99999 to +99999[a]	Correction value added to measured value
Alarms 1/2 per measuring range 1 to 4	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

[a] The unit set for the conductivity measurement input appears in the entry field.

10.6 Analog outputs of base unit and optional boards

Open: Device Menu > Configuration > Analog Outputs > Analog Output 1 to 9

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation for the output
Signal output value	Selection from analog selection	Analog signal source of the output
Analog signal	0 to 10 V 0 to 20 mA 4 to 20 mA 10 to 0 V 20 to 0 mA 20 to 4 mA	Type of standard signal to be generated
Enable manu. mode	Yes No	The manual mode for the specific output is enabled/locked here. The manual mode permits fixed analog values to be set for the output for testing purposes. ⇨ Chapter 8.2.3 "Functional level", page 95
Safety value 1 to 4	0 to 10.7 V or 0 to 22 mA	Specifies an analog value that the output assumes at hold, at calibration or in case of a fault If an analysis input for conductivity measurement is set as "Signal output value", the safety values 1 to 4 are assigned to the conductivity measuring ranges 1 to 4. Pairs with the same number belong together. Pairs with the same number belong together. Otherwise, the safety value 1 applies.
Scale start 1 to 4	-99999 to +99999[a]	Analog value of the analog signal source (see configuration item "Signal output value") that corresponds to the lower limit of the standard signal range generated [0 V or 0(4) mA]
Scale end 1 to 4	-99999 to +99999[a]	Analog value of the analog signal source (see configuration item "Signal output value") that corresponds to the upper limit of the standard signal range generated (10 V or 20 mA)
Digital signal for hold	Selection from binary selector	Digital signal for activating the hold function When the hold function is activated, the analog output assumes the state defined in the "Response at hold" setting.

Configuration point	Selection/ setting option	Explanation
Response at hold	Low High NAMUR low NAMUR high Frozen Safety value	Specification of the analog output value when the hold function is activated, during calibration of one of the sensors for the particular output or at error (overrange/underrange) **low:** lower limit of the standard signal value range [0 V or 0(4) mA] **high:** upper limit of the standard signal value range (10 V or 20 mA) **NAMUR low:** lower NAMUR limit of the standard signal [0 V or 0(3.4) mA] **NAMUR high:** upper NAMUR limit of the standard signal (10.7 V or 22 mA) **hold:** unchanging analog value **Safety value:** see configuration item "Safety value" in this table
Response during calibration	Moving Frozen Safe value	
Response in case of a fault	Low High NAMUR low NAMUR high Frozen Safety value	

[a] The unit for the value set for the "Signal output value" appears in the entry field.

10.7 Digital inputs of base unit and optional boards

Open: Device Menu > Configuration > Digital Inputs > Digital Input 1 to 9

Configuration point	Selection/ setting option	Explanation
Designation	Up to 21 text characters	Designation for the input
Inverting	Yes No	Invert/do not invert state
Contact	**Base unit:** Potential-free contact, External voltage source	Type of digital signal connected
	Optional boards: Potential-free contact	
Alarm	Binary inputs alarms are used to monitor input-side switching signals.The alarm settings for all digital device functions are explained together.The alarm settings for all digital device functions are explained together.The alarm settings for all digital device functions are explained together. ⇨ Chapter 10.12.3 "Digital signal alarms", page 200	

10.8 Digital outputs of base unit and optional boards

Open: Device Menu > Configuration > Digital Outputs > Digital Output 1 to 17

Configuration point	Selection/ setting option	Explanation
Designation	Up to 21 text characters	Designation for the output
Signal output value	Selection from binary selector	Digital signal source for the output
Inverting	Yes No	Invert/do not invert state
Enable manu. mode	Yes No	The manual mode for the specific output is enabled/locked here. Manual mode permits fixed binary values (switching states) to be set for the output for testing purposes. ⇨ Chapter 8.2.3 "Functional level", page 95

10.9 Alias values

Open: Device menu > Configuration > Alias values > Alias value 1 to 16

An alias value is a useful tool for distributing an analog signal of the JUMO AQUIS touch P to several internal functions and analog outputs of the device. It serves primarily as a unique distribution node between a signal source (analog input or output signal of a device-internal function) and several signal destinations (e.g. inputs of device-internal functions and analog outputs). This simplifies management of the signal flow in the device. For instance, the signal source for a group of device-internal functions and analog outputs can easily be changed in an alias value if the corresponding alias value is set as the input signal in the associated functions and analog outputs. In the figure, the alias value 1 is set as input signal for a controller, a recording group and an analog output. The alias value allows the signal source to be changed from temperature input 1 to temperature input 2 at a central location. It is simply a matter of changing the input value of the alias value.



JUMO PC setup programm



Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Naming for the alias value

Configuration point	Selection/ setting option	Explanation
Source of the designation	Text designation Signal designation	Selection of the designator text to be displayed for the alias value For the designator text of the alias value in the analog selection and in the unit functions, you can select between "Text designation" (designation of the alias value) and "Signal designation" (designation of the signal selected in the configuration item "Input signal").
Input signal	Selection from Analog selector	Signal source of the alias value Input value equals output value; the alias value represents the input signal.

10.10 Salinity

NOTE

The 4 salinity functions are based on the "Practical Salinity Scale" (PSS-78, UNESCO 1981) and are valid for the temperature range of -2 to 35 °C and the salinity range of 0 to 42 g/kg or PSU.

Configuration point	Selection/ setting option	Explanation
Function	Inactive Active	Activation/deactivation of the salinity function
Designation	Up to 20 text characters	Plain text designation of the salinity function This designation is displayed in menus, e. g. analog or binary selection.
Unit	PSU[a] g/kg	Selection of the unit in which the salinity is displayed.
Comma format	Auto Fixed decimal place format	Decimal points in the display
Start of display range	-99999 to +99999[b]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[b]	
Signal conductivity	Selection from Analog selection	Selection of an **uncompensated conductivity measurement** as a signal source for the salinity function
Compensation	Fixed temperature analog selector	Selection of the signal source for temperature compensation in the salinity function **Fixed temperature:** Compensation using a fixed temperature value that is entered in the configuration item "Compensation temperature". **Analog selector:** Selection of the signal source from the Analog selector of the JUMO AQUIS touch P for temperature compensation of the salinity function
Compensation temperature	Selection from Analog selection	**only if "Compensation" is set to "Analog selector":** Selection of the signal source from the Analog selector of the JUMO AQUIS touch P for temperature compensation of the salinity function

Configuration point	Selection/ setting option	Explanation
fixed compensation temp.	-2 to 35 °C	**only if "Compensation" is set to "Fixed compensation temperature":** constant temperature value, for temperature compensation of the salinity function

[a] PSU stands for **P**ractical **S**alinity **U**nit. The value of the "PSU" unit corresponds to the "g/kg" unit.
[b] The unit displayed in the entry field corresponds to the setting in the "unit" parameter.

10.11 Digital sensors

NOTE

For operation of digital sensors, you need the extra code "JUMO digiLine protocol activated“ (⇨ Chapter 4.2 "Order details", page 24)

NOTE

Only one serial interface of the device can be configured for operation of digital sensors. If your device has 2 serial interfaces (base unit and possibly an optional board), select 1 interface for connection of digital sensors and configure it appropriately.

NOTE

Correct functioning of digital sensors depends on correctly setting the interface to which the digital sensors are connected and are to be operated. Make sure the selected serial interface is configured correctly.

10.11.1 General settings for digital sensors

The inputs for digital sensors 1 to 6 are prepared for startup in the general settings for digital sensors. The type of digital sensor is selected here. Only then can the JUMO digiLine electronics recognized on a JUMO digiLine bus be assigned to an input for digital sensors.
⇨ Chapter 7.2 "Digital sensors", page 72
⇨ Chapter 8.2.7 "Digital sensors", page 99

Open General Settings Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > General

Configuration point	Selection/ setting option	Explanation
Parameter	No sensor pH ORP Temperature O-DO Turbidity Free chlorine pH-dependent Free chlorine pH-neutral Total chlorine Ozone tenside-dependent Ozone tenside-neutral Peracetic acid Hydrogen peroxide Chlorine dioxide tenside-dependent Chlorine dioxide tenside-neutral Bromide Free chlorine, open CR (conductive conductivity) Ci (inductive conductivity) Flow	Sensor type selection Digital sensors can only be linked if these settings match the type information of the sensor to be linked. If this setting is changed during operation of a linked sensor, the sensor involved loses its link and must be put into operation anew.
with temperature input	Yes No	The setting "with temperature input" is only available upon selection of pH sensors.
VDN number	0 to 999	Specification that only certain variants of a sensor type are accepted.
O-DO subtype	O-DO ecoLine O-DO H10 O-DO H20 O-DO S10	**For oxygen sensors only:** select the oxygen sensor type
	W02 dL temp W02 dL temp and pressure	**Only for flow sensor:** Selection of the flow sensor type

10.11.2 Configuration of digital sensors

Open Configuration Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration

Gen. settings for all types of digital sensors

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Plain text designation for the digital sensor input This designation is displayed in menus, e. g. analog or binary selection.
Alarms 1/2	Alarms for measured values from digital sensors are used for monitoring the measured values with respect to adjustable limits. Except for JUMO digiLine CR/Ci, the alarm settings for all digital sensors can be found in the configuration of the individual digital sensor (see above). For the JUMO digiLine CR/Ci, the alarm settings can be found in the measuring range configuration: Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration > Measuring Range 1 to 4 The alarm settings for all measured values from digital sensors are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

10.11.3 Configuration for sensors with JUMO digiLine electronics

Only for JUMO sensors with JUMO digiLine electronics pH/ORP/T

Configuration point	Selection/ setting option	Explanation
TAG checking	Inactive Active	If desired, this function can be activated to assign JUMO digiLine electronics to measuring points. When it is activated, the "TAG number" of the sensor is compared with the entry in the "Sensor Tag" field of the digital sensor inputs on connection of a sensor to a master device. If these differ, the JUMO digiLine electronics are not linked. The "TAG number" of the JUMO digiLine electronics can be entered and edited in the JUMO digiLine electronics only with the JUMO-DSM software.
Sensor TAG	Up to 20 text characters	
Redox unit	mV percent	**mV**: unit for the redox potential **Percent**: concentration percentage that can be derived from the redox measurement This requires a two-point calibration. ⇨ Chapter 14.2.1 "Calibration methods for Redox sensors", page 249
Filter time constant[a]	0 to 25 s	Optimization of measured value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	-99999 to +99999[b]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[b]	

Configuration point	Selection/ setting option	Explanation
Compensation[a]	Fixed compensation temperature Sensor temperature Interface	**For pH sensors only:** Selection of the signal source for temperature compensation in the JUMO digiLine electronics **Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Sensor temperature:** The integrated temperature probe of the pH sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the JUMO digiLine electronics via the serial interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
fixed compensation temp.[a]	-25 to+150 °C	**only if "Compensation" is set to "Fixed compensation temperature":** constant temperature value, for temperature compensation of the pH value measurement in the JUMO digiLine electronics
Compensation temperature	Selection from Analog selection	**only if "Compensation" is set to "Interface":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the pH value measurement in the JUMO digiLine electronics
Temperature input filter time[a]	0 to 25 s	Optimization of measured temperature value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.
Temperature offset[a]	-10 to+10 °C	Correction value that is added to the measured temperature value

[a] This setting is saved in the configuration of the JUMO digiLine electronics.
[b] The unit for the item set in "Parameter" appears in the entry field.

Only for sensors with JUMO digiLine CR/Ci

Configuration point	Selection/ setting option	Explanation
TAG checking	Inactive Active	If desired, this function can be activated to assign JUMO digiLine electronics to measuring points. When it is activated, the "TAG number" of the sensor is compared with the entry in the "Sensor Tag" field of the digital sensor inputs on connection of a sensor to a master device. If these differ, the JUMO digiLine electronics are not linked. The "TAG number" of the JUMO digiLine electronics can be entered and edited in the JUMO digiLine electronics only with the JUMO-DSM software.
Sensor TAG	Up to 20 text characters	
Compensation[a]	Fixed compensation temperature Sensor temperature Interface	Selection of the signal source for temperature compensation in the JUMO digiLine electronics **Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Sensor temperature:** The integrated temperature probe of the conductivity sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the JUMO digiLine electronics via the serial interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
Compensation temperature	Selection from Analog selection	**only if "Compensation" is set to "Interface":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the conductivity measurement in the JUMO digiLine electronics

Configuration point	Selection/ setting option	Explanation
fixed compensation temp.[a]	-50 to +150 °C	**only if "Compensation" is set to "Fixed compensation temperature":** constant temperature value, for temperature compensation of the conductivity measurement in the JUMO digiLine electronics
Reference temperature[a]	15 to 30 °C	**required only for conductivity measurement with "TC linear", "TC curve" or TDS temperature compensation: Temperature at which the (temperature-compensated) conductivity value displayed was set**
Wire break detection[a]	Off On	**for CR sensors only:** A sensor alarm is activated in the event of a sensor wire break when this function is activated.
Conductivity filter time constant[a]	0 to 25 s	Optimization of measured value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.
nominal cell constant[a]	**For CR:** 0.01 to 10 cm^{-1} **For Ci:** 4.00 to 8.00 cm^{-1}	nominal cell constant of the conductivity sensor (can be read from the sensor nameplate) If an ASTM test certificate showing precisely-measured cell constants is available, in addition to entering the nominal cell constants the relative cell constants of all measuring ranges in the calibration values must be manually entered (⇨ Chapter "Manual entry of calibration values", page 236).
rel. cell constant (mode)[a]	For all MR One per MR	This parameter can be used to specify whether one relative cell constant should be used for all 4 measuring ranges, or whether each measuring range should have its own cell constant and that is used for the measured value calculation. ⇨ Chapter "Manual entry of calibration values", page 236

Configuration point	Selection/ setting option	Explanation
Install. factor	80 to 120 %	**for Ci sensors only:** This factor helps to correct for measurement errors by the sensor when the sensor cannot be mounted as indicated in the installation instructions for the particular sensor. Always refer to the documentation for the sensor type associated with your device for the setting. You can identify the sensor type for your device from the order code on the nameplate of the device. ⇨ Chapter 4.2 "Order details", page 24
Measuring range selection 1	Selection from binary selector	Measuring range selection permits selection of the measuring ranges 1 to 4 by controlling the binary signals. ⇨ Chapter "CR/Ci measuring range switching", page 172
Measuring range selection 2	Selection from binary selector	
Temperature input function	On Off	**only for hardwired device versions:** Activation of the temperature input
Filter time Temperature input[a]	0 to 25 s	Optimization of measured temperature value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.
Temperature offset[a]	-10 to+10 °C	Correction value that is added to the measured temperature value
Connection type[a]	2-wire, 3-wire	**only for device versions with a separate CR sensor** Connection variants for the connected resistance thermometer

[a] This setting is saved in the configuration of the JUMO digiLine electronics.

CR/Ci measuring ranges

Four separately configurable measuring ranges are available for the JUMO digiLine CR/Ci for measuring electrolytic conductivity. The measuring range is switched by means of 2 selectable digital signals. These are specified in the configuration of the individual input of the digital sensor, which is configured for the JUMO digiLine CR/Ci concerned.

⇨ Chapter "Only for sensors with JUMO digiLine CR/Ci", page 169

CR/Ci measuring range switching

The following table shows which binary value combinations activate the individual measuring ranges:

Active measuring range	Binary signal Measuring range selection 1	Digital signal Measuring range switching 2
Measuring range 1	0	0
Measuring range 2	1	0
Measuring range 3	0	1
Measuring range 4	1	1

CR/Ci measuring range configuration

Opening JUMO digiLine CR/Ci: Device Menu > Configuration > Digital Sensors >
Digital Sensor 1 to 6 > Measuring Range 1 to 4

Configuration point	Selection/ setting option	Explanation
TDS factor	0.01 to 2.00	**only for TDS compensation:** Conversion factor from measured conductivity to display unit (see configuration item "Unit" in this table)
Compensation	**For JUMO digiLine CR/Ci:** Off, TC linear, TC curve, Natural water, Natural water with expanded temperature range, TDS	Type of temperature compensation for conductivity measurement
	For JUMO digiLine CR: ASTM neutral, ASTM acidic, ASTM alkaline	

Configuration point	Selection/ setting option	Explanation
Compensation	**For JUMO digiLine Ci:** NaOH 0 to 12 % NaOH 25 to 50 % HNO_3 0 to 25 % HNO_3 36 to 82 % H_2SO_4 0 to 28 % H_2SO_4 36 to 85 % H_2SO_4 92 to 99 % HCl 0 to 18 % HCl 22 to 44 % NaCl 0 to 25 % $MgCl_2$ 0 to 17.5 % $MgCl_2$ 18.5 to 25 %	Type of temperature compensation for conductivity measurement
Start of display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[a]	
Unit for calculation	µS/cm mS/cm kΩ×cm MΩ×cm	Unit in which the conductivity is displayed
Unit for table and TDS	Up to 5 text characters	**only for conductivity measurement with TDS compensation:** Unit for the process variable to be displayed for TDS measurements or when using customer-specific linearization (e.g. ppm or mg/l)
Customer-specific linearization	Selection of a linearization table	Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Comma format	Auto Fixed decimal place format	Decimal points in the display
Offset	-99999 to +99999[a]	Correction value added to measured value

[a] The unit for the item set in the parameter "Unit for calculation" appears in the entry field.

10 Configuration

Only for sensors of the JUMO digiLine O-DO H10/H20 types

Configuration point	Selection/ setting option	Explanation
TAG checking	Inactive Active	If desired, this function can be activated to assign JUMO digiLine electronics to measuring points. When it is activated, the "TAG number" of the sensor is compared with the entry in the "Sensor Tag" field of the digital sensor inputs on connection of a sensor to a master device. If these differ, the JUMO digiLine electronics are not linked. The "TAG number" of the JUMO digiLine electronics can be entered and edited in the JUMO digiLine electronics only with the JUMO-DSM software.
Sensor TAG	Up to 20 text characters	
Measurement mode	Humid Dry	Selection depends on the humidity content of the measurement medium. "Humid" = Measurement medium with humidity content > 50 %, , "Dry" = Measurement medium with humidity content < 50 %.
Oxygen unit	% vol % SAT ppb ppm hPa	Selection of the unit in which the oxygen content is displayed. The "ppm" and "ppb" units are not available when selecting the "Dry" measurement mode. If the unit "hPa" is selected, the oxygen partial pressure is measured in hectopascals.
Start of display range	-99999 to +99999	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs. The unit set as the unit in the parameter "Oxygen unit" appears in the entry field.
End of display range	-99999 to +99999	
Comma format	Auto Fixed decimal place format	Decimal points in the display
Sampling time	1 to 599 s	The measurements of the sensor are triggered by JUMO AQUIS touch. The sampling rate defines the time between the measurements and impacts aging of the sensor cap.

Configuration point	Selection/ setting option	Explanation
Temperature compensation source	Fixed compensation temperature sensor temperature Analog selector	Selection of the signal source for temperature compensation in the JUMO digiLine electronics **Fixed compensation temperature:** The value is set in JUMO AQUIS touch under the configuration item "Fixed compensation temperature". **Sensor temperature**: The integrated temperature probe of the oxygen sensor supplies the compensation temperature. **Analog selector**: The JUMO AQUIS touch transmits the compensation temperature to the JUMO digiLine electronic components via the serial interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
Compensation temperature	Selection from Analog selection	**Only if "Temperature compensation source" is set to "Analog selector":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the oxygen measurement in the JUMO digiLine electronics
Fixed compensation temperature	0 to 50 °C	**Only if "Temperature compensation source" is set to "Fixed compensation temperature":** Input of the fixed compensation temperature.

Configuration point	Selection/ setting option	Explanation
Pressure compensation source	Fixed compensation pressure Analog selector	**only if "Oxygen unit" is set to "% Vol" or "% SAT":** Selection of the signal source for the pressure compensation of the JUMO digiLine electronics **Fixed compensation pressure:** Compensation using a fixed pressure value entered in the "Fixed compensation pressure" configuration item. **Analog selector:** The JUMO AQUIS touch transmits the compensation pressure to the JUMO digiLine electronics via the serial interface. The source for the compensation pressure is set in the "Compensation pressure" configuration item.
Compensation pressure	Selection from Analog selection	**Only if the "Oxygen unit" is set to "% Vol" or "% SAT", and "Pressure compensation source" is set to "Analog selector":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for pressure compensation of the oxygen measurement in the JUMO digiLine electronics
Fixed compensation pressure	500 to 1500 hPa	**Only if the "Oxygen unit" is set to "% Vol" or "% SAT", and "Pressure compensation source" is set to "Fixed compensation pressure":** Fixed pressure value for compensation of the oxygen measurement in the JUMO digiLine electronic components
Salt content	0 to 99 g/kg	**Only if the "Oxygen unit" is set to "ppm" or "ppb":** Fixed saline content value for the compensation of the oxygen measurement in JUMO digiLine electronic components

Configuration point	Selection/ setting option	Explanation
Switch-off temp Measuring	-50 to +130 °C	Input of the temperature value which if it is exceeded, sensor oxygen measurement is to be switched off. A temperature-compensated oxygen measurement value can only be output in the temperature range of 0 to 50 °C.
Minimum Measurement temperature	-50 to +130 °C	Input of the minimum temperature value from which the sensor's operating hours are to be acquired.
Maximum Measurement temperature	-50 to +130 °C	Input of the maximum temperature value up to which the sensor's operating hours are to be acquired.
Measurements counter	Inactive Active	This optionally activatable function is only intended for counting oxygen measurements and depends on the configured sampling rate. The counter is an indicator for identifying aging and wear of the sensor cap. If the counter is activated, the count value can be viewed in the "Device info" menu
Limit value count measurements	0 to 99,999,999	**Only if "Measurements counter" is set to "active":** Input of the limit value for oxygen measurements, e.g. for a request for a sensor cap change via the sensor alarm function.

10 Configuration

Only for sensors of the JUMO digiLine O-DO S10 types

Configuration point	Selection/ setting option	Explanation
TAG checking	Inactive Active	If desired, this function can be activated to assign JUMO digiLine electronics to measuring points. When it is activated, the "TAG number" of the sensor is compared with the entry in the "Sensor Tag" field of the digital sensor inputs on connection of a sensor to a master device. If these differ, the JUMO digiLine electronics are not linked. The "TAG number" of the JUMO digiLine electronics can be entered and edited in the JUMO digiLine electronics only with the JUMO-DSM software.
Sensor TAG	Up to 20 text characters	
Oxygen unit	% Vol % SAT ppm hPa	Selection of the unit in which the oxygen content is displayed. If the unit "hPa" is selected, the oxygen partial pressure is measured in hectopascals.
Start of display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[a]	
Comma format	Auto Fixed decimal place format	Decimal points in the display
Temperature compensation source	Sensor temperature Analog selector	Selection of the signal source for temperature compensation in the JUMO digiLine electronics **Sensor temperature:** The integrated temperature probe of the oxygen sensor supplies the compensation temperature. **Analog selector:** The JUMO AQUIS touch transmits the compensation temperature to the JUMO digiLine electronic components via the serial interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".

Configuration point	Selection/ setting option	Explanation
Compensation temperature	Selection from Analog selection	**Only if "Temperature compensation source" is set to "Analog selector":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the oxygen measurement in the JUMO digiLine electronics
Pressure compensation source	Fixed compensation pressure Analog selector	**only if "Oxygen unit" is set to "% Vol" or "% SAT":** Selection of the signal source for the pressure compensation of the JUMO digiLine electronics **Fixed compensation pressure:** Compensation using a fixed pressure value entered in the "Fixed compensation pressure" configuration item. **Analog selector:** The JUMO AQUIS touch transmits the compensation pressure to the JUMO digiLine electronics via the serial interface. The source for the compensation pressure is set in the "Compensation pressure" configuration item.
Compensation pressure	Selection from Analog selection	**only if the "Oxygen unit" is set to "% Vol" or "% SAT", and "Pressure compensation source" is set to "Analog selector":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for pressure compensation of the oxygen measurement in the JUMO digiLine electronics
Fixed compensation pressure	10 to 2000 hPa	**only if the "Oxygen unit" is set to "% Vol" or "% SAT", and "Pressure compensation source" is set to "Fixed compensation pressure":** constant pressure value, for pressure compensation of the oxygen measurement in the JUMO digiLine electronics

Configuration point	Selection/ setting option	Explanation
Salt content compensation source	Fixed salt content Analog selector	**only if "Oxygen unit" is set to "ppm":** Selection of the signal source for the salt content compensation of the JUMO digiLine electronics **Fixed salt content:** Compensation using a fixed salt content entered in the "Fixed compensation salt content" configuration item. **Analog selector**: The JUMO AQUIS touch transmits the compensation salt content to the JUMO digiLine electronics via the serial interface. The source for the compensation salt content is set in the "Compensation salt content" configuration item.
Salt content compensation	Selection from Analog selection	**only if "Oxygen unit" is set to "ppm", and "Salt content compensation source" is set to "Analog selector":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for salt content compensation of the oxygen measurement in the JUMO digiLine electronics As a signal source for the salt content, the JUMO AQUIS touch P offers 4 salinity functions, which can determine the salt content in the process solution with the aid of a conductivity sensor and a temperature sensor (⇨ Chapter 10.10 "Salinity", page 162).
Fixed salt content compensation	0 to 60 mS/cm	**only if "Oxygen unit" is set to "ppm" and "Salt content compensation source" are set to "Fixed salt content compensation":** constant conductivity value, for salt content compensation of the oxygen measurement in the JUMO digiLine electronics

[a] The unit set as the unit in the parameter "Oxygen unit" appears in the entry field.

Only for sensors of the type JUMO flowTRANS US W02 dL

Configuration point	Selection/ setting option	Explanation
TAG checking	Inactive Active	If desired, this function can be activated to assign JUMO digiLine electronics to measuring points. When it is activated, the "TAG number" of the sensor is compared with the entry in the "Sensor Tag" field of the digital sensor inputs on connection of a sensor to a master device. If these differ, the JUMO digiLine electronics are not linked. The "TAG number" of the JUMO digiLine electronics can be entered and edited in the JUMO digiLine electronics only with the JUMO-DSM software.
Sensor TAG	Up to 20 text characters	
Flow unit	l/sec l/min l/h cm3/s cm3/h ft3/m (ft3/min) ft3/h uga/m (usgal/min) usgal/h iga/m (impgal/min) iga/h (impgal/h)	Selection of the unit in which the flow value is displayed. The specifications in brackets show the units in full.
Comma format, flow	Auto Fixed decimal place format	Decimal points in the display
Filter time, flow	0 to 25 s	Optimization of measured value updating. The higher the value of the filter time, the slower the measured value is updated.
Inversion, flow	Inactive Active	Inverts the flow signal. Helpful e.g. if the device has been installed in the wrong flow direction.
Characteristic line, flow	Standard User defined 1 to 9	Standard: Water User-defined: Currently cannot be defined by the user. **Please do not select!**

Configuration point	Selection/ setting option	Explanation
Start of display range flow	-99999 to +99999	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End, display range, flow	-99999 to +99999	
Low flow limit value	0 to 10 %	Input value in % of measuring range end value. No process value is output below the limit value.
Hysteresis Low flow	0 to 50 %	Input value in % of the low flow limit value. Sets hysteresis of low flow.
Unit Totalizer	cm3 l m3 ft3 usgal imgal (impgal)	Selection of the unit in which the total count value is displayed. The specifications in brackets show the units in full. **The JUMO AQUIS touch only shows the value of the totalizer of the JUMO flowTRANS US W02. This function must be controlled by the JUMO DSM software or the relevant device's app.**
Filter time temperature	0 to 25 s	Optimization of measured value updating. The higher the value of the filter time, the slower the measured value is updated.
Temperature offset	-10 to +10 °C	Offset correction for zero point adjustment
Pressure unit[a]	bar mbar psi	Selection of the unit in which the pressure value is displayed.
Decimal place, pressure[a]	Auto Fixed decimal place format	Decimal points in the display
Filter time, pressure[a]	0 to 25 s	Optimization of measured value updating. The higher the value of the filter time, the slower the measured value is updated.
Offset, pressure[a]	-10000 to 10000	Offset correction for zero point adjustment
Start of display range, pressure[a]	-99999 to 99999	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs.
End of display range, pressure[a]	-99999 to 99999	

Configuration point	Selection/ setting option	Explanation
Bluetooth mode	Off Restricted On	When selecting "Limited", the Bluetooth® module of the JUMO flowTRANS US W02 is temporarily enabled via NFC. If the Bluetooth® connection is not used after pairing, the Bluetooth® module switches off after a certain period of time.

[a] Only visible if JUMO flowTRANS US subtype W02 dL temp and pressure is selected

10.11.4 Configuration of JUMO ecoLine sensors

For JUMO ecoLine O-DO sensors only

Configuration point	Selection/ setting option	Explanation
Oxygen unit	% Sat mg/l ppm	Selection of the unit in which the oxygen content is displayed.
Salt content	0 to 10000 g/kg	Specification of the salt content (salinity) of the measurement solution for compensation of the effect of the salinity on the measured value of the oxygen content in the measurement solution
Air pressure	500 to 1500 hPa	Specification of the plant's ambient air pressure for compensation of the effect of the air pressure on the measured value of the oxygen content in the measurement solution
Compensation	Fixed compensation temperature Sensor temperature Interface	**Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Sensor temperature:** The integrated temperature probe of the O-DO sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
fixed compensation temp.	-25 to+150 °C	**Only if "Compensation" is set to "Fixed compensation temperature":** constant temperature value for temperature compensation of the oxygen measurement in the O-DO sensor

Configuration point	Selection/ setting option	Explanation
Compensation temperature	Selection from Analog selection	**Only if "Compensation" is set to "Interface":** Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the oxygen measurement in the O-DO sensor
Start of display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[a]	
Sampling time	1 to 999 s	Indication of the length of the interval between 2 measurements A slower "sampling rate" contributes to a longer operating life of the sensor. With faster "sampling rates, the measured value is updated frequently.
Filter time constant	0 to 25 s	Optimization of measured value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.

[a] The unit set as the unit in "Oxygen unit" appears in the entry field.

For JUMO ecoLine NTU sensors only

Configuration point	Selection/ setting option	Explanation
Turbidity measuring range	Automatic 0 to 50 NTU 0 to 200 NTU 0 to 1000 NTU 0 to 4000 NTU	Selection of the measuring range for the turbidity measurement The user can choose a fixed measuring range or automatic measuring range selection.
Turbidity unit	NTU FNU	Selection of the unit in which the measured turbidity value is displayed.
Comma format	Fixed decimal place format	Decimal points in the display
Filter time constant	0 to 25 s	Optimization of measured value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	-99999 to +99999[a]	

[a] The unit set as the unit in "Turbidity unit" appears in the entry field.

10.11.5 Configuration of JUMO tecLine sensors

Configuration point	Selection/ setting option	Explanation
Measuring range Free chlorine pH-dependent Open chlorine measurement Total chlorine Chlorine dioxide Chlorine dioxide tenside-neutral Bromide Free chlorine pH-neutral Ozone tenside-dependent Ozone tenside-neutral Peracetic acid Hydrogen peroxide	 2 ppm 20 ppm 2 ppm 20 ppm 200 ppm 10 ppm 20 ppm 2 ppm 10 ppm 200 ppm 2000 ppm 20000 ppm 20000 ppm 20 %	Setting of the measuring range for the various measurands of digital JUMO tecLine sensors This is where you set the measuring range of your digital JUMO tecLine sensor according to the order details for the sensor.
Comma format	Auto Fixed decimal place format	Decimal points in the display
Filter time constant	0 to 25 s	Optimization of measured value updating in the JUMO digiLine electronics The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	0 to 20000[a]	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
End of display range	0 to 20000[a]	
pH-compensated chlorine measurement	On Off	**available only for pH-dependent measurements of free chlorine:** Activation/deactivation of the pH-compensation for the free chlorine measurement

Configuration point	Selection/ setting option	Explanation
pH compensation source	Selection from Analog selection	**available only with pH-compensation activated:** Analog input of the pH-value sensor for pH-compensated measurement of free chlorine

[a] The unit for the particular sensor value appears in the entry field.

10.11.6 Sensor alarms

Digital sensors cyclically transmit a number of alarm and status bits. In the settings for the sensor alarms, it is possible to set which of these signals should be indicated on the JUMO AQUIS touch P. The settings for the alarm conditions themselves are made in the configuration of the individual sensor electronics or stipulated by the specifications for the particular sensor. More detailed information on configuration can be found in the operating manual for the particular sensor type.

Open Sensor Alarms Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Sensor Alarms

Every alarm transmitted by the digital sensors has the following configuration parameters:

Configuration point	Selection/ setting option	Explanation
Alarm/Event list	Off Event Alarm	Assignment of alarm notification to alarm list or event list
Sensor alarm delay	0 to 999 s	time delay from receipt of the alarm signal from the sensor and triggering of the alarm on the device
Alarm text	–	Text for the alarm/event list Displayed only and cannot be changed.

The range of alarm types that can be transmitted by a digital sensor depends on the sensor type. The individual alarm lists for the various sensor types are provided in the following.

JUMO digiLine pH

Alarm	Explanation
pH sensor alarm	Alarm for pH value out of range
Temperature sensor alarm	Alarm for temperature out of range
pH min. warning	Lower pH limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
pH min. alarm	Lower pH limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
pH max. warning	Upper pH limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
pH max. alarm	Upper pH limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Min. temperature warning	Lower temperature limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Min. temperature alarm	Lower temperature limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Max. temperature warning	Upper temperature limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Max. temperature alarm	Upper temperature limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Calibration timer alarm	Alarm for sensor calibration due (see "Calibration data" in the JUMO digiLine pH operating manual)
CIP/SIP/Autoclaving warning	Pre-alarm for maximum number of CIP/SIP/autoclaving cycles (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
CIP/SIP/Autoclaving alarm	Alarm for maximum number of CIP/SIP/autoclaving cycles (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Sensor stress warning	Sensor stress pre-alarm (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Sensor stress alarm	Sensor stress alarm (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Digital input state	Signal state of the digital input of the sensor electronics

JUMO digiLine ORP

Alarm	Explanation
ORP sensor alarm	Alarm for redox value out of range
Calibration timer alarm	Alarm for sensor calibration due (see "Calibration data" in the JUMO digiLine ORP operating manual)
Digital input state	Signal state of the digital input of the sensor electronics

JUMO digiLine T

Alarm	Explanation
Temperature sensor alarm	Alarm for temperature value out of range
Digital input state	Signal state of the digital input of the sensor electronics

JUMO digiLine CR/Ci

Alarm	Explanation
Conductivity alarm	Alarm for conductivity value out of range
Temperature alarm	Alarm for conductivity value out of range
Compensation range left	Alarm for temperature limits violated for the configured temperature compensation type
Pre-alarm for max. CIP/SIP	Pre-alarm for maximum number of CIP/SIP (see "Sensor monitoring" configuration in the JUMO digiLine CR/Ci operating manual)
Alarm for max. CIP/SIP	Alarm for maximum number of CIP/SIP (see sensor monitoring configuration in the JUMO digiLine CR/Ci operating manual)
Sensor stress pre-alarm	Sensor stress pre-alarm (see sensor monitoring configuration in the JUMO digiLine CR/Ci operating manual)
Sensor stress alarm	Sensor stress alarm (see sensor monitoring configuration in the JUMO digiLine CR/Ci operating manual)
Calibration timer expired	Alarm for sensor calibration due (see "Calibration data" in the JUMO digiLine CR/Ci operating manual)
Operating data acquisition alarm	Alarm for violation of allowed limits for operating data acquired for the sensor type (extreme conditions). You can find more on this in the operating manual for the JUMO digiLine CR/Ci.
Contamination alarm	Alarm for heavy contamination of 4-pin conductive conductivity sensors

JUMO digiLine O-DO H10/H20

Alarm	Explanation
Oxygen error flag	There is a fault with the oxygen sensor
Temperature error flag	There is a fault with the temperature sensor.
Switch-off temp. exceeded	When the specified switch-off temperature is exceeded, the oxygen measurement is automatically switched off. This protects the luminophore against premature aging and increases the operating life. This is particularly useful for CIP and SIP processes where no oxygen measurement is required.
Max. pulse reached	The number of oxygen measurements has exceeded the value that was defined as the limit value for the maximum number of measurements.
Cap missing	The sensor has detected that the sensor cap is missing.
Max. CIP exceeded	The number of CIP cycles since the last calibration has exceeded the value that was defined as the limit value for the maximum number of CIP cycles.
Max. SIP exceeded	The number of SIP cycles since the last calibration has exceeded the value that was defined as the limit value for the maximum number of SIP cycles.

JUMO digiLine O-DO S10

Alarm	Explanation
Oxygen error flag	There is a fault with the oxygen sensor
Temperature error flag	There is a fault with the temperature sensor.
Alarm sensor element	Sensor cap missing.
Oxygen outside the measuring range	The oxygen measured value is outside the sensor specification
Temperature outside the measuring range	The temperature measured value is outside the sensor specification
Sensor element warning status	The sensor cap is worn and should be replaced.

JUMO flowTRANS US W02 dL

Alarm	Explanation
Alarm, flow	**Possible causes:** Too many air bubbles in the system **or** the measuring range has been exceeded **or** the sensor is faulty.
Temperature alarm	**Possible causes:** The measuring range has been fallen below/exceeded **or** the sensor is faulty.
Alarm, pressure	
Empty conduit	The meter run is empty.
Air bubbles present	Air bubbles have been detected in the system.

JUMO ecoLine O-DO

Alarm	Explanation
Warning: Value out of spec	The measured value is out of the sensor specification
Warning: Measurement interrupted	The measurement process was interrupted
Error: Measurement impossible	Error due to measured values being outside sensor specification
Error: Membrane cap missing	Error due to missing membrane cap

JUMO ecoLine NTU

Alarm	Explanation
Warning: Value out of spec	The measured value is out of the sensor specification
Warning: Extraneous light	Warning: Measurement process disrupted by extraneous light
Error: Measurement impossible	Error due to measured values being outside sensor specification
Error: Extraneous light	Error in measurement process due to extraneous light

10.11.7 CIP/SIP definition for JUMO digiLine pH and JUMO digiLine CR/Ci

For sensor monitoring of JUMO digiLine pH and JUMO digiLine CR/Ci, the parameters listed in the following can set from the JUMO AQUIS touch P. They are used to count the CIP/SIP cycles in the JUMO digiLine electronics. You can find more on this in the operating manual for the JUMO digiLine pH or JUMO digiLine CR/Ci.

NOTE

Sensor monitoring requires plant-specific empirical values for the sensor stress caused by process conditions. Configure the sensor monitoring parameters on the basis of these empirical values.

Open CIP/SIP Definition Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > CIP/SIP Definition

Configuration point	Selection/ setting option	Explanation
CIP min. temperature[a]	-20 to+150 °C	Temperature thresholds for identifying CIP/SIP cycles If the CIP/SIP cycle takes place above one of these values during the set duration of a CIP/SIP cycle, the values identify a successfully completed CIP/SIP cycle and the CIP or SIP counter in the JUMO digiLine electronics is incremented. The respective counter is reset only after the value has dropped below the CIP/SIP temperature.
SIP min. temperature[a]		
CIP cycle duration[a]	60 to 65535 s	Minimum time to detection of a CIP/SIP cycle.
SIP cycle duration[a]		
CIP/SIP alarming	Inactive Active	Setting for alarming on the JUMO AQUIS touch P, if the CIP, SIP, or autoclaving counters in the JUMO digiLine electronics have reached the maximum number of permissible cycles.

[a] This setting is saved in the configuration of the JUMO digiLine electronics.

10.11.8 CIP/SIP definition for JUMO digiLine O-DO H10/H20

For sensor monitoring, the parameters listed in the following can set from the JUMO AQUIS touch P. They are used to count the CIP/SIP cycles in the sensor. The parameters can alternatively also be set with the DSM or setup program.

NOTE

Sensor monitoring requires plant-specific empirical values for the stress caused by process conditions. Define the sensor monitoring parameters on the basis of these empirical values.

Open CIP/SIP Definition Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > CIP/SIP Definition

Configuration point	Selection/ setting option	Explanation
CIP min. temperature	-20 to +150 °C	Temperature thresholds for identifying CIP/SIP cycles If the CIP/SIP cycle lasts longer than the set CIP/SIP duration between the minimum and maximum temperature, the values identify a successfully completed CIP/SIP cycle and the CIP or SIP counter in the JUMO digiLine electronic components is incremented. The respective counter is incremented only after the value has dropped below the CIP/SIP min. temperature.
SIP min. temperature		
CIP max. temperature	-20 to +150 °C	
SIP max. temperature		
CIP cycle duration	1 to 65535 min	Minimum time to detection of a CIP/SIP cycle.
SIP cycle duration		
Max. CIP cycles	0 to 65535	Specification of the maximum permissible CIP and SIP cycles.
Max. SIP cycles		
CIP/SIP alarming	Inactive Active	Setting for alarming on the JUMO AQUIS touch P, if the CIP, SIP, or autoclaving counters in the JUMO digiLine electronics have reached the maximum number of permissible cycles.

10.11.9 Calibration timer

Open Calibration Timer Settings Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Calibration Timer

Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together.
⇨ Chapter 10.13 "Calibration timer", page 201

10 Configuration

10.12 Limit monitoring and alarms

10.12.1 Limit value monitoring functions

Open Limit Monitoring:
Device Menu > Configuration > Limit Monitoring >
Limit Value Monitoring 1 to 8

Configuration point	Selection/ setting option	Explanation
Designation	Up to 21 text characters	Designation for the limit monitoring
Input signal	Selection from Analog selector	Signal source of the analog value that is monitored by limit monitoring
Alarms 1/2	Limit monitoring alarms are used to monitor any output signals with respect to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

10.12.2 Alarms for analog signals and digital sensors

Open Limit Monitoring Alarm Configuration:
Device Menu > Configuration > Limit Monitoring > Limit Monitoring 1 to 8

Open Temperature Inputs Alarm Configuration:
Device Menu > Configuration > Analog Inputs >
Temperature Inputs 1 to 2

Open Universal Inputs Alarm Configuration:
Device Menu > Configuration > Analog Inputs >
Universal Input 1 to 3 > Configuration

Open pH/Redox/NH_3 Analysis Inputs Alarm Configuration:
Device Menu > Configuration > Analog Inputs >
Analysis Input 1 to 4 > Configuration

Open CR / Ci Analysis Inputs Alarm Configuration:
Hold function
Device Menu > Configuration > Analog Inputs >
Analysis Input 1 to 4 > Configuration

Alarms
Device Menu > Configuration > Analog Inputs >
Analysis Input 1 to 4 > Configuration > Measuring Range 1 to 4

Open alarm configuration of measured values for digital sensors (all except JUMO digiLine CR/Ci):
Device Menu > Configuration > Digital Sensors >
Digital Sensors 1 to 6 > Configuration

Open alarm configuration of measured values for digital sensors of the type JUMO digiLine CR/Ci:

Hold function
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration

Alarms
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Measuring Range 1 to 4

Open Alarm Configuration For External Analog Inputs:
Device Menu > Configuration > External Analog Inputs >
External Analog Inputs 1 to 16

Open Alarm Configuration For Flow Rate:
Device Menu > Configuration > Flow Rate > Flow Rate 1 to 2

Configuration point	**Selection/ setting option**	**Explanation**
Digital signal for hold	Selection from the binary selector	Digital signal for activating the hold function When the hold function is activated, the alarm assumes the state defined in the "Response at hold" setting.
Response at hold	Inactive Active Frozen	Specification of the alarm state when the hold function is activated, at calibration of the particular input or at error (out of range) **Inactive:** Alarm suppressed **Active: A**larm forced **Frozen:** Alarm state is maintained regardless of alarm condition changes **Normal:** Alarm in acc. with alarm condition
Response at calibration	Inactive Active Frozen Normal	
Response at error	Inactive Active Frozen	
Alarm type	Inactive Minimum alarm Maximum alarm Alarm window Invert alarm window	Four alarm types (comparator functions) can be selected to monitor measured values for violation of limit values. ⇨ Characteristic lines after the table
	Only for CR analysis inputs: USP Pre-alarm USP Cleaned water Pre-alarm cleaned Water	Limit value alarms to USP <645> or European Pharmacopoeia (Ph. Eur.) for cleaned water
Alarm/Event list	Off Event Alarm	Assignment of alarm notification to alarm list or event list
Alarm text	Up to 21 text characters	Text for the alarm/event list
Limit value	-99999 to +99999	Limit value for the particular alarm type

Configuration point	Selection/ setting option	Explanation
Hysteresis	0 to 99999	Spacing between switch-on and switch-off points for the alarm types ⇨ Characteristic lines after the table
Window range	0 to 99999	Range of the alarm window ⇨ Characteristic lines after the table
Pulse function	Yes No	Time limit for alarm with the wiper time as maximum alarm duration
Pulse time	0 to 999 s	Duration of alarm with pulse function activated
Alarm delay On	0 to 999 s	Time delay between occurrence of the alarm condition and triggering of the alarm
Alarm delay Off	0 to 999 s	Time delay between ending of the alarm condition and clearing of the alarm

Minimum alarm (On-signal when value drops below lower limit)



Maximum alarm (On-signal when value exceeds upper limit)



Alarm window (On-signal within a configurable value range



Invert alarm window (On-signal outside a configurable value range)



10.12.3 Digital signal alarms

Open Alarm Configuration For Binary Inputs:
Device Menu > Configuration > Binary Inputs >
Binary Inputs 1 to 9

Open Alarm Configuration For External Binary Inputs:
Device Menu > Configuration > External Binary Inputs >
External Binary Inputs 1 to 16

Open Alarm Configuration For Logic Formula:
Device Menu > Configuration > Logic Formula > Formula 1 to 30

Configuration point	**Selection/ setting option**	**Explanation**
Digital signal for hold	Selection from the binary selector	Digital signal for activating the hold function When the hold function is activated, the alarm assumes the state defined in the "Response at hold" setting.
Response at hold	Inactive Active Frozen Normal	Specification of the alarm state when the hold function is activated **Inactive:** Alarm suppressed **Active: A**larm forced **Frozen:** Alarm state is maintained regardless of alarm condition changes **Normal:** Alarm in acc. with alarm condition
Alarm type	Active Inactive	Arming or disarming an alarm
Alarm/Event list	Off Event Alarm	Assignment of alarm notification to alarm list or event list
Alarm text	Up to 21 text characters	Text for the alarm/event list
Alarm active at	High Low	Digital input alarm condition
Alarm delay	0 to 9999 s	Time delay between occurrence of the alarm condition and triggering of the alarm

10.13 Calibration timer

Every input for analysis measurands has its own calibration timer. Inputs for temperature sensors do not have a calibration timer, since they do not need to be calibrated. Calibration timers signal when sensor calibration is due via a calibration alarm. Once a particular input has been calibrated successfully, its calibration timer is reset. The signal for a calibration due can be generated, for instance, by binary outputs with external indicator lights or the alarm/event list. The structure of the calibration timer configuration of types JUMO digiLine ORP, JUMO digiLine pH and JUMO digiLine CR/Ci differs from that of all other analysis sensors. In this case, there is only the "Calibration interval" parameter. Observe the following configuration table.

10.13.1 Configuration of the calibration timers

Open Calibration Timer Configuration Universal Inputs:
Device Menu > Configuration > Analog Inputs >
Universal Input 1 to 3 > Calibration Timer

Open Calibration Timer Configuration Analysis Inputs:
Device Menu > Configuration > Analog Inputs >
Analysis Input 1 to 4 > Calibration Timer

Open Calibration Timer Settings Digital Sensors:
Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Calibration Timer

Configuration point	Selection/ setting option	Explanation
Function[a]	Inactive Active	Activation/deactivation of the calibration timer for an analog input
Alarm/Event list[a]	Off Alarm Event	Assignment of calibration timer timeout notification to alarm list or event list
Alarm text[a]	21 text characters	Text for the alarm/event list upon timeout of calibration timers
Calibration interval[a]	0 to 9999 days	Time from one calibration to the next. When a calibration is due is indicated by the calibration alarm on the JUMO AQUIS touch P.

[a] For sensors with JUMO digiLine electronics of types JUMO digiLine-ORP, -pH, and -CR/Ci, only the calibration interval can be set. With these types, the calibration alarm is active automatically. The texts for alarm and event list are preset.

10 Configuration

10.14 Controller

10.14.1 Configuration of the controllers

Open: Device Menu > Configuration > Controller > Controller 1 to 4 > Configuration

Configuration point	Selection/ setting option	Explanation
Controller type	Two-point controller Three-state controller, Coarse-/fine controller, Modulating controller, Continuous Controller with Integrated Position Controller, Continuous controller	Selection of controller type
Control direction	Inverse Direct	**Inverse:** Output increases with negative control deviation (actual value < setpoint value), output decreases with positive control deviation **direct:** Output level increase with positive control the deviation (actual value >setpoint value), Output level decrease with negative control deviation
Output type 1 Output type 2	Pulse length output Impulse frequency output Continuous output	Signal type of controller output signal
Output contact type 1 to 2	Normally-closed contact Normally open contact	Contact type (control direction) of the binary controller outputs (K1,K2) Working contact corresponds to a normally-open contact Resting contact corresponds to a normally-closed contact
Manual mode	Enabled Disabled	Enabling of manual mode
Acceptance of manual output 1	Yes No	Acceptance of the preconfigured manual output level (for the 1st controller output on coarse-/fine controllers) upon activation of the manual mode
Man. output level 1	-100 to +100 %	Preconfigured manual output level (for the 1st controller output on coarse/fine controllers) Accepted automatically on activation of the "manual mode" if acceptance of the manual output level is set to "Yes". Otherwise, the controller accepts the last output level from the automatic control mode.

Configuration point	Selection/ setting option	Explanation
Acceptance of manual output 2	Yes No	**only for coarse/fine controllers:** Acceptance of the preconfigured manual output level for the 2nd controller output upon activation of the manual mode
Man. output level 2	0 to 100 %	**only for coarse/fine controllers:** Preconfigured manual output level for the 2nd controller output Accepted automatically upon activation of the manual mode if acceptance of the manual output level is set to "Yes"; otherwise the controller assumes the last output level from the automatic control mode.
Acceptance of hold output level 1	Yes No	Acceptance of the preconfigured hold output level (for the 1st controller output on coarse/fine controllers) upon activation of the hold mode
Hold output level 1	-100 to +100 %	Preconfigured hold output level (for the 1st controller output on coarse-/fine controllers) Accepted automatically on activation of the "manual mode" if acceptance of the manual output level is set to "Yes". Otherwise, the controller accepts the last output level from the automatic control mode.
Acceptance of hold output level 2	Yes No	**only for coarse/fine controllers:** Acceptance of the preconfigured hold output level for the 2nd controller output upon activation of the hold mode
Hold output level 2	0 to 100 %	**only for coarse/fine controllers:** Preconfigured hold output level for the 2nd controller output Accepted automatically upon activation of the hold mode if acceptance of the hold output level is set to "Yes"; otherwise, the controller assumes the last output level from the automatic control mode.
Autotuning	Enabled Disabled	Enabling of self-optimization
Alarm monitoring	Inactive Active	Activation/deactivation of alarm monitoring Alarm monitoring provides a continuous plausibility check of the control deviation. A dosing alarm is triggered when the control deviation is greater than the value of the alarm tolerance set in the controller parameters. If "Alarm ack." is activated (see next configuration item), the controller switches to hold mode on a holding alarm.

Configuration point	Selection/ setting option	Explanation
Alarm ack.	Inactive Active	Activation/deactivation of the acknowledgment function Dosing alarms of the respective controller must be acknowledged in the "Alarm list" when "Alarm acknowledgement" is activated. Dosing alarms are not cleared automatically when the control deviation drops to a value that is less than or equal to the alarm tolerance. The alarm tolerance is set in the controller parameters. ⇨ Chapter 9.2 "Parameter Sets (Controller parameter)", page 132.

Pulse length output

With a pulse width output, the output level generated by the controller has the form of the pulse/pause ratio of a square-wave signal with a fixed frequency (pulse width modulation). Output of this type of signal from the device uses a binary output.



Impulse frequency output

With a pulse frequency output, the output level generated by the controller has the form of the frequency of a square-wave signal with a fixed pulse/pause ratio. Output of this type of signal from the device uses a binary output.



Continuous output

With a continuous output, the output level generated by the controller is transmitted directly to connected functions. Output of this type of signal from the device uses a analog output. The proportionality between the min/max span of the controller output level and the signal strength is specified by the scaling of the analog output.

For more detailed information on the subject of control technology, you can download the technical article "Control Engingeering - Basic principles and tips for practitioners" (FAS 525) as a PDF document for free from the JUMO website.

10.14.2 Controller inputs

Open: Device Menu > Configuration > Controller > Controller 1 to 4 > Input

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation of the controller input
Actual value	Selection from Analog selector	Selection of the analog signal source for the actual value
Output level feedback signal	Selection from Analog selector	**only for modulating controller and continuous controller with integrated position controller** Selection of the analog signal source for the current output level (e.g. universal input with resistance transmitter or analog input with standard signal) On continuous controllers with an integrated position controller, output level feedback is necessary.
Parameter block switching	Selection from binary selector	Selection of the digital signal source for switching from parameter set 1 to parameter set 2 Two parameter sets are stored for each controller and can be switched via this digital signal. ⇨ Chapter 9.2 "Parameter Sets (Controller parameter)", page 132
Digital signal for manual	Selection from binary selector	Selection of the digital signal source to switch the controller to manual mode In addition to the button on the respective controller screen, it is also possible to activate manual mode with a digital signal (e.g. key switch for a digital input) binary signal.
Digital signal for hold	Selection from binary selector	Selection of the digital signal source to switch the controller to hold mode
Manual text	Up to 20 text characters	Text for the alarm/event list upon activation of manual mode
Alarm text	Up to 20 text characters	Text for the alarm/event list upon occurrence of a dosing alarm

10.14.3 Disturbance feedforward control

Open: Device Menu > Configuration > Controller > Controller 1 to 4 > Ena. variable disturbance

Configuration point	Selection/ setting option	Explanation
additive var. disturb.	Selection from Analog selector	Analog input for the additive variable disturbance The additive output componente Y_{add} is added to the output. This is calculated as follows: $Y_{add} = X \times [(Y_2 - Y_1) \div (X_2 - X_1)] + Y_1$  Y_{add}: Additive output level component X: Variable disturbance value X_1: Additive var. disturb. X start value X_2: Additive var. disturb. X end value Y_1: Additive var. disturb. Y start value Y_2: Additive var. disturb. Y end value
Additive var. disturb. X Start value	-99999 to +99999	Smallest value of the variable disturbance
Additive var. disturb. X End value	-99999 to +99999	Largest value of the variable disturbance
Additive var. disturb. Y Start value	-100 to +100 %	Additive output level component with largest variable disturbance value
Additive var. disturb. Y End value	-100 to +100 %	Additive output level component with largest variable disturbance value

Configuration point	Selection/ setting option	Explanation
Multiplicative Disturbance	Selection from Analog selector	Analog input for the multiplicative variable disturbance The ratio of the variable disturbance value at the working point of the variable disturbance is multiplied by the proportional gain of the controller. Changes in the variable disturbance affect the total gain of the controller. $K_{Tot} = K_p \times (X \div A)$ K_{Tot}: Total gain of the controller K_p: Proportional gain X: Variable disturbance value A: Working point
Working point	0 to 99999	Stationary variable disturbance value (variable disturbance value under steady-state, normal operating conditions of the system) If the variable disturbance equals the value of the working point (X = A), the following holds: $K_{Tot} = K_p \times 1$

10.14.4 Autotuning

Open: Device Menu > Configuration > Controller > Controller 1 to 4 > Self-optimization

Configuration point	Selection/ setting option	Explanation
Standby output	-100 to +100 %	Output level at start of self-optimization
Output level for step	10 to 100 %	Sudden output value increase issued by the controller as a test signal For automatic parameterization of the controller, the response (step response) of the process (section) is evaluated.
Transfer CY	Yes No	Acceptance of the switching cycle (C_y) for pulse width outputs from self-optimization into the controller parameters

10.15 Setpoint value configuration

Open: Device Menu > Configuration > Setpoint Value Configuration > Setpoint Value Configuration Controller 1 to 4

Configuration point	Selection/ setting option	Explanation
external Setpoint 1 to 2	Selection from Analog selector	Selection of the analog value as setpoint value source If external setpoint values 1 to 2 are selected, they replace setpoint values 1 to 2 of the controller parameters in the respective controllers. ⇨ Chapter 9.2 "Parameter Sets (Controller parameter)", page 132 With external setpoint values, the "Manual entry" button on the controller screen is hidden. ⇨ Chapter 8.5.1 "Automatic control mode", page 116
Signal Setpoint changeover	Selection from binary selector	Digital signal for switching from setpoint value 1 to Setpoint value 2 Binary value = 0 activates (external) setpoint value 1 Binary value = 1 activates (external) setpoint value 2
start Setpoint limit	-99999 to +99999	lower limit for setpoint values
End Setpoint limit	-99999 to +99999	upper limit for setpoint values

10 Configuration

10.16 Timer

Open timer: Device Menu > Configuration > Timer > Timer 1 to 12 > Timer

Configuration point	Selection/ setting option	Explanation
Timer function	Inactive Timer Control timer Control timer with run-time	Operating principle of the timer **Control timer:** Functions as weekly time switch Settings for a time program during the week ⇨ Chapter 10.16.1 "Control timer", page 212 **Timer:** Functions as timing element; the chrono-logical progression of the output signal can be flexibly matched to the application via the Nm. A detailed timing diagram follows this table.
Description	Up to 20 text characters	Timer designation
Response after Power off	Program stop Continue running Restart	Response of the timer upon interruption of the Voltage supply
Timer time	hh:mm:ss	Elapsed time from timer start until the timer generates the set binary value
Lead time Timer start		Delay time before the timer time starts
After-run time timer end	-1 to 32767 s	Time interval after timeout of the timer time Special feature: If the "After-run time after timer end" is set to the value -1, the time interval is infinitely long.
Signal Timer quit signal	Selection from binary selector	**only for "after-run time, timer end" > 0:** Binary signal for resetting the timer during the after-run time after timer end.
Timer start signal	Selection from binary selector	Digital signal to start the timer Retriggering with "Timer start" is possible only If the "Lead time" and the "Timer time" have timed out.
Output signal	High Low	Polarity inversion of the timer output signal **high:** the output signal is not polarity inverted. **low:** the output signal is polarity inverted.
Timer stop signal	Selection from binary selector	Digital signal to reset the timer
Timer hold signal	Selection from binary selector	Interrupts timer operation
Timer restart signal	Selection from binary selector	Binary signal to reset and restart the timer during the "Lead time" or "Timer time"

Configuration point	Selection/ setting option	Explanation
Signal Tolerance band x	Selection from Analog selector	Selection of an analog signal the deviation of which from the "Tolerance band w signal" is to be monitored The timer starts and continues running only if the amount of deviation is not greater than the set window range. If the deviation is greater than the window range, running timers are interrupted and timer start for timers that have not yet started is prevented. 
Signal Tolerance band w	Selection from Analog selector	Selection of the analog signal from which the "Tolerance band x signal" may not deviate by more than the "Window range" in order for the timer to run
Window range	0 to 99999[a]	maximum amount of deviation |x - w|
Enable wash event	Yes No	Activation/deactivation of event list entries with On-signal from "Timer start signal"
Event list text	Up to 21 text characters	Text for the event list with On-signal from "Timer start signal"

[a] The unit for the window range is obtained from the "Tolerance band x signal" parameter in this table.

Timing diagram



10.16.1 Control timer

Timer settings for a timed program during the week
Prerequisite: The "Timer function" must be configured as a "Control timer" or "Control timer with runtime".
⇨ Chapter 10.16 "Timer", page 210

Up to 4 Switch-on and Switch-off times can be specified separately for each weekday.
Open Switching Time Settings: Device Menu > Configuration > Timers > Timer 1 to 12 > Control Timer > Monday to Sunday

Configuration point	Selection/ setting option	Explanation
Switch-on times 1 to 4	hh:mm:ss	When the time passes the On-time, the control timer sets the binary value = 1 (switched on).
Switch-off times 1 to 4	hh:mm:ss	**only for "Control timer" (without runtime):** When the time passes the Switch-off time, the control timer sets the binary value = 0 (switched off).
Runtime	hh:mm:ss	**only for "Control timer with runtime":** Time during which the control timer with runtime has a binary value = 1 after the switch-on time; After the "Runtime" elapses, the binary value changes back to 0.

10.17 Washtimer

Open: Device Menu > Configuration > Washtimer > Washtimer 1 to 2

Configuration point	Selection/ setting option	Explanation
Washtimer active	Yes No	Activation/deactivation of the washtimer Washtimers are used to clean analysis sensors regularly and can actuate external equipment for cleaning sensors via binary outputs.
Designation	Up to 20 text characters	Timer designation
Time interval	0 to 999 h	Cycle of the automatically repeated sensor cleaning The interval time is restarted after the washing process (washing time + hold time after washing) has elapsed.
Washing time	0 to 999 min	Duration of sensor cleaning
Hold time after washing	0 to 999 s	After-run time of the washtimer hold signal upon timeout of the washing time The washtimer hold signal provides an On-signal for the duration of the washing time plus the hold time. The hold signal is intended primarily to activate the hold mode for controllers and analog outputs. These functions are held in a safe mode until the washed analysis sensor provides stable measured values once again.
Signal for interval restart	Selection from the binary selector	Binary signal to restart ongoing intervals
Signal for washing suppression	Selection from the binary selector	Binary signal for preventing a washing process from starting Washing processes that are already underway are not stopped by this signal.
Enable wash event	Yes No	Activation/deactivation of event list entries during sensor cleaning
Event list text	Up to 21 text characters	Text for the event list during sensor cleaning

10 Configuration

10.18 Counter

Open: Device Menu > Configuration > Counter > Counter 1 to 4

Configuration point	Selection/ setting option	Explanation
Function	Inactive Service counter Operating Hours Counter	Counter operation mode **Service counter:** The positive edges (switch-on operations) of a digital signal are counted (E.g. for checking the wear status of relays) **Operation hours counter:** The On-time of a digital signal is measured and the number of completed operating hours displayed.
Designation	Up to 20 text characters	Counter designation
Input signal	Selection from the binary selector	Digital signal, the switch-on operations or operating hours of which are to be counted
Alarm type Alarm/event list Alarm text	If a counter has reached its limit value, appropriate notifications can be configured for the alarm/event list. The alarm settings for all digital device functions are explained together. ⇨ Chapter 10.12.3 "Digital signal alarms", page 200	
Service count. limit value	0 to 99999	Alarm threshold for number of positive edges (activations)
Operating hours counter limit value	0 to 99999 h	Alarm threshold for the number of operating hours

10.19 Recording

10.19.1 Parameter

Call up: Device Menu > Configuration > Recording > Group 1 to 4 > Parameter

Configuration point	Selection/ setting option	Explanation
Status	Switched off Display and save	Activate / deactivate the recording group
Designation	Up to 20 text characters	Group designation
Diagram header	Yes No	Display or hide the diagram header in the group ⇨ Chapter 8.6.1 "Data monitor/recording function control elements", page 122
Perforation	Yes No	Display or hide a visualized perforation strip in the recorder diagram of the recording group ⇨ Chapter 8.6.1 "Data monitor/recording function control elements", page 122
Show binary chann.	Yes No	Display or hide the binary traces in the group ⇨ Chapter 8.6.1 "Data monitor/recording function control elements", page 122
Memory values	Average value Current value Minimum value Maximum value	Selection of the measured value arithmetic for the measured value recording of the recording group
Memory cycle	1 to 3600 s	Length of the recording interval in the recording group

10.19.2 Analog channels

For each recording group, up to 4 analog channels with 1 analog signal each can be set up for recording and visualization in the recorder diagram of the recording group.
Call up: Device Menu > Configuration > Recording > Group 1 to 4 > Analog channels 1 to 4

Configuration point	Selection/ setting option	Explanation
Analog channels	Selection from the analog selector	Selection of an analog signal, for the analog channel
Designation	Up to 20 text characters	Designation of the analog channel
Line width	Thin Thick	Selection of the line thickness for displaying the measured value trend in the recorder image

10.19.3 Binary channels

For each recording group, up to 3 binary channels with 1 binary signal each can be set up for recording and visualization in the binary traces of the recording group. Please note that binary traces in the recording group are only visible if the "Show binary chann." parameter is set to "yes".
⇨ Chapter 10.19.1 "Parameter", page 215
Call up: Device Menu > Configuration > Recording > Group 1 to 4 > Binary channels 1 to 3

Configuration point	Selection/ setting option	Explanation
Binary channels	Select from the binary selection	Selection of a binary signal for the binary channel
Designation	Up to 20 text characters	Binary channel designation

10.20 Ethernet

The Ethernet settings must be requested from the administrator of the network in which the device is installed.

Open: Device Menu > Configuration > Ethernet

Configuration point	Selection/ setting option	Explanation
Config. IP address	Manual Automatic	**manual:** If no DHCP server is installed or a dedicated IP configuration is desired and the IP address configuration is known (e.g. from the network administrator), the data can be entered manually. **automatic:** A DHCP server is installed in the network. During power-up and booting, the JUMO AQUIS touch P receives the IP configuration from the DHCP server; the IP configuration takes place automatically.
Manual IP address	Valid IP address[a]	IP configuration of the Ethernet optional board Manual entry of known configuration data or automatic configuration by the DHCP server (see configuration item "IP address assignment")
Subnet mask	Valid subnet mask[a]	
Standard gateway	Valid IP address[a]	
DNS server	Valid IP address[a]	
Transfer rate	Automatic 10 Mbit/s half duplex 10 Mbit/s full duplex 100 Mbit/s half duplex 100 Mbit/s full duplex	Transmission speed (bit rate) and duplex mode of the Ethernet optional board This setting must match the setting of the switch or router port to which the JUMO AQUIS touch P is connected.

[a] To enter an IP configuration manually for the JUMO AQUIS touch P, a valid available IP address in the network must be known. Please contact your network administrator in this regard.

NOTE

The Ethernet settings are entered in the online parameters in the JUMO PC setup program.
The IP configuration of the device can also be changed from the PC if the PC and device are connected via Ethernet. In this case, changing the IP address or subnet mask can interrupt the PC-device connection.
⇨ Chapter 22.10.3 "Ethernet", page 408

NOTE
The JUMO AQUIS touch P can act as a Modbus master and send configurable Modbus frames to slave devices in configurable cycles.
You can find further information on Modbus frames and the Modbus master function in the Modbus description of the JUMO AQUIS touch P.

10.21 Serial interfaces

Open: Device Menu > Configuration > Serial Interfaces > Serial Interfaces 1 to 2

Configuration point	Selection/ setting option	Explanation
Protocol	Modbus slave Modbus master Modbus digital sensors	Communication protocol of the bus system **Modbus Slave:** For operation of the device as a slave in a Modbus system **Modbus master:** For operation of the device as a master in a Modbus system, for example for querying measured values from sensors with a Modbus slave function. You can find further information on this in the Modbus interface description for the device. **Modbus digital sensors:** For operation of JUMO digital sensors on the serial interface (see order details for extra code "JUMO digiLine protocol activated") In the JUMO AQUIS touch P, either the interface on the base unit or the optional serial interface (if present) can be configured for digital sensors (JUMO digiLine operation). Simultaneous use of both interfaces for JUMO digiLine operation is not possible.

Configuration point	Selection/ setting option	Explanation
Baudrate	9600 19200 38400	Transmission speed (symbol rate) of the serial interface[a] For all bus users (device and digital sensors) to communicate with one another, they must have the same baud rate. The baud rates of JUMO tecLine and JUMO digiLine sensors are automatically set by the JUMO digiLine master device during the scanning process. When connecting **digital JUMO ecoLine sensors**, the **baud rate** of the JUMO AQUIS touch P must be set to **9600** prior to startup. Otherwise, the sensors will not begin operation. **supported baud rates of JUMO digital sensors** • JUMO ecoLine: 9600 • JUMO tecLine and JUMO digiLine: 9600,19200, 38400
Data format	8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity	Format of the data word[a] For all bus users (device and digital sensors) to communicate with one another, they must have the same data format. The data formats of JUMO tecLine and JUMO digiLine sensors are automatically set by the JUMO digiLine master device during the scanning process. When connecting **digital JUMO ecoLine sensors**, the **data format** of the JUMO AQUIS touch P must be set to "**8-1-no parity**" prior to startup. Otherwise, the sensors will not begin operation. Format: Useful bit – stop bit – parity bit
Min. response time	0 to 500 ms	Minimum time from receiving a query to sending a response This parameter is used to adjust the response speed of the device to slower bus users.

Configuration point	Selection/ setting option	Explanation
Modbus slave		
Timeout master	60 to 60000 ms	Master monitoring time After this time, a failure of the Modbus master is identified. An internal digital signal is set in the event of a timeout.
Device address	1 to 254	Unambiguous specification of a bus participant
Modbus master		
Timeout	60 to 10000 ms	A request sent by the master is defined as faulty if no answer is received within this time.
Scan cycle	60 to 99999 ms	The Modbus master requests data from the Modbus slaves at these intervals.

[a] For all users to communicate with one another, these setting be the same on all users.

10.22 Modbus TCP

Open: Device Menu > Configuration > Modbus TCP

Configuration point	Selection/ setting option	Explanation
Modbus slave		
Port	0 to 1024	TCP port of the JUMO AQUIS touch P as a Modbus slave. The change to the TCP port for the slave function must be made with the JUMO setup program. In the **delivery state,** the **TCP port number "502"** is configured.
Modbus master		
Timeout	4000 to 10000 ms	A request sent by the master is defined as faulty if no answer is received within this time.
Scan cycle	60 to 99999 ms	The Modbus master requests data from the Modbus slaves at these intervals.
External devices (device 1 to 4)[a]		
Manual IP address	Valid IP address[b]	IP address of the Modbus slave device
Port	0 to 1024	TCP port of Modbus slave device

[a] Settings for up to 4 target slave devices to which the JUMO AQUIS touch P is to send its Modbus commands are created for the Modbus master function of the JUMO AQUIS touch P via Ethernet. It can be selected as the target device for the respective Modbus frame in the settings of the Modbus frames.

[b] IP addresses must be unique within a network. Consult your network administrator for a valid IP address configuration.

10.23 Formula

Mathematical formula are created with the JUMO PC setup program and loaded to the device. The configuration of a formula can then also be edited on the device itself.

Open: Device Menu > Configuration > Mathematical Formula > Formula 1 to 16

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Formula designation
Temperature	None Relative Absolute	For automatic conversion of temperature units, it is necessary to know whether the calculated result is an **absolute temperature** (temperature value on the Celsius scale) or a **relative temperature** (temperature difference in °C). If the result of the calculation not a temperature, **"none"** must be set here.
Unit	Up to 5 text characters	**Entry of the unit for temperatures inactive:** Unit for the output value of the mathematical formula (calculation result)
start Display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale For representation of measured values as recorder diagrams and bar graphs
End Display range	-99999 to +99999[a]	
Response at error	No output Replacement value	Control of value output for error (E.g. division by zero). The value in the configuration item "Value for error" serves as substitute value.
Value for error	-99999 to +99999[a]	Safety value for the output of a mathematical formula for error
Secure using power OFF	Yes No	Nonvolatile storage of the calculation If "Yes" is set here, the formula last calculated before the device was switched off will be saved. Once the device is switched back on, the calculation will start with the saved value and continue with the current value in real time.

[a] The unit set for the particular mathematical formula appears in the entry field.

10.24 Logic formula

Logic formula are created with the JUMO PC setup program and loaded to the device. Following this, the configuration of a logic formula can also be edited
directly on the device.

Open: Device Menu > Configuration > Logic Formula > Formula 1 to 30

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Logic formula designation
Alarm type	Corresponding notifications for the alarm/event list can be configured for the event list. The alarm settings for all digital device functions are explained together. ⇨ Chapter 10.12.3 "Digital signal alarms", page 200	
Alarm/Event list		
Alarm text		
Alarm delay		
Digital signal for hold		
Response at hold		

10.25 Manual values (configuration)

Open: Device menu > Configuration > Manual Values (config.) > Manual Value (config.) 1 to 16

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation of the manual value
Temperature	None Relative Absolute	For automatic conversion of temperature units, it is necessary to know whether the manual value is an **absolute temperature** (temperature value on the Celsius scale) or a **relative temperature** (temperature difference in °C). If the manual value not a temperature, **"none"** must be set here.
Unit	Up to 5 text characters	**Entry of the unit for temperatures inactive:** Unit for the manual value
Comma format	Auto Fixed decimal place format	Decimal points in the display
start Display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range	-99999 to +99999[a]	

[a] The unit set for the particular manual value appears in the entry field.

10.26 External analog inputs

Open: Device Menu > Configuration > External Analog Inputs > External Analog Inputs 1 to 16

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation of the external analog input
Temperature	None Relative Absolute	For automatic conversion of temperature units, it is necessary to know whether the analog value received via the external analog input is an **absolute temperature** (temperature value on the Celsius or Fahrenheit scale) or a **relative temperature** (temperature difference). If this analog value is not a temperature, **"none"** must be entered here.
Unit	Up to 5 text characters	Unit for the analog value received via the external analog input
Comma format	Auto Fixed decimal place format	Decimal points in the display
start Display range	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range	-99999 to +99999[a]	
Hold value	No Yes	Nonvolatile storage of the last analog value received when the device restarts
Alarms 1/2	Alarms for external analog inputs are used to monitor analog values received via the individual external analog inputs in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

[a] The unit set for the particular manual value appears in the entry field.

10.27 External digital inputs

Call up: Device Menu > Configuration > External Digital Inputs > External Binary Inputs 1 to 16

Configuration point	Selection/ setting option	Explanation
Designation	Up to 20 text characters	Designation of the external digital input
Hold value	No Yes	Nonvolatile storage of the last binary value received when the device restarts
Alarm	Alarms for external digital inputs are used to monitor input-side binary signals. The alarm settings for all digital device functions are explained together. ⇨ Chapter 10.12.3 "Digital signal alarms", page 200	

10.28 Flow

Open: Device Menu > Configuration > Flow Rate > Flow Rate 1 to 2

Configuration point	Selection/ setting option	Explanation
Input type	Inactive Digital input 2 Digital input 3 Analog input	Selection of the signal source for the flow rate measurement **Digital input 1/2:** Pulse frequency signals via Digital inputs **Analog input:** An analog signal is specified in the configuration item "Analog signal".
Designation	Up to 20 text characters	Designation of the flow rate function
Analog signal	Selection from Analog selector	**only for "Analog input" as "Input type":** Selection of the analog signal source as the flow rate signal
Measuring principle	Period measurement 3 to 300 Hz Pulse counting 300 Hz to 10 kHz	**only for "Digital input 2/3" as "Input type":** Measurement method for determining the flow rate Pulse frequency signals are provided by paddlewheel sensors, for instance.
Time base	0 to 9999 s	**only for "Pulse counting" as "Measuring principle":** Duration of a counting segment The pulses counted within a counting segment divided by the time base yields the pulse frequency value. With a setting of 0 s, the time base is 250 ms.

Configuration point	Selection/ setting option	Explanation
K-factor	0 to. 99999 l^{-1}	Ratio of the pulse count to flow rate (pulses per liter) The K-factor can be obtained from the documentation for the fitting in which the flow rate sensor (e.g. paddle wheel sensor) is installed. If the flow rate signal is transmitted as a standard signal or via an interface (external analog inputs), be aware that the K-factor affects analog values as well. For reliable handling of the flow rate as an analog signal, it is recommended that the flow value be generated as a standard signal and the K-factor set to a value of 1.
Unit	l / s l / min l / h m^3 / s m^3 / min m^3 / h gal / s gal / min gal / h Customer-specific	Unit for the flow rate value **Customer-specific unit:** In the individual measured display, the flow value in liters per second is multiplied by the factor from the "Conversion factor" setting and the unit displayed on the basis of the " Unit description" setting.
Conversion factor (flow)	-99999 to +99999	only for "customer-specific" as "Unit": Conversion factor from the unit "l / s" for the flow to the customer-specific unit
Unit description (flow)	Up to 5 text characters	**only for "customer-specific" as "Unit":** Entry of an arbitrary customer-specific unit for the flow rate
Comma format (flow)	Auto, Fixed decimal place format	Decimal points in the display
start Display range (flow)	-99999 to +99999[a]	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range (flow)	-99999 to +99999[a]	

Configuration point	Selection/ setting option	Explanation
Total quantity	Off Hourly Daily Weekly Monthly Annual Unlimited	**only available with flow measurement activated:** Activation of the flow rate quantity counter The setting establishes the automatic reset cycle. In addition, the flow rate quantity counters can be reset manually at the functional level or via a digital signal (reset input). The last counter state is saved during resetting and is available in the analog selection as "Total quantity - Periods 1/2".
Reset input	Selection from binary selector	**only for "unlimited" as "Total quantity":** Digital signal for resetting the current counter state
Conversion factor (totalized flow rate)	-99999 to +99999	**only for "customer-specific" as "Unit":** Conversion factor from the unit "l" for the flow rate quantity to the customer-specific unit
Unit designation (totalized flow rate)	Up to 5 text characters	**only for "customer-specific" as "Unit":** Entry of an arbitrary customer-specific unit for the flow rate quantity
Comma format (totalized flow rate)	Auto, Fixed decimal place format	Decimal points in the display
start Display range (totalized flow rate)	-99999 to +99999[b]	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range (totalized flow rate)	-99999 to +99999[b]	
Alarms 1/2	Flow rate function alarms are used to monitor flow values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇨ Chapter 10.12.2 "Alarms for analog signals and digital sensors", page 196	

[a] The unit set for the particular flow rate function appears in the entry field.
[b] The unit set as the flow rate for the particular flow function appears in the entry field.

11.1 Installing optional boards

DANGER!
Installation and removal of optional boards must be performed only by qualified personnel. To ensure electrical safety, country-specific regulations must be observed.

CAUTION!
Optional boards must be carefully inserted into the SMK plug connections on the device's motherboard without tilting. Failure to do this can cause the SMK plug connections on the device's motherboard to break off. This applies in particular for the optional board of the COM 2 slot (serial interface RS422/485 and PROFIBUS-DP). In order to avoid damage:

- always use the plastic board frame provided
- Carefully slide the plastic board frame with the optional board into the slot without tilting
- Apply uniform pressure to insert into the SMK plug connection on both sides of the optional board front and do not tilt.

The following step-by-step table explains in detail the procedure for retrofitting optional boards:

Step	Action
1	Disconnect all phases of the power being supplied to the device (power grid, outside power supply sources for relays/solid-state relays etc.).
2	Identify the optional board from the part number on the sticker attached to the packaging as well as from the connection socket and the accessories table. ⇨ Chapter 4.4 "Accessories", page 27   Using the block diagram, select a suitable slot for the optional board. ⇨ Chapter 3.2 "Block diagram", page 21

Step	Action
3	Disconnect all screw terminals and interface cables connected at the rear of the device. To prevent connections being interchanged, note down the assignment of the connectors to the sockets. 
4	Undo (do not remove) the two countersunk screws on the bottom of the case and remove the pan head screw on the side of the case. 
5	Now open the rear panel of the case and remove it. 

Step	Action
6	Insert the optional board into the selected slot straight and without tilting. Apply uniform pressure to insert at the right and left corners of the optional board front and allow it to engage gently into the SMK plug connection. Ensure that the board is seated correctly. For better guidance of the board, you can fill empty slots with plastic board frames. 
7	Fill all empty slots with plastic board frames.
8	Reinsert the rear panel of the case and fasten with 3 screws. Make sure that all the toothed lock washers for securing the screws are re-inserted (see Step 4). The screws represent the protection conductor connection to the rear panel of the case.
9	Reinsert all the plug-in screw terminals and interface cables that were removed in Step 3 into the correct sockets. For "Ci analysis input" optional boards (inductive conductivity), continue at Step 10; otherwise, at Step 12
10	Connect the inductive conductivity sensor using the M12 socket adapter from the scope of delivery of the Ci optional board to the Ci optional board of the device.
11	Connect the 2-wire temperature sensor cable of the M12 socket adapter to an appropriate analog input (e.g. temperature measurement input). Observe the information regarding the integrated temperature sensor in the conductivity sensor.
12	Now, reconnect the power supply and check whether the new hardware has been recognized. ⇨ Chapter 7.3.1 "Checking the optional boards", page 77
13	Only for Ci optional boards (inductive conductivity): Perform a Ci base calibration. ⇨ Chapter "Performing the Ci base calibration", page 231
14	Only for optional boards for analysis inputs: Calibrate the analysis inputs. ⇨ Chapter 12 "Calibration in general", page 235

11 Retrofitting optional boards

11.2 Ci base calibration

Analysis inputs for inductive conductivity sensors must undergo a Ci base calibration during startup. A Ci base calibration must be performed when:

- A new sensor or a new Ci optional board is being installed for the first time
- The sensor or a Ci optional board was replaced
- A Ci optional board was repositioned to a different optional board slot
- Data loss occurred as the result of failure of the buffer battery while the power was switched off
- Device software was updated

After the basic calibration has been performed, the measurement input can be calibrated. Following successful calibration, the measurement input is ready for use.



NOTE
For the Ci base calibration, you need the JUMO Type 202711/21 calibration adapter for inductive conductivity sensors (TN 00543395).



CAUTION!
A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

Performing the Ci base calibration

Step	Action
1	Ensure that you have user rights for calibration settings. The default settings authorize the "Master" and "Service" users for this. ⇨ Chapter 8.1.1 "Passwords and user rights", page 79
2	Ensure that the electronics of the JUMO AQUIS touch P have reached operating temperature. You can view the board temperature at: Device Menu > Service > Service Data > "Internal Data" tab Ensure that the ambient temperature specified for the device corresponds to the conditions for the normal operating mode. Wait until the board temperature has reached an approximately constant value.
3	Place the sensor such that the sensor body is suspended freely in air. Observe the following rules during the entire calibration: • Keep all objects away from the sensor body • Do not touch the sensor body • Do not allow the sensor body to lie flat on a surface  Sensor body of a Ci sensor

Step	Action
4	Place the wire of the calibration sensor with 2 windings through the opening in the Ci sensor without connecting the ends of the wires. 
5	Start the Ci base calibration Device menu > Calibration > Select Ci Analysis Input > Ci Base Calibration
6	Enter the cell constant for the sensor and confirm by pressing "OK". Tap button to enter field 
7	The device now performs a measuring with the open cable loop of the calibration adapter open. Wait until the measured value displayed stabilizes and then confirm by pressing "OK". 

Step	Action
8	Connect the ends of the wires forming the conductor loop of the calibration adapter. 
9	Set the calibration adapter to the resistance value shown in the instruction text in the display (in the example: 20 kΩ). Once the measurement displayed has stabilized, confirm by pressing "OK". Instructions instructions 
10	Now follow the instructions on the display. You will be requested to set certain resistance values on the calibration adapter one at a time and then to confirm each measuring by pressing "OK". All resistance value set on the calibration adapter are measured for the end of one measuring range and the beginning of the following measuring range. Each resistance value will thus be confirmed 2 times. Only the last measuring will be confirmed 1 time.

Step	Action
11	Once all measurements have been confirmed, a summary of the calibration data acquired appears. Confirm by pressing "OK". If the Ci base calibration fails, the procedure is canceled without acceptance of the calibration data. Protocol after successful Ci base calibration  Protocol after failed Ci base calibration 
12	Accept the calibration data acquired by pressing "Yes"; discard the data by pressing "No".

12.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

12.2 General information

The actual electrical characteristics of analysis sensors always deviate somewhat from the nominal specifications. The reasons for this include:

- Like every measuring instrument, analysis sensors always have a certain uncertainty of measurement that results from manufacturing tolerances.
- During use, analysis sensors are exposed to chemical processes. Deposits and wear phenomena caused by these processes result in changes of the electrical characteristics of sensors.

To optimize the accuracy of measurements, analysis sensors must be calibrated. Calibrations are required:

- during installation or when changing a sensor
- regularly at time intervals that must be specified by the user
- if implausible measured values are displayed
- if process conditions change, e. g. as the result of equipment modification

Calibration timers can be configured to provide a regular reminder of when calibrations are due.
⇨ Chapter 10.13 "Calibration timer", page 201

Each successfully completed calibration is recorded in the calibration logbook.
⇨ Chapter 12.3 "Calibration logbook", page 237

12.2.1 General procedure for calibration

True calibration (calibrating with routines)

After opening one of the calibration routines in the device, the user is guided through a process with measurements and entries. In the course of this process, the calibration values are determined and saved automatically.
Suitable calibration routines are available for every type of analysis sensor. The individual calibration routines for the various sensor types are described in separate chapters.

⇨ Chapter 13 "Calibrating a pH measuring chain", page 241 to ⇨ Chapter 17 "Calibrating Ci conductivity sensors", page 269

Execution of calibration routines requires that the following prerequisites be met:

- You must be logged in as a user with the right to perform calibrations. Factory-preset users have all of these rights.
  ⇨ Chapter 8.1.1 "Passwords and user rights", page 79
- You must ensure that the calibration default settings for the individual analysis inputs , and, possibly, the universal inputs are set correctly. The explanations of the calibration default settings can be found in the chapters on calibration of the various analysis sensors.
- In the case of Ci analysis inputs, it should be noted that the optional boards must undergo a basic calibration during the initial commissioning. If this has not yet been performed, it is necessary to do so prior to any other calibration.

⇨ Chapter 11.2 "Ci base calibration", page 230

Manual entry of calibration values

NOTE
Incorrectly entered calibration values result in incorrect measured values. Correct measurements are essential for control systems and limit monitoring.

If calibration values are known, they can also be entered manually. This may be the case with temperature-compensated conductivity measurements, for instance, when the temperature coefficient of a liquid is known. Another important application case is the manual entry of relative cell constants of conductivity sensors. If an ASTM test certificate showing precisely-measured cell constants is available, in addition to entering the nominal cell constants in the configuration of the conductivity sensor concerned, the relative cell constants of all measuring ranges in the calibration values must be manually entered.
Configuration of conductivity sensors:
⇨ Chapter 10.5.6 "CR/Ci analysis inputs (conductive/inductive conductivity)", page 152
⇨ Chapter "Only for sensors with JUMO digiLine CR/Ci", page 169

Known calibration values are entered manually under:

Device menu > Calibration > Select Analog Input or Digital Sensor > Calibration Values

12.3 Calibration logbook

A separate logbook is kept for each input that has been configured for an analysis sensor (analysis inputs, universal inputs or inputs for digital sensors).

The last 10 **successful** calibrations of the input concerned are saved in the calibration logbook. Canceled or failed calibrations (calibrations outside the permissible limits) are not saved in the logbook, but rather noted in the event list. Manual changes of calibration values on the device are also documented. The following data are retained in the logbook:

- Heading with description of the measurement input and calibration method
- Date and time
- Measurand
- Calibration assessment (assessment of the calibration values determined during the true calibration)
- Calibration values determined or entered
- Reference values used
- Calibration mode (true calibration/manual entry of calibration values)

Since this information does not yet fit in a screen line, the logbook entries are listed in abbreviated form with the date and calibration results for the time being. More exact information can be accessed for every entry via the detail view.

Example of a calibration logbook



Calibration assessment symbols

✔	Calibration values are valid: Sensor is OK
	The calibration values determined are critical. It is recommended that the sensor be cleaned.
	Manual value input

For Ci analysis inputs (inductive conductivity) and universal inputs that have been configured as a conductivity measurement input, a "TC curve" button is also displayed. Tapping this button opens a list with the temperature coefficients determined from the last "TC curve calibration".



Example of a detail view of a logbook entry

The calibration logbook provides an overview of the calibrations performed. Tapping the "Details" button opens the selected logbook entry in the detail view. The detail view displays a table with all calibration values from a calibration procedure. The "Service" button is used for diagnostic purposes by trained personnel or JUMO Service.



Assessment criteria

pH calibrations
(glass electrodes and ISFET connected to analysis measuring inputs as well as standard signals connected to universal inputs)

Calibration value [unit]	—				🔔		✔		🔔				—
Zero point [pH]	...	<	5	≤	...	<	6 to 8	<	...	≤	9	<	...
Slope [%]	...	<	75	≤	...	<	89.6 to 103.1	<	...	≤	110	<	...

pH calibrations (antimony electrodes connected to analysis measuring inputs)

Calibration value [unit]	—		✔		—
Zero point [pH]	...	<	-2 to +2	<	...
Slope [%]	...	<	10 to 110	<	...

Redox zero-point calibration

Calibration value [unit]	—				🔔		✔		🔔				—
Zero point [mV]	...	<	-200	≤	...	<	-120 to +120	<	...	≤	+200	<	...

NOTE
There is no assessment of the calibration values in the case of a redox 2-point calibration.

Ammonia calibration

Calibration value [unit]	—				🔔		✔		🔔				—
Zero point [mV]	...	<	-612	≤	...	<	-312 to +588	<	...	≤	+888	<	...

12 Calibration in general

Calibration of conductivity sensors
(analysis measuring inputs and standard signals connected to universal inputs)

Calibration value [unit]	—														—
Rel. cell constant (CR) [%]	...	<	50	≤	...	<	75 to 125	<	...	≤	150	<	...
Rel. cell constant (Ci) [%]	...	<	80	≤	...	<	90 to 110	<	...	≤	120	<	...

Calibration value [unit]	—				—
Temperature coefficient (CR) [%/K]	...	<	0 to 8	<	...
Temperature coefficient (Ci) [%/K]	...	<	0 to 5.5	<	...

NOTE
No assessment of the calibration values is performed for universal inputs in the "linear scaling" operation mode.

Calibration of conductivity sensors with JUMO digiLine CR/Ci

Calibration value [unit]	—														—
Rel. cell constant (CR) [%]	...	<	50	≤	...	<	75 to 125	<	...	≤	150	<	...
Rel. cell constant (Ci) [%]	...	<	80	≤	...	<	90 to 110	<	...	≤	120	<	...

Calibration value [unit]	—				—
Temperature coefficient (CR) [%/K]	...	<	0 to 8	<	...
Temperature coefficient (Ci) [%/K]	...	<	0 to 6	<	...

13.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

13.2 General information

The calibration of pH electrodes is based on measurements in buffer solutions with a defined pH-value. The pH values of the buffer solutions used are specified either via entry of fixed values into the calibration default settings, entered during the calibration or recognized automatically by "automatic buffer recognition" during the calibration process. For "automatic buffer recognition", a buffer set table must be selected in the calibration default settings. In this case, the buffer solutions used must be listed in the provided buffer set table. Since pH value measurement of liquids is temperature-dependent, the temperature of the buffer solution must be sensed in order to compensate for its effect on the result of the measurement. This requires either manual entry or measurement with the aid of a temperature sensor.

13.2.1 Calibration methods for pH sensors

Zero-point calibration

This calibration method is used to determine the pH zero point on the measurement characteristic curve. The slope is retained.

A buffer solution with a defined pH value is needed as a reference.

Two-point Calibration

By measuring 2 different buffer solutions with defined pH values, the pH zero point and pH slope of the measuring chain are established.

The pH values of the buffer solutions must be at least 2 pH apart. This calibration method is recommended for most applications.

Three-point calibration

With a three-point calibration, the pH zero point as well as the pH slope in the acidic region and the pH slope in the alkaline region are established. The three-point calibration can be performed only for pH sensors on analysis inputs. It is not available for JUMO digiLine pH sensors.

This method requires 3 buffer solutions with defined pH-values as references. One of these must be acidic, one neutral and one alkaline. The pH values of the buffer solution must be at least 2 pH apart from one another. This calibration method is recommended for applications with more demanding accuracy requirements when performing measurements in both the alkaline and acidic regions.

13.2.2 Calibration default settings for pH sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the pH Calibration are described in the following.

Open the calibration default settings:
Device Menu > Calibration > Select Analysis Input or Digital Sensor Input for pH/redox/NH3 > Calibration Presets

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in. The "Calibration default settings" menu for a digital sensor is visible for the digital sensor concerned only when it is linked.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
⇨ Chapter 8.2.7 "Digital sensors", page 99

Sample screen:
pH calibration default settings



pH calibration default settings

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
Additional calibration default settings are explained in the following table.

Parameter	Possible settings	Explanation
Buffer set selection	Buffer set 1 to 3 factory-preset: • **Buffer set 1:** Reference buffer solutions for calibrating pH measuring instruments acc. to DIN 19266 • **Buffer set 2:** Technical buffer solutions, preferably for calibrating and adjusting technical pH measuring instruments acc. to DIN 19267	Buffer set tables contain pH values for selected buffer solutions as a function of temperature. These tables can be prepared/edited using commercially available standard solutions (DIN 19266, NIST; otherwise, technical buffer solutions etc.) or on the basis of customer-specific information. With their aid, buffer solutions can be recognized automatically when calibrating. The pH value data for the buffer solutions used must be contained in the buffer set table selected. When a Buffer set is selected, this activates automatic buffer recognition and the entry fields for the settings "pH buffer 1 to 3" are hidden. You need the JUMO PC setup program to edit buffer set tables.
Buffer 1 pH-value	-2 to +16 pH	manual entry of the pH-values of the buffer solutions being used for the calibration Depending on the selected Calibration routine, the corresponding entry fields for "pH buffer 1 to 3" are displayed. The pH-values of the buffer solutions used must be at least 2 pH apart.
Buffer 2 pH-value	-2 to +16 pH	
Buffer 3 pH-value	-2 to +16 pH	
Compensation	Fixed compensation temperature Temperature input Interface	**Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Temperature input:** The integrated temperature probe of the pH sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".

Parameter	Possible settings	Explanation
Temperature compensation	Selection from Analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration

13.3 pH Calibration routines

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

NOTE
Digital sensors need to be linked before they can be calibrated.
⇨ Chapter 8.2.7 "Digital sensors", page 99

13.3.1 Zero-point calibration

Step	Action
1	Start the Zero-point calibration. **for pH sensors on analysis inputs:** Device Menu > Calibration > Select Analysis Input for pH/redox/ NH_3 > Open Zero-Point Calibration **for pH sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > Open Zero-Point Calibration
2	If temperature compensation was not specified in the calibration default settings, enter the temperature of the buffer solution here manually. If temperature compensation was specified, the temperature of the buffer solution is determined automatically. tap button to enter temperature 
3	Clean the pH electrode and immerse it in the buffer solution.

Step	Action
4	**Entry of the pH-value of the buffer solution** • **without buffer recognition:** Check whether the "pH buffer 1" matches the pH-value of the buffer solution used. If a buffer set table was not specified, the "buffer 1 pH" value is taken from the calibration default settings. It is still possible to change this manually here. tap button to enter pH-value of the buffer field  • **with buffer recognition:** A prerequisite here is that a buffer set table has been selected in the buffer set table and the pH-value of the buffer solution used is contained in this buffer set table. If these prerequisites are satisfied, the pH value of the buffer solution is determined automatically during the calibration.
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
6	A Protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
7	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

13.3.2 Two-point and three-point calibration

Step	Action
1	Start the desired Calibration routine. **for pH sensors on analysis inputs:** Device Menu > Calibration > Analysis Input Select Analysis Input for pH/redox/NH_3 > Open Two-Point or Three-Point Calibration **for pH sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > Open Two-Point Calibration
2	If temperature compensation was not specified in the calibration default settings, enter the temperatures of the buffer solution here manually. If temperature compensation was specified, the temperature of the buffer solution is determined automatically. To enter the temperature, tap the button 
3	Clean the pH electrode and immerse it in one of the buffer solutions. For a Two-point calibration, you need 2 buffer solutions. For a three-point calibration, you need 3 buffer solutions (acidic, neutral, and alkaline).

Step	Action
4	**Entry of the pH-value of the buffer solution** • **without buffer recognition:** Check whether the "pH buffer 1" matches the pH-value of the buffer solution used. If a buffer set table was not specified, the "buffer 1 pH" value is taken from the calibration default settings. It is still possible to change this manually here. tap button to enter pH-value of the buffer field  • **with buffer recognition:** A prerequisite here is that a buffer set table has been selected in the buffer set table and the pH-value of the buffer solution used is contained in this buffer set table. If these prerequisites are satisfied, the pH value of the buffer solution is determined automatically during the calibration.
5	Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
6	For each additional calibration point, repeat steps 3 to 5 with the required buffer solutions.
7	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
8	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

14.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

14.2 General information

The calibration of redox sensors is based on measurements in test solutions with a defined redox potential.

14.2.1 Calibration methods for Redox sensors

Zero-point calibration

This calibration method is used to determine the redox zero point.

A test solution with a defined redox potential is needed as a reference.

"mV" must be set as the redox unit in the configuration of the redox measurement input (analysis input or input for digital sensors).

⇨ Chapter 10.5.4 "pH/Redox/NH_3 analysis inputs", page 149

Two-point Calibration

This calibration is used to establish an application-specific measurement characteristic curve where redox potentials are represented as a percentage of concentration values. The redox potentials of 2 solutions are measured. Concentration values in percent are then assigned to the measured values by the user.

Two process-typical sample solutions are needed as calibration solutions as a reference.
"Percent" must be set as the redox unit in the configuration of the redox measurement input (analysis input or input for digital sensors).
⇨ Chapter 10.5.4 "pH/Redox/NH_3 analysis inputs", page 149
⇨ Chapter "Only for JUMO sensors with JUMO digiLine electronics pH/ORP/T", page 167

Example: In a detoxification plant, the toxicity of a liquid is to be measured on the basis of the Redox potential. The calibration requires 2 solutions:

- the concentration of the highly toxic solution is given as 80 % by the user, for instance
- the concentration of the detoxified solution is given as 10% by the user, for instance

Using the redox potential, the toxicity can now be measured and displayed in percent.

14.2.2 Calibration default settings for Redox sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the Redox calibration are described in the following.

Open the calibration default settings:
Device Menu > Calibration > Select Analysis Input or Digital Sensor Input for pH/redox/NH_3 > Calibration Presets

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in. The "Calibration default settings" menu for a digital sensor is visible for the digital sensor concerned only when it is linked.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
⇨ Chapter 8.2.7 "Digital sensors", page 99

Sample screen:
Redox calibration default settings
(zero-point calibration)



Redox calibration default settings

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
Additional calibration default settings are explained in the following table.

Parameter	Possible settings	Explanation
Redox test solution	-1500 to +1500 mV	Manual entry of the Redox potential of the test solution being used for calibration

NOTE
Remember that the configuration of the redox measurement input must be set to the redox unit "mV" for the zero-point calibration and to "Percent" for the two-point calibration.
⇨ Chapter 10.5.4 "pH/Redox/NH_3 analysis inputs", page 149

14.3 Redox calibration routines

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

NOTE
Digital sensors need to be linked before they can be calibrated.
⇨ Chapter 8.2.7 "Digital sensors", page 99

14.3.1 Zero-point calibration

Step	Action
1	Ensure that • the calibration default settings are correct, • "mV" is set as the Redox unit in the configuration of the Redox measurement input. ⇨ Chapter 14.2.2 "Calibration default settings for Redox sensors", page 250. ⇨ Chapter 10.5.4 "pH/Redox/NH_3 analysis inputs", page 149
2	Start the Zero-point calibration. **for redox sensors on analysis inputs:** Device Menu > Calibration > Select Analysis Input for pH/redox/NH_3 > Zero-Point Calibration **for redox sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > Zero-Point Calibration
3	Check that the "Redox test solution" value displayed matches the Redox value of the test solution. The "Redox test solution" value is taken from the calibration default settings. It is still possible to change this manually here. Tap button to change the Redox value of the test solution manually 

Step	Action
4	Clean the Redox electrode and immerse it in the test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

14.3.2 Two-point Calibration

Step	Action
1	Ensure that • the calibration default settings are correct • "Percent" is set as the Redox unit in the configuration of the Redox measurement input. ⇨ Chapter 14.2.2 "Calibration default settings for Redox sensors", page 250. ⇨ Chapter 10.5.4 "pH/Redox/NH_3 analysis inputs", page 149
2	Start the two-point calibration. **for redox sensors on analysis inputs:** Device Menu > Calibration > Select Analysis Input for pH/redox/NH_3 > Two-Point Calibration **for redox sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > Two-Point Calibration
3	Enter the concentration value of the first reference solution in percent. Confirm by pressing "OK". Tap button to enter field 
4	Clean the Redox electrode and immerse it in the first test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
5	As in step 3, enter the concentration value of the second solution in percent. Confirm by pressing "OK".
6	Clean the Redox electrode and immerse it in the second test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
7	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
8	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

14 Calibrating redox sensors

15.1 Notes

WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.7 "Digital inputs of base unit and optional boards", page 158

15.2 General information

The calibration of ammonia sensors is based on measurements in ammonia-free test solutions.

15.2.1 Calibration methods for ammonia sensors

Zero-point calibration

This calibration method is used to determine the ammonia zero point.
An ammonia-free test solution (e.g. water) is needed as a reference.

15.2.2 Calibration default settings for ammonia sensors

In the ammonia sensor calibration default settings, the zero-point calibration is enabled and preconfigured as the only available calibration routine.

Open the calibration default settings:
Device Menu > Calibration > Select Analysis Input for pH/redox/NH_3 > Calibration Presets

Sample screen: Ammonia calibration default settings



15 Calibrating ammonia sensors

15.3 Ammonia calibration routines

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

15.3.1 Zero-point calibration

Step	Action
1	Start the Zero-point calibration. Device Menu > Calibration > Select Analysis Input for pH/redox/ NH_3 > Zero-Point Calibration
2	Clean the ammonia electrode and immerse it in the ammonia-free test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
3	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
4	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

16.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

16.2 General information

The calibration of CR sensors is based on measurements in test solutions with a defined electrolytic conductivity. Since the electrolytic conductivity of liquids is temperature dependent, the temperature of the test solution must be sensed. This requires either manual entry or measurement with the aid of a temperature sensor.

16.2.1 Calibration methods for CR conductivity sensors (conductive)

Rel. cell constant

The deviation from the nominal cell constant of a CR sensor is described by the relative cell constant. The rel. cell constant is determined by making a measurement in a test solution with a defined conductivity.

Temperature coefficient

The temperature coefficient is a measure of the temperature dependence of the electrolytic conductivity of a liquid. It is used to compensate for the effect of temperature when measuring the electrolytic conductivity. When performing a temperature-compensated conductivity measurement, the conductivity value measured is always indicated with reference to the fixed reference temperature. With the aid of the temperature coefficient, the value of the electrolytic conductivity displayed at the reference temperature is calculated from the current measured values of conductivity and temperature of the liquid.
The reference temperature is set in the configuration of the individual CR analysis input or digital input with JUMO digiLine CR.
⇨ Chapter 10.5.6 "CR/Ci analysis inputs (conductive/inductive conductivity)", page 152
⇨ Chapter "Only for sensors with JUMO digiLine CR/Ci", page 169
The temperature coefficient is determined from 2 measurements in a test solution at different temperatures (reference and operation temp.).



NOTE
If the temperature coefficient of a sample solution is known, it can be entered directly.
⇨ Chapter 12.2.1 "General procedure for calibration", page 235

TC curve for JUMO digiLine CR (for nonlinear temperature coefficients)

If the conductivity of a liquid whose temperature coefficient changes with temperature has to be measured, this method can determine 6 temperature coefficients for 6 temperature intervals. In this way, it is possible to determine a good approximation of the temperature coefficient curve. While the operator brings the sample solution to the temperature values requested by the device, the device determines the temperature coefficient for each interval. This requires installation of a temperature sensor that the device can use to sense the temperature of the sample solution. The series of temperature values consists of 7 values in total:

- Starting temperature and end temperature of the TC curve (⇨ Chapter "Calibration presets for calibrating the TC curve for JUMO digiLine CR", page 260)
- Reference temperature (⇨ Chapter 10.11.2 "Configuration of digital sensors", page 166)
- 4 additional temperature values between the "starting temperature and end temperature of the TC curve"



16.2.2 Calibration presets for CR conductivity sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the CR calibration are described in the following.

Open the calibration default settings:
for conductivity sensors on analysis inputs:
Device Menu > Calibration > Select CR Analysis Input > Calibration Presets

for conductivity sensors with JUMO digiLine electronics:
Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Settings

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

Sample screen:
CR calibration presets



The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
Additional calibration default settings are explained in the following table.

16 Calibrating CR conductivity sensors

Calibration presets for calibrating the relative cell constant

Parameter	Possible settings	Explanation
Reference conductivity	0 to 9999 mS/cm	Conductivity of the reference solution

Calibration presets for calibrating the temperature coefficient

Parameter	Possible settings	Explanation
Temperature compensation	Selection from analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration
Reference temperature	-50 to +150 °C	The conductivities of a sample solution at reference temperature and working temperature are captured during the calibration process. This yields 2 value pairs (temperature/conductivity). These value pairs provide the basis for calculating the temperature coefficient. The operation temp. must differ from the reference temperature by at least 5 °C.
Operation temp.	-50 to +150 °C	

Calibration presets for calibrating the TC curve for JUMO digiLine CR

Parameter	Possible settings	Explanation
Compensation	Fixed compensation temperature, Temperature input, Interface	**Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Temperature input:** The integrated temperature probe of the conductivity sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
Temperature compensation	Selection from Analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration
Starting temperature	-50 to +250 °C	The starting and final temperatures of the range for which a temperature coefficient curve is to be determined. The starting temperature must be at least 20 °C lower than the final temperature. The reference temperature for the measurement input must lie between the starting and final temperatures, and differ from the starting and final temperatures by at least 2 °C.
Final temperature	-50 to +250 °C	

NOTE
Calibration of the TC curve is possible only with automatic temperature acquisition.

16 Calibrating CR conductivity sensors

16.3 CR calibration routines

NOTE
Conductivity measuring inputs can be configured with measuring range change-over. Accordingly, calibrations must be performed for all "accessible measuring ranges".

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

16.3.1 Calibrating the relative cell constant

Step	Action
1	Start calibration of the relative cell constant. **for conductivity sensors on analysis or universal inputs:** Device Menu > Calibration > Select CR Analysis Input or Universal Input > Relative Cell Constant Calibration For CR optional boards, continue with step 2; for universal inputs set to the "conductivity measurement" operation mode, continue with step 3 **for conductivity sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > Relative Cell Constant Calibration
2	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range. Tap button to enter measuring range 

Step	Action
3	Ensure that • the sensor has been cleaned and is immersed in the test solution, • the set reference conductivity matches the conductivity value of the test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK". The preset reference conductivity can be changed here manually if necessary. tap button to change reference conductivity field 
4	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
5	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

16.3.2 Calibrating the temperature coefficient

Step	Action
1	Start calibration of the temperature coefficient. **for conductivity sensors on analysis or universal inputs:** Device Menu > Calibration > Select CR Analysis Input or Universal Input > TC calibration **for conductivity sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > TC Calibration
2	Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution). For CR optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operation mode, continue with step 4
3	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range. tap button to enter measuring field 

Step	Action
4	• **with temperature acquisition** A prerequisite is that temperature compensation was specified in the calibration the presets. Bring the temperature of the sample solution to the requested values of the reference and operation temperatures in succession. The order does not matter. Acquisition of the individual values takes place automatically. current temperature value requested Temperature value  Display after acquisition of first value remaining requested Temperature value  • **without temperature acquisition** If temperature compensation was not specified in the calibration presets, you must control acquisition of the value manually. Bring the temperature of the sample solution first to the value of the reference temperature and confirm by pressing "OK". Then proceed in the same manner for the operation temperature.
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

16.3.3 Calibrating the TC curve for JUMO digiLine CR

Step	Action
1	Start the desired calibration of the TC curve for JUMO digiLine CR **for conductivity sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > TC Curve
2	Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution). for CR optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operating mode, continue with step 4
3	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range. tap button to enter measuring field 
4	Bring the temperature of the sample solution to the requested setpoints in succession. Seven temperatures are requested. current temperature value requested Temperature val- 
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

16 Calibrating CR conductivity sensors

16 Calibrating CR conductivity sensors

17.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

17.2 General information

The calibration of Ci sensors is based on measurements in test solutions with a defined electrolytic conductivity. Since the electrolytic conductivity of liquids is temperature dependent, the temperature of the test solution must be sensed. This requires either manual entry or measurement with the aid of a temperature sensor.

17.2.1 Calibration methods for Ci conductivity sensors (inductive)

Rel. cell constant

The deviation from the nominal cell constant of a Ci sensor is described by the relative cell constant. The rel. cell constant is determined by making a measurement in a test solution with a defined conductivity.

Temperature coefficient

The temperature coefficient is a measure of the temperature dependence of the electrolytic conductivity of a liquid. It is used to compensate for the effect of temperature when measuring the electrolytic conductivity. When performing a temperature-compensated conductivity measurement, the conductivity value measured is always indicated with reference to the fixed reference temperature. With the aid of the temperature coefficient, the value of the electrolytic conductivity displayed at the reference temperature is calculated from the current measured values of conductivity and temperature of the liquid.
The reference temperature is set in the configuration of the individual Ci analysis input or digital input with JUMO digiLine Ci.
⇨ Chapter 10.5.6 "CR/Ci analysis inputs (conductive/inductive conductivity)", page 152
⇨ Chapter "Only for sensors with JUMO digiLine CR/Ci", page 169
The temperature coefficient is determined from 2 measurements in a test solution at different temperatures (reference and operation temp.).



NOTE
If the temperature coefficient of a sample solution is known, it can be entered directly.
⇨ Chapter 12.2.1 "General procedure for calibration", page 235

17 Calibrating Ci conductivity sensors

TC curve for conductivity sensors on analysis or universal inputs (for nonlinear temperature coefficients)

If the conductivity of a liquid whose temperature coefficient changes with temperature has to be measured, this method can determine 5 temperature coefficients for 5 temperature intervals. In this way, it is possible to determine a good approximation of the temperature coefficient curve. While the operator brings the sample solution to the temperature values requested by the device, the device determines the temperature coefficient for each interval. This requires installation of a temperature sensor that the device can use to sense the temperature of the sample solution.



TC curve for JUMO digiLine Ci (for nonlinear temperature coefficients)

If the conductivity of a liquid whose temperature coefficient changes with temperature has to be measured, this method can determine 6 temperature coefficients for 6 temperature intervals. In this way, it is possible to determine a good approximation of the temperature coefficient curve. While the operator brings the sample solution to the temperature values requested by the device, the device determines the temperature coefficient for each interval. This requires installation of a temperature sensor that the device can use to sense the temperature of the sample solution. The series of temperature values consists of 7 values in total:

- Starting temperature and end temperature of the TC curve“ (see calibration process for TC curve)
- Reference temperature (⇨ Chapter 10.11.2 "Configuration of digital sensors", page 166)
- 4 additional temperature values between the "starting temperature and end temperature of the TC curve"



17.2.2 Calibration presets for Ci conductivity sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the Ci calibration are described in the following.

Open the calibration default settings:

for conductivity sensors on analysis inputs:
Device Menu > Calibration > Select Ci Analysis Input > Calibration Default Settings

for conductivity sensors with JUMO digiLine electronics:
Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Settings

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

Sample screen:
Ci calibration presets



The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
Additional calibration default settings are explained in the following table.

Calibration presets for calibrating the relative cell constant

Parameter	Possible settings	Explanation
Reference conductivity	0 to 9999 mS/cm	Conductivity of the reference solution

Calibration presets for calibrating the temperature coefficient

Parameter	Possible settings	Explanation
Temperature compensation	Selection from analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration
Reference temperature	-50 to +150 °C	The conductivities of a sample solution at reference temperature and working temperature are captured during the calibration process. This yields 2 value pairs (temperature/conductivity). These value pairs provide the basis for calculating the temperature coefficient. The operation temp. must differ from the reference temperature by at least 5 °C.
Operation temp.	-50 to +150 °C	

17 Calibrating Ci conductivity sensors

Calibration presets for calibrating the TC curve

Parameter	Possible settings	Explanation
Compensation	Fixed compensation temperature, Temperature input, Interface	**only for JUMO digiLine Ci** **Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Temperature input:** The integrated temperature probe of the conductivity sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
Temperature compensation	Selection from analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration
Starting temperature	-50 to +250 °C	The starting and final temperatures of the range for which a temperature coefficient curve is to be determined. The starting temperature must be at least 20 °C lower than the final temperature. The reference temperature for the measurement input must lie between the starting and final temperatures, and differ from the starting and final temperatures by at least 2 °C.
Final temperature	-50 to +250 °C	

NOTE
Calibration of the TC curve is possible only with automatic temperature acquisition.

17.3 Ci calibration routines

NOTE
Conductivity measuring inputs can be configured with measuring range change-over. Accordingly, calibrations must be performed for all "accessible measuring ranges".

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

NOTE
Analysis inputs for inductive conductivity measurements (Ci) must undergo a Ci base calibration in the course of commissioning. Subsequent calibration is not possible without this initial Ci base calibration.
⇨ Chapter 11.2 "Ci base calibration", page 230

17.3.1 Calibrating the relative cell constant

Step	Action
1	Start calibration of the relative cell constant. **for conductivity sensors on analysis or universal inputs:** Device Menu > Calibration > Select Ci Analysis Input or Universal Input > Relative Cell Constant Calibration For Ci optional boards, continue with step 2; for universal inputs set to the "conductivity measurement" operation mode, continue with step 3 **for conductivity sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > Relative Cell Constant Calibration

Step	Action
2	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range. tap button to enter measuring field 
3	Ensure that • the sensor has been cleaned and is immersed in the test solution, • the set reference conductivity matches the conductivity value of the test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK". The preset reference conductivity can be changed here manually if necessary. tap button to change reference conductivity field 
4	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
5	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

17.3.2 Calibrating the temperature coefficient (TC)

Step	Action
1	Start calibration of the temperature coefficient. **for conductivity sensors on analysis or universal inputs:** Device menu > Calibration > Select Ci analysis input or universal input > TC calibration **for conductivity sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > TC Calibration
2	Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution). for Ci optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operating mode, continue with step 4
3	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range. tap button to enter measuring field 

Step	Action
4	• **with temperature acquisition** A prerequisite is that temperature compensation was specified in the calibration the presets. Bring the temperature of the sample solution to the requested values of the reference and operation temperatures in succession. The order does not matter. Acquisition of the individual values takes place automatically. current temperature value requested Temperature val-  Display after acquisition of first value remaining requested Temperature value  • **without temperature acquisition** If temperature compensation was not specified in the calibration presets, you must control acquisition of the value manually. Bring the temperature of the sample solution first to the value of the reference temperature and confirm by pressing "OK". Then proceed in the same manner for the operation temperature.
5	A Protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

17.3.3 Calibrating the TC curve

Step	Action
1	Start the desired calibration of the TC curve. **for conductivity sensors on analysis or universal inputs:** Device Menu > Calibration > Select Ci Analysis Input or Universal Input > TC Curve **for conductivity sensors with JUMO digiLine electronics:** Device Menu > Calibration > Digital Sensor 1 to 6 > TC Curve
2	Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution). for Ci optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operating mode, continue with step 4
3	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range. tap button to enter measuring field 

Step	Action
4	Bring the temperature of the sample solution to the requested set-points in succession. The temperatures for the individual calibration points will be requested: • Six temperatures for Ci analysis inputs or universal input • Seven temperatures for JUMO digiLine Ci current temperature value requested Temperature val- 
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

18.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

18.2 General information

18.2.1 Calibration methods for universal inputs

Universal inputs can be configured with various operation modes for a number of different process variables (see table below).
Detailed information on the possible configurations:
⇨ Chapter 10.5.2 "Universal inputs of base unit and optional boards", page 145

Appropriate calibration routines for each operation mode of a universal input can be enabled in the calibration default settings.
The following table lists the availability of calibration routines for the individual operation modes.

Universal input Operation modes / **Calibration routine**	linear scaling	Temp. measurement	pH value measurement	Conductivity measurement	free chlorine, pH/T-compensated
Zero-point calibration	X		X		
Slope calibration	X				X
Two-point Calibration	X		X		
Rel. cell constant				X	
Temperature coefficient				X	
TC curve				X	

Zero-point calibration

This calibration method is used to determine the zero point on the measurement characteristic curve. The slope is retained.

A test solution with a defined value of the respective measurand is needed as a reference.

Slope calibration

This calibration method is used to determine the slope of the measurement characteristic curve. The zero point is retained.

A test solution with a defined value of the respective measurand is needed as a reference.

18 Calibrating universal inputs

Two-point Calibration

The zero point and slope of the measuring characteristic curve are determined with the aid of 2 measurings of 2 different reference solutions.

Two test solutions with defined values of the respective measurand are needed as a references.

Calibrating rel. cell constants, temperature coefficients, and TC curves

The calibration routines for conductivity measuring with the universal input correspond to those for the Ci calibration.

⇨ Chapter 17 "Calibrating Ci conductivity sensors", page 269

18.2.2 Universal inputs calibration default settings

Which calibration default settings are available depends on the configuration settings of the universal input.

Open the calibration default settings:
Device menu > Calibration > Select Universal Input >
Calibration default settings

Calibration default settings for the individual operation modes

- **linear scaling**

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
The "linear scaling" operation mode permits adjustment of the zero point, slope, and two-point calibration.

Sample screen: Universal input calibration default settings in the "linear scaling" operation mode



- **pH value measurement**

The calibration default settings correspond to those for the zero-point and two-point calibration for pH/redox/NH_3 analysis inputs.

⇨ "pH calibration default settings", page 243

- **Conductivity measurement**

The calibration default settings correspond to those for the Ci calibration.

⇨ Chapter 17.2.2 "Calibration presets for Ci conductivity sensors", page 272

- **free chlorine, pH/Temp.-compensated**

In the universal inputs calibration default settings for the "free chlorine, pH/T-compensated" operation mode, the slope calibration is enabled and preconfigured as the only available calibration routine.



Sample screen: Universal input calibration default settings in the "free chlorine, pH/T-compensated" operation mode

Additional calibration default settings for calibration of chlorine sensors are explained in the following table.

Parameter	Possible settings	Explanation
Temperature compensation	Selection from Analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration
pH compensation source	Selection from Analog selection	pH measurement input for automatic sensing of the test/sample solution pH value during the calibration

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

18.3 Universal input calibration routines

This chapter explains the universal inputs calibration routines for the "linear scaling" and "free chlorine, pH/T-compensated" operation modes.
The explanations in the corresponding calibration chapters for the "pH value measurement" and "Conductivity measurement" operation modes apply, except that three-point calibration for pH sensors is not available for universal inputs (⇨ Chapter 18.2.1 "Calibration methods for universal inputs", page 281).

⇨ Chapter 13.3 "pH Calibration routines", page 245
⇨ Chapter 17.3 "Ci calibration routines", page 275

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

18.3.1 Zero point/slope calibration (linear scaling)

Step	Action
1	Start the desired Calibration routine. Device menu > Calibration > Select Universal Input > Zero-point calibration
2	Clean the sensor and immerse it in the test solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK". The measuring value is based on previous calibration values 
3	Enter the reference value of the test solution. Confirm by pressing "OK" Tap button to enter reference value of test solution 
4	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
5	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

18.3.2 Two-point calibration (linear scaling)

Step	Action
1	Start the desired Calibration routine. Device menu > Calibration > Select Universal Input > Two-point calibration
2	Clean the sensor and immerse it in the first test solution. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK". Measuring value based on previous calibration values 
3	Enter the reference value of the first test solution. Tap button to enter reference value of test solution 
4	Clean the sensor and immerse it in the second reference solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
5	As in step 3, enter the reference value of the second test solution. Confirm by pressing "OK".
6	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
7	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

18 Calibrating universal inputs

18.3.3 Slope calibration (free chlorine, pH/Temp.-compensated)

Step	Action
1	Start the slope calibration. Device menu > Calibration > Select Universal Input > Slope Calibration
2	Clean the sensor and immerse it in the test solution.
3	Check the displayed values for the pH value and temperature. Automatic sensing can be configured in the calibration default settings for both measurands independently of one another. With automatic acquisition, the particular influencing variable is only displayed and can no longer be changed here. Without automatic acquisition, the particular influencing variable must be entered manually here. Wait until the measured value displayed stabilizes and then check the pH value displayed. Then confirm by pressing "OK". Example with temperature acquisition and without pH value acquisition Measuring value based on previous calibration values Tap button to enter pH value of test solution 
4	Enter the concentration value of the test solution. Confirm by pressing "OK" Tap button to enter chlorine concentration 

Step	Action
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

19.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157
The duration of the calibration processes can then be tracked in the event list of the JUMO AQUIS touch.

19.2 General information

The sensors are calibrated ex works, meaning that no calibration is required before initial startup. If the measured values appear implausible during operation, the sensors should be calibrated. The various calibration methods for JUMO oxygen sensors are described in detail below.



NOTE
JUMO digital sensors can be calibrated on both the JUMO AQUIS touch P and on the PC using the JUMO DSM software. Further information in this regard can be found in the operating manual of the sensor type.

Before starting the calibration processes, ensure stable environmental influences and give your calibration setup enough time to achieve a stable physical and chemical state. To ensure successful calibration, the calibration sample should therefore be kept at room temperature in the open sample vessel for 30 minutes before the start of calibration. An equilibrium in the gas exchange between the calibration sample and ambient air is therefore established. Prevent interfering factors in the direct surroundings of the calibration setup such as direct sunlight, drafts, etc.



NOTE
The **JUMO digiLine O-DO S10** sensor ideally needs 10 to 15 minutes of warm-up time after being switched on. Measurements can be taken in this time. For an optimal calibration, however, the process should not be started until the warm-up time has lapsed.



NOTE
JUMO digiLine O-DO H10 and **H20** sensors are calibrated using test solutions or test gases. Depending on the humidity content of the calibration medium, a distinction must be drawn between the "Humid" and "Dry" mode in the sensor's calibration default setting.

The "Humid" mode must always be selected for test solutions. For test gases, "Humid" should be selected for a humidity content of over 50 % and "Dry" for a humidity content below 50 %.

19.2.1 Calibration methods for O-DO sensors

Zero point calibration

The zero point of the oxygen saturation characteristic line is determined with this calibration. The slope is retained.

An oxygen-free measurement medium is required as a reference. The zero-point calibration is commonly carried out in water treated with sodium sulfite (sodium sulfite concentration < 2 %).

In the case of the **JUMO ecoLine O-DO** sensor, the zero-point calibration is only performed together with the end-value calibration as a two-point calibration.

In the case of the **JUMO digiLine O-DO H10/H20**, the "Humid" measurement mode needs to be selected for the calibration method with sodium sulfite solution in the calibration default setting.
A zero-point calibration of the JUMO digiLine O-DO H10/H20 with nitrogen gas (nitrogen 5.0) is also possible under laboratory conditions.
During calibration with humidified gas, the "Humid" measurement mode must be set for this in the calibration default setting and the "Dry" measurement mode must be set in the case of direct supply of the nitrogen gas without prior humidification.

End-value or slope calibration (all O-DO sensors except JUMO digiLine O-DO H20)

With end-value calibration, the end value of the measurement characteristic curve is calibrated at the defined state of 100 % oxygen saturation.
This state can in principle be achieved in the following ways:

- By positioning the sensor in water vapor-saturated air (for example, directly over a water surface).
- By positioning the sensor in air-saturated water (air is directed through water until the water is saturated with it).

In the case of the JUMO digiLine O-DO H10, the "Humid" measurement mode must be set in the calibration default setting for these two calibration methods.

- Positioning of the sensor in an oxygen calibration gas with an oxygen content of 20.9 % vol.

In the case of the JUMO digiLine O-DO H10, the "Humid" measurement mode must be set in the calibration default setting for this calibration method for humidified gas and the "Dry" measurement mode must be set in the case of direct supply of the oxygen calibration gas without prior humidification.



NOTE
As the manufacturing of air-saturated water requires a high level of effort and is difficult to reproduce, the easier process of calibration in water vapor-saturated air is recommended for the operational calibration.

NOTE

The basic design for the calibration methods of the JUMO digiLine O-DO H10 and H20 sensors is described in their operating manual.

Positioning the sensor in the water vapor-saturated air



To achieve successful calibration, the following points must be taken into account:

- The sensor membrane must be kept dry during the calibration process. Drops of water adhering to the sensor membrane could distort the measurement result.
- The air pressure and temperature must remain constant during the calibration.

End-value or slope calibration of JUMO digiLine O-DO H20 (trace sensor)

With the end-value calibration of this sensor, the end value of the measurement characteristic line is calibrated using an oxygen calibration gas with an oxygen content of 1 to 2 % vol.
The "Humid" measurement mode must be set in the calibration default setting for this calibration method for humidified gas and the "Dry" measurement mode must be set in the case of direct supply of the oxygen calibration gas without prior humidification.

Two-point calibration (all O-DO sensors)

The two-point calibration is a combination of zero-point and end-value calibration. This calibration method offers the greatest possible level of accuracy and is particularly recommended for measurements of low concentration values.

19.2.2 Calibration default settings for O-DO sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the O-DO calibration are described in the following.

Open the calibration default settings:
Device Menu > Calibration > Digital Sensor 1 to 6 >
Calibration Default Settings

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in. The "Calibration default settings" menu for a digital sensor is visible for the digital sensor concerned only when it is linked.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
⇨ Chapter 8.2.7 "Digital sensors", page 99

Sample screen:
Calibration default settings for the
JUMO digiLine O-DO S10



Sample screen:
Calibration default settings for
JUMO digiLine O-DO H10
JUMO digiLine O-DO H20



Sample screen:
Calibration default settings for the JUMO ecoLine O-DO



19 Calibrating O-DO sensors

O-DO calibration default settings

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.

Additional calibration default settings, which are available for the **JUMO eco-Line O-DO** as well, are explained in the following table.

Parameter	Possible settings	Explanation
Compensation	Fixed compensation temperature Temperature input Interface	**Fixed compensation temperature:** Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature". **Temperature input:** The integrated temperature probe of the O-DO sensor supplies the compensation temperature. **Interface:** The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
Temperature compensation	Selection from Analog selection	Temperature input for automatic acquisition of the test/sample solution temperature during the calibration

An additional calibration default setting that is also available for the JUMO digiLine O-DO H10/H20 sensors is explained in the following table.

Parameter	Possible settings	Explanation
Measurement mode	Humid Dry	**Humid:** Select this if the sensor is to be calibrated in a liquid measurement medium or in a gaseous measurement medium with a humidity content > 50 %. Dry: Select this if the sensor is to be calibrated in a gaseous measurement medium with a humidity content < 50 %.



NOTE
For JUMO digiLine O-DO H10/H20 sensors, the measurement mode can be set **both in the configuration and in the calibration default settings**. Once the calibration is finished, the sensors return to the mode that was set **in the configuration**.

19.3 O-DO calibration routine

NOTE
For the JUMO digiLine O-DO H10/H20 and JUMO digiLine O-DO S10 sensors, the compensation settings and measuring units from the configuration also apply during calibration. Before calibration, it is necessary to check whether these settings are valid for the conditions during the calibrations. It may be necessary to adjust the configuration for the calibration process and reset it to the process conditions when the calibration is complete.
The sensors acquire the oxygen partial pressure as the process variable and convert it internally into the set unit.
Therefore, a unit different to the one used for measurement mode in the process can be used during the calibration.

⇨ Chapter "Only for sensors of the JUMO digiLine O-DO H10/H20 types", page 174
⇨ Chapter "Only for sensors of the JUMO digiLine O-DO S10 types", page 178

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

NOTE
Digital sensors need to be linked before they can be calibrated.
⇨ Chapter 8.2.7 "Digital sensors", page 99

19.3.1 JUMO digiLine O-DO H10 and H20 Humid zero-point calibration

Step	Action
1	Prepare a stable calibration setup and an **oxygen-free reference specimen**. ⇨ Chapter 19.2.1 "Calibration methods for O-DO sensors", page 292. The basic design for this calibration is also described in the sensor's operating manual.
2	Place the oxygen sensor in the calibration setup. Leave the reference specimen in the open sample vessel for some time to reach chemical and physical equilibrium. Make sure that the calibration setup, with the reference specimen, guarantees consistent environmental influences throughout the calibration process.
3	Ensure that the oxygen unit is configured to "**% SAT**" (if using oxygen-free water as a reference) for measuring the oxygen content. Call up Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration.
4	Ensure that the measurement mode is set to "**Humid**" in the calibration default settings of the sensor. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Setting.
5	When the measured value and temperature are stable, start the zero-point calibration. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Zero-Point Calibration.
6	Wait until the measured value has stabilized. Specified reference value for the oxygen saturation 
7	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined are applied and the calibration is entered in the calibration logbook.

Step	Action
8	If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". This concludes the calibration process.

19.3.2 JUMO digiLine O-DO H10 and H20 Dry zero-point calibration

Step	Action
1	Prepare a stable calibration setup with an **oxygen-free reference environment**, e.g. a measurement chamber with oxygen-saturated atmosphere (nitrogen gas 5.0). The basic design for this calibration is described in the sensor's operating manual.
2	Place the oxygen sensor in the calibration setup. Make sure that the calibration setup, with the oxygen-free reference environment, guarantees consistent environmental influences throughout the calibration process.
3	Ensure that the measurement mode is set to "**Dry**" in the calibration default settings of the sensor. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Setting.
4	When the measured value and temperature are stable, start the zero-point calibration. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Zero-Point Calibration.
5	Wait until the measured value has stabilized.  Specified reference value for the oxygen saturation
6	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined are applied and the calibration is entered in the calibration logbook.
7	If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". This concludes the calibration process.

19.3.3 JUMO digiLine O-DO H10 Humid end-value calibration

Step	Action
1	Prepare a stable calibration setup with **water vapor-saturated air** or **oxygen-saturated water**. ⇨ Chapter 19.2.1 "Calibration methods for O-DO sensors", page 292. The basic design for this calibration is also described in the sensor's operating manual.
2	Place the oxygen sensor in the calibration setup. Make sure that the calibration setup, with the reference specimen, guarantees consistent environmental influences throughout the calibration process.
3	Ensure that the oxygen unit is configured to "**% SAT**" for measuring the oxygen content. Call up Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration.
4	Ensure that the measurement mode is set to "**Humid**" in the calibration default settings of the sensor. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Setting.
5	When the measured value and temperature are stable, start the end-point calibration (slope calibration). Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Zero-Point Calibration.
6	Wait until the measured value has stabilized.  Editable reference value for the oxygen saturation
7	You can change the reference value by pressing the default value ("100.00" in the example). You can enter the reference value you want in the window that opens.
8	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined are applied and the calibration is entered in the calibration logbook.

Step	Action
9	If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". This concludes the calibration process.

19.3.4 JUMO digiLine O-DO H10 and H20 Dry end-value calibration

Step	Action
1	Prepare a stable calibration setup with an **oxygen** calibration gas with the **oxygen content** required for the end-value calibration: • 20.9 % vol for the JUMO digiLine O-DO **H10** sensor • 1 to 2 % vol for the JUMO digiLine O-DO **H20** sensor The basic design for this calibration is described in the sensor's operating manual.
2	Place the oxygen sensor in the calibration setup. Make sure that the calibration setup, with the reference environment, guarantees consistent environmental influences throughout the calibration process.
3	Ensure that the oxygen unit is configured to "**% SAT**" for measuring the oxygen content. Call up Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration.
4	Ensure that the measurement mode is set to "**Dry**" in the calibration default settings of the sensor. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Setting.
5	When the measured value and temperature are stable, start the end-point calibration (slope calibration). Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Zero-Point Calibration.
6	Wait until the measured value has stabilized.  Editable reference value for the oxygen saturation
7	You can change the reference value by pressing the default value ("2.00" in the example). You can enter the reference value you want in the window that opens.

Step	Action
8	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined are applied and the calibration is entered in the calibration logbook.
9	If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". This concludes the calibration process.

19.3.5 JUMO digiLine O-DO H10 Humid two-point calibration

Step	Action
1	Prepare both a stable calibration setup with **oxygen-free water** (for the zero-point calibration) and a stable calibration setup with **oxygen-saturated water** or **water vapor-saturated air** (for the end-value calibration). ⇨ Chapter 19.2.1 "Calibration methods for O-DO sensors", page 292. The basic design for these calibrations is also described in the sensor's operating manual.
2	Place the oxygen sensor in the calibration setup with **oxygen-free water**. Make sure that the calibration setup, with the reference specimen, guarantees consistent environmental influences throughout the calibration process. Leave the reference specimen in the open sample vessel for some time to reach chemical and physical equilibrium.
3	Ensure that the oxygen unit is configured to "**% SAT**" for measuring the oxygen content. Call up Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration.
4	Ensure that the measurement mode is set to "**Humid**" in the calibration default settings of the sensor. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Setting.
5	When the measured value and temperature are stable, start the two-point calibration. Device Menu > Calibration > Digital Sensor 1 to 6 >Two-Point Calibration The device starts with the zero-point calibration.

Step	Action
6	Wait until the measured value has stabilized.  Specified reference value for the oxygen saturation
7	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined for the zero point are applied and the calibration is entered in the calibration logbook.
8	If the zero point calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". The device switches to end value calibration.
9	Place the oxygen sensor in the calibration setup with **oxygen-saturated water** or **water vapor-saturated air**. The basic design for this calibration is described in the sensor's operating manual. Make sure that the calibration setup, with the reference specimen, guarantees consistent environmental influences throughout the calibration process.
10	Wait until the measured value has stabilized.  Editable reference value for the oxygen saturation
11	You can change the reference value by pressing the default value ("100.00" in the example). You can enter the reference value you want in the window that opens.
12	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined for the end value are applied and the calibration is entered in the calibration logbook.

Step	Action
13	If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". This concludes the calibration process.

19.3.6 JUMO digiLine O-DO H20 Dry two-point calibration

Step	Action
1	Prepare a stable calibration setup, e.g. with a measurement chamber. The measurement chamber should be able to be filled both with an **oxygen-free reference environment** (e.g. nitrogen calibration gas) and with a **reference environment with the oxygen content required for the end-value calibration** (1 to 2 % vol). The basic design for this calibration is described in the sensor's operating manual.
2	Place the oxygen sensor in the measurement chamber and ensure an **oxygen-free reference environment**. Make sure that the calibration setup, with the reference environment, guarantees consistent environmental influences throughout the calibration process.
3	Ensure that the oxygen unit is configured to "**% vol**" for measuring the oxygen content. Call up Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration.
4	Ensure that the measurement mode is set to "**Dry**" in the calibration default settings of the sensor. Call up Device Menu > Calibration > Digital Sensor 1 to 6 > Calibration Default Setting.
5	When the measured value and temperature are stable, start the two-point calibration. Device Menu > Calibration > Digital Sensor 1 to 6 >Two-Point Calibration The device starts with the zero-point calibration.
6	Wait until the measured value has stabilized. Specified reference value for the oxygen saturation 

Step	Action
7	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined for the zero point are applied and the calibration is entered in the calibration logbook.
8	If the zero point calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". The device switches to end value calibration.
9	Ensure a **reference environment with the oxygen content required for the end-value calibration** in the reference setup measurement chamber. Make sure that the calibration setup, with the reference environment, guarantees consistent environmental influences throughout the calibration process.
10	Wait until the measured value has stabilized.  Editable reference value for the oxygen saturation
11	You can change the reference value by pressing the default value ("2.00" in the example). You can enter the reference value you want in the window that opens.
12	When the measured value display is stable, confirm the result of the measurement by pressing "OK". The calibration values determined for the end value are applied and the calibration is entered in the calibration logbook.
13	If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". This concludes the calibration process.

19.3.7 Zero-point calibration with JUMO digiLine O-DO S10

Step	Action
1	Prepare a stable calibration setup and an **oxygen-free reference specimen** with clean water. Place the oxygen sensor in your calibration setup. Make sure that the calibration setup, with the reference specimen, guarantees consistent environmental influences throughout the calibration process. Leave the reference specimen in the open sample vessel for several minutes to reach chemical and physical equilibrium.
2	When measured value and temperature are stable, start the zero-point calibration. Device Menu > Calibration > Digital Sensor 1 to 6 > Open Zero-Point Calibration
3	Wait at least 90 seconds until the "OK" button is active. During the waiting time of 90 seconds a blue arrow runs through the button. Only then can it be pressed to confirm the calibration. Wait 90 seconds until the "OK" button is active Specified reference value for the oxygen saturation 
4	After the waiting time has elapsed and the measured value display is stable, confirm the result of the measurement by pressing "OK"
5	**Successful calibration:** If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". The calibration values determined are applied and enter the calibration in the Calibration logbook. This concludes the calibration process. **Calibration error:** Failed calibrations result in an error message at this point. By pressing the "OK" button, the calibration can be repeated by returning to step 2. With the "Cancel" button, the calibration process is ended at this point without any results. Within a calibration process, the calibration can be repeated up to 4 times by returning to step 2. Then the calibration process has to be ended without any results by pressing "Cancel".

19.3.8 End value calibration for JUMO digiLine O-DO S10

Step	Action
1	Prepare a stable calibration setup and a **reference specimen of known oxygen concentration** with clean water. Place the oxygen sensor in the calibration setup. Make sure that the calibration set-up, with the reference specimen, guarantees consistent environmental influences throughout the calibration process. Leave the reference specimen in the open sample vessel for at least 30 minutes to reach chemical and physical equilibrium.
2	Start the end value calibration. Go to Device Menu > Calibration > Digital Sensor 1 to 6 > End Value Calibration
3	Enter the known oxygen concentration of your calibration sample as the reference value. If you leave the reference value at the value 0 %, the calibration is automatically carried out with the reference value 100 %. Wait at least 90 seconds until the "OK" button is active. During the waiting time of 90 seconds a blue arrow runs through the button. Only then can it be pressed to confirm the calibration. Wait 90 seconds until the "OK" button is active Tap to enter the reference value of the oxygen saturation 
4	After the waiting time has elapsed and the measured value display is stable, confirm the result of the measurement by pressing "OK"
5	**Successful calibration:** If the calibration ends successfully, a protocol summarizing determined calibration values appears. Acknowledge the protocol by pressing "OK". The calibration values determined are applied and enter the calibration in the Calibration logbook. This concludes the calibration process. **Calibration error:** Failed calibrations result in an error message at this point. By pressing the "OK" button, the calibration can be repeated by returning to step 2. With the "Cancel" button, the calibration process is ended at this point without any results. Within a calibration process, the calibration can be repeated up to 4 times by returning to step 2. Then the calibration process has to be ended without any results by pressing "Cancel".

19.3.9 End value calibration for JUMO ecoLine O-DO

Step	Action
1	Start the end value calibration. Device Menu > Calibration > Digital Sensor 1 to 6 > End Value Calibration
2	If temperature compensation was not specified in the calibration default settings, enter the temperature of the air-saturated water or the water vapor-saturated air here manually. If temperature compensation was specified, the temperature is determined automatically. Tap button to enter temperature 
3	Immerse the sensor in air-saturated water or position it in water vapor-saturated air (⇨ Chapter 19.2.1 "Calibration methods for O-DO sensors", page 292). If you use water vapor-saturated air, ensure constant air pressure, constant temperature and that no water drops adhere to the membrane during the calibration procedure. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
4	The device displays the current measured value of oxygen saturation and the test material temperature. The setpoint value for oxygen saturation (100 % sat.) is set automatically by the device. The user does not need to make any entries here. 
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"

Step	Action
6	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
7	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

19.3.10 Two-point calibration for JUMO ecoLine O-DO

Step	Action
1	Start the two-point calibration. Device Menu > Calibration > Digital Sensor 1 to 6 > Two-Point Calibration
2	To determine the zero point, prepare a water sulfite solution (sulfite concentration < 2 %).
3	If temperature compensation was not specified in the calibration default settings, enter the temperature of the test materials used here manually. If temperature compensation was specified, the temperature is determined automatically. Tap button to enter temperature 
4	Immerse the sensor in the water sulfite solution. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
5	The device displays the current measured value of oxygen saturation and the test material temperature. The setpoint value for oxygen saturation (0 % sat.) is set automatically by the device. The user does not need to make any entries here. 
6	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"

Step	Action
7	Immerse the sensor in air-saturated water or position it in water vapor-saturated air (⇨ Chapter 19.2.1 "Calibration methods for O-DO sensors", page 292). If you use water vapor-saturated air, ensure constant air pressure, constant temperature and that no water drops adhere to the membrane during the calibration procedure. Wait until the measured value display stabilizes and then confirm the result of the measurement by pressing "OK".
8	The device displays the current measured value of oxygen saturation and the test material temperature. The setpoint value for oxygen saturation (100 % sat.) is set automatically by the device. The user does not need to make any entries here. 
9	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
10	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
11	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

19 Calibrating O-DO sensors

20.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

20.2 General information

Turbidity sensors are calibrated by means of two-point calibration in distilled water and formazine reference solution. The sensor is calibrated ex works, meaning that no calibration is required before initial startup. If the measured values are seen to drift during operation, the sensor should be calibrated.

Preparatory cleaning

Rinse off the sensor with clear water. Organic deposits left on the sensor optics, such as a biofilm or silt, may cause measurement errors. These deposits should be removed carefully with warm soapy water and a soft sponge. Never use abrasive agents (e.g. scouring sponge)!

Calcium deposits can be removed by submersing the sensors in a diluted hydrochloric acid solution **(concentration max. 5 %)** for several minutes.

20.2.1 Calibration methods for turbidity sensors

Two-point calibration

With two-point calibration, the zero point and slope of the sensor are calibrated. Distilled water is used as the test material for determining the zero point. Formazine is used as the test material for determining the second reference point. The zero point and calculated percent deviation from the ideal slope are saved as reference values.

20.2.2 Calibration presets for turbidity sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the calibration of turbidity sensors are described in the following.

Open the calibration default settings:
Device Menu > Calibration > Digital Sensor 1 to 6 >
Calibration Default Settings

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in. The "Calibration default settings" menu for a digital sensor is visible for the digital sensor concerned only when it is linked.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
⇨ Chapter 8.2.7 "Digital sensors", page 99

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
You can enable the two-point calibration for turbidity sensors.

20.3 Calibration routines for turbidity sensors

NOTE
Turbidity sensors can be configured with automatic selection of the measuring range. Accordingly, calibrations must be performed for all "accessible measuring ranges".

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

NOTE
Digital sensors need to be linked before they can be calibrated.
⇨ Chapter 8.2.7 "Digital sensors", page 99

20.3.1 Two-point calibration

Step	Action
1	Start the two-point calibration. Device Menu > Calibration > Digital Sensor 1 to 6 > Two-Point Calibration
2	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" 
3	Clean the sensor and immerse it in the distilled water.
4	The device displays the current measured value of the distilled water. The user does not need to make any entries here.
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
6	Immerse the sensor in a formazine reference solution. Its turbidity value should be approximately at the middle of the selected measuring range.

Step	Action
7	The device displays the current measured value of the formazine reference solution. Enter the actual turbidity value of the reference solution.
8	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
9	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
10	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

21 Calibration during disinfection measurements

21.1 Notes



WARNING!
During the calibration, the relays and analog output signals assume the states configured for the calibration! The response of the output signals is set for each output in its "Response at calibration" configuration point.
⇨ Chapter 10.6 "Analog outputs of base unit and optional boards", page 157

21.2 General information

JUMO digital sensors for disinfection measurands (chlorine, hydrogen peroxide, peracetic acid, ozone, chlorine dioxide and bromide) are calibrated by means of suitable comparison measurements in the measured value for the sensor type concerned (e.g. DPD method). Be sure to observe the information in the operating manual of the sensor for disinfection measurands with respect to calibration. The concentration values from the comparison measurement are entered in the device during the calibration process.

21 Calibration during disinfection measurements

21.2.1 Calibration methods for disinfection measurand sensors

End value calibration

For end value calibration, the slope of the sensor is calibrated by means of a comparison measurement (e.g. DPD method).

Two-point Calibration

With two-point calibration, the zero point and slope of the sensor are calibrated. This calibration method offers the greatest possible level of accuracy and is particularly recommended for measurements of low concentration values.

21.2.2 Calibration default settings for disinfection measurand sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for disinfection measurand sensors are described in the following.

Open the calibration default settings:
Device Menu > Calibration > Digital Sensor 1 to 6 >
Calibration Default Settings

NOTE
The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in. The "Calibration default settings" menu for a digital sensor is visible for the digital sensor concerned only when it is linked.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
⇨ Chapter 8.2.7 "Digital sensors", page 99

Sample screen:
Chlorine
calibration presets



Calibration default settings for disinfection measurand sensors

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.
Calibration routines that are not enabled are not visible in the calibration menu.
Additional calibration default settings are explained in the following table.

Parameter	Possible settings	Explanation
pH compensation	Selection from Analog selection	**Available only for chlorine measurement with pH compensation** pH input for automatic sensing of the test/sample solution pH value during the calibration

21 Calibration during disinfection measurements

21.3 Calibration routine for disinfection measurands

WARNING!
Be sure to observe the information in the respective operating manual of the various digital sensors for disinfection measurands with respect to calibration. Depending on sensor type, run-in periods may need to be observed and the sensors built into an appropriate fitting. Non-compliance will lead to incorrect calibration values and hence to incorrect measurement results.

NOTE
You must be logged in with corresponding user rights to perform calibrations.
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

NOTE
Digital sensors need to be linked before they can be calibrated.
⇨ Chapter 8.2.7 "Digital sensors", page 99

21.3.1 End value calibration

WARNING!
Steps 4 to 5 should be carried out very quickly, since the comparison measurement and the inputting of your result must be done promptly.

Step	Action
1	Make sure that the sensor to be calibrated is built into a suitable fitting and had enough time to run-in before the calibration was started. Be sure to observe the information in the operating manual of the sensor with respect to operation and calibration of the sensor type concerned and respect the stated operating conditions during the calibration.
2	Start the end value calibration. Device Menu > Calibration > Digital Sensor 1 to 6 > End Value Calibration

Step	Action
3	The device will show the current concentration measured value for the disinfection measurand. The user does not need to make any entries here. Wait until the measured value displayed stabilizes and then confirm by pressing "OK". Display of concentration value  Display of concentration value with pH-compensated chlorine measurement 
4	Remove a sample of the solution from the fitting and determine, as quickly as possible, its actual concentration value using a suitable comparison measurement.
5	Enter the concentration value of the solution determined during the comparison measurement as soon as possible after the comparison measurement. To enter the concentration value, tap the button 

Step	Action
6	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
7	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

21.3.2 Two-point Calibration

WARNING!
Steps 7 to 8 should be carried out very quickly, since the comparison measurement and the inputting of your result must be done promptly.

Step	Action
1	Make sure that the sensor to be calibrated is built into a suitable fitting and had enough time to run-in before the calibration was started. Be sure to observe the information in the operating manual of the sensor with respect to operation and calibration of the sensor type concerned and respect the stated operating conditions during the calibration.
2	Start the two-point calibration. Device Menu > Calibration > Digital Sensor 1 to 6 > Two-Point Calibration
3	Now let a solution containing no disinfectant to flow through the fitting (concentration value = 0)
4	The device will show the current concentration measured value for the disinfection measurand. The user does not need to make any entries here. Wait until the measured value displayed stabilizes and then confirm by pressing "OK". 
5	Now let a solution containing disinfectant to flow through the fitting (concentration value > 0)

Step	Action
6	The device will show the current concentration measured value for the disinfection measurand. The user does not need to make any entries here. Wait until the measured value displayed stabilizes and then confirm by pressing "OK". Display of concentration value  Display of concentration value with pH-compensated chlorine measurement 
7	Remove a sample of the solution from the fitting and determine, as quickly as possible, its actual concentration value using a suitable comparison measurement.
8	Enter the concentration value of the solution determined during the comparison measurement as soon as possible after the comparison measurement. To enter the concentration value, tap the button 

Step	Action
9	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
10	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

21 Calibration during disinfection measurements

NOTE
Data transmission from and to the device requires that the following requirements be satisfied:

- The device must be powered on
- The device must be connected to the PC either via USB or Ethernet (⇨ Chapter 22.7 "Connection to device", page 348)
- All windows on the user interface of the device must be closed; the device must be at the operating level

Configuration or parameter changes may not be made simultaneously on the device and with the JUMO PC setup program.

22.1 General information

All configuration data and parameterization can be edited offline with the JUMO PC setup program. Entire device configurations can be loaded into the device, exported from the device and saved on a PC/laptop.
In addition, the software is needed for the following tasks:

- Editing of User names and user rights on the device
  ⇨ Chapter 22.8.3 "User list", page 363
- Saving and deleting languages from the device
  ⇨ Chapter 22.8.4 "Country settings", page 366
- Creating/editing device settings lists for user levels
  ⇨ Chapter 22.8.6 "User levels", page 374
- Creating/editing formula and logic formula
  ⇨ Chapter 22.8.7 "Formula", page 375
  ⇨ Chapter 22.8.8 "Logic formula", page 376
- Creating/editing value tables for customer-specific linearization
  ⇨ Chapter 22.8.9 "Customer-specific linearization", page 377
- Editing of Buffer set tables for automatic buffer detection when calibrating pH sensors
  ⇨ Chapter 22.8.10 "Buffer set tables", page 380
- Creating/editing Process screens
  ⇨ Chapter 22.8.11 "Process images", page 381
- Configuring the e-mail function
  ⇨ Chapter 22.8.12 "Email", page 395
- Configuring the Webserver
  ⇨ Chapter 22.8.13 "Web server", page 402
- Viewing calibration logbooks
  ⇨ Chapter 22.9.1 "Calibration logbooks", page 405

22 PC Setup Program

22.2 Installing the JUMO PC setup program

Hardware and software requirements

A PC satisfying the following requirements is necessary for installation and operation of the JUMO PC setup program:

- Operating system: Microsoft®[1] Windows 7®1 and Windows 10®1 (32-bit and 64-bit version)
- Memory: 1 GB
- Available hard disk space: 1 GB
- DVD drive
- USB Host interface
- LAN interface (Ethernet)



NOTE
Close all applications on your PC before starting installation of the JUMO PC setup program.

22.2.1 Process

Step	Action
1	With the PC running, insert the CD supplied with the device into the drive and close it.
2	After the CD has been inserted, the installation program starts automatically; if this does not happen, proceed as follows: Start the "Launch.exe" file in the main directory of the CD.
3	The installation program guides you through the rest of installation accompanied by on-screen messages.

1. Microsoft, Windows 7, and Windows 10 are registered trademarks of the Microsoft Corporation.

Step	Action
4	Read and confirm the license agreement. Acceptance of the agreement is a basic requirement for installation of the software. 
5	• **30-days test version or demo version** Activate the check box for the 30-days test version. The entry fields for the license number are filled in automatically. • **Full version** Insert the license key that you received from JUMO[a]. 
6	Select the program folder to which the links for starting the software art be copied. The directory for the program files is determined automatically.
7	Click the "Install" button and wait until the installation has completed.

[a] To install the full version, you must acquire an appropriate license from JUMO. The contact data can be found on the back of this document.

NOTE
If the "30-days test version" option is selected during installation, the JUMO PC setup program is fully functional for 30 days. At the end of 30 days, the program switches automatically to a "demo version" where some functions such as data transmission, data storage and printing no longer work. The software can be licensed at a later date.

Program start

Once installation is complete, you can start the PC setup program from the Windows®[1] Start menu.

22.3 Logging onto the setup program

The user name and password are not requested following initial installation of the setup program. In the "Extras" menu, the "Renew login / Change password" function can be used to activate this request when the program starts.
⇨ Chapter 22.6.3 "Extras", page 345

A distinction can be made between the "Specialist" and "Maintenance" users when the log-in function is activated. The two users have different rights regarding access to functions of the PC setup program.
⇨ Chapter 22.3.1 "Rights in the setup program", page 331

If the prompt is active, the user must log on:

1. Microsoft and Windows 7 are registered trademarks of Microsoft Corporation.

22.3.1 Rights in the setup program

Depending on the version and login, individual users have different rights in the PC setup program.
The differences are summarized in the following table.

Users / User rights	Demo Version	Service	Specialist
New	X	X	X
Open	X	X	X
Save, Save As, Delete		X	X
Delete undocumented parameters			X
Export data to external mass storage (USB flash drive)		X	X
Import data from external mass storage (USB flash drive)		X	X
Print		X	X
Activate program options	X		X
Activate extra codes			X
Edit interface settings		X	X
Edit device settings	X	X	X
Delete device			X
Create new device	X		X
Reset user list	X	X	X

22.4 QuickStart agent

Installation

During installation of the PC setup program, an additional program with the description "QuickStart agent" is installed. This program starts automatically and appears as a symbol in the Windows taskbar.
Example:



(1) "Show icons" button
(2) Taskbar
(3) QuickStart agent link

Quick-start of programs

The QuickStart agent monitors removable media on the PC and responds if, for instance, a device or USB flash drive is connected to the PC. It lists all PC programs associated with the device found.
The user can decide which PC program should be started. This is done by highlighting the program in the list and then launching it by pressing the "Start" button. If there is only one program, it starts immediately.
Pressing the "Close" button switches the QuickStart agent to the background.

Settings

The "Settings" button can be used to change the following QuickStart agent options:

- National language used by the QuickStart agent
- Selection of programs that can be started by the QuickStart agent
- Autostart of the QuickStart agent when starting the PC

QuickStart agent in the foreground or background

Left- or right-clicking the symbol in the Windows® taskbar opens a selection list. Here, the user has the option of bringing the QuickStart agent to the foreground or background by selecting the relevant entry in the list.

If autostart is inactive, i.e. the symbol does not appear in the taskbar, the QuickStart agent can be started manually from the Windows Start menu. The QuickStart agent is located in the same program group as the JUMO PC setup program.

Ending the QuickStart agent

Selecting the entry "End" closes the QuickStart agent. It can be restarted from the Windows Start menu.

22 PC Setup Program

22.5 User interface

22.5.1 Elements of the user interface



(1)	Menu bar	(2)	Toolbar
(3)	Working area – navigation tree	(4)	Working area – display window
(5)	Connection status	(6)	Online data

Menu bar

The individual functions of the PC setup program are launched from the menu bar.
⇨ Chapter 22.6 "Menu bar", page 341

Toolbar

The toolbar contains selected functions from the menu bar. These can be launched by left-clicking on them. Hovering the mouse pointer over one of the icons displays the name of the function after a few seconds. Hovering the mouse pointer over one of the icons displays the name of the function after a few seconds.

Moving the toolbar

The user can change the position of the toolbar:

Step	Action
1	Position the mouse pointer between two icon groups 
2	Left-click with the mouse button
3	While holding down the left mouse button, move the toolbar to the desired location
4	Release the left mouse button

Possible positions of the toolbar:

- Along the left or right window border (vertical alignment)
- Below the menu bar (horizontal alignment),
- Along the lower edge above the user information (horizontal alignment)
- Any position (its own window - any alignment by changing the window size)

Closing the toolbar

If the toolbar was moved, it can be closed by clicking the cross at the right upper corner of the toolbar window. To display the toolbar again, it must be activated (set checkmark) in the "Standard Settings" menu under "User Interface".
File > Standard Settings

The toolbar that appears at the location to which it was previously moved.

Working area

The working area consists of the navigation tree (at left) and the display window (at right)
and displays the current settings of a configuration file (setup file).
⇨ Chapter 22.5.3 "Editing the setup file", page 339

The way the working area is divided can be changed by moving the border between the navigation tree and display window sideways with the aid of the left mouse button.

Connection status

The "Connection status" line indicates whether a connection to a device exists. In addition, some interface data is displayed, e.g., the IP address.
The "Window" menu can be used to show or hide the line.
The height of the line can be changed by moving the border of the online data window with the aid of the left mouse button.

Online data

The "Online data" function displays current process data in the PC setup program.
The "Window" menu can be used to show or hide the online data window.
File > Online Data

The height of the window can be changed by moving the border of the working area or the "Connection status" line with the aid of the left mouse button.

22.5.2 Display protection

Display protection can be activated in the basic settings of a device setup file.
To activate display protection, a password must be entered in the "Display protection" field.



When display protection is activated, all device settings in the PC setup program are concealed the next time the setup file is opened.



To show the device settings in the PC setup program again, double-click the entry "Display protection" in the display window or the navigation tree. Enter the display protection password in the following dialog. After the correct password has been entered, the entire device setup in the PC setup program appears again and can be edited.

22 PC Setup Program



22.5.3 Editing the setup file

In the "File" menu, create or open an existing setup file.

Create a new file:
File > New

Open an existing file:
File > Open

The working area (navigation tree and display window) shows the menu structure with the individual setting options for the JUMO AQUIS touch S from within the JUMO PC setup program.



(1) Navigation tree (complete menu structure of the PC setup program)

(2) Display window
Pop-up overviews of the sub-menus with their configuration data

(3) Active setup window

(4) Inactive setup window

Navigation tree

Left-clicking (once) on the entry "Project" or on a certain module displays the associated subitems in the display window. Clicking on the ("-") symbol closes a menu, clicking on the ("+") symbol opens a menu. Double-clicking on an entry (e.g. "Hardware configuration") opens a corresponding dialog for editing the individual configuration data. Alternatively, it is possible to access the individual menu levels via the "Edit" menu.

Display window

Double-clicking on an entry in the display window opens a dialog for editing the corresponding configuration data. Clicking once on the right-arrow symbol preceding the entry lists the current settings in the display window. Clicking once on the down-arrow symbol hides the settings again.

Setup window

If several setup windows are open simultaneously, clicking once on the name at the lower edge of the inactive window makes it the active window.

22.6 Menu bar

This chapter describes the menu bar functions. The order of the subchapters corresponds to the location of the menus in the menu bar (from left to right).

22.6.1 File menu

New

Creates a new setup file in the working area. After selecting the "New" command, the user can select from the following options:

- **User-Defined Setting**
  Extra codes and optional boards can be selected for the new setup file. This option is used to create a new setup without having a device connected.
- **Automatic Detection**
  The configuration (extra codes and optional boards) of the connected device are written to the new setup file. If desired, the "Read setup file from device" checkbox can also be selected. The current configuration is then written to the new setup file from the device and is available for editing.
  This option is used to edit or create the setup for an existing or new device.

Open ...

Opens an existing setup file and displays the content in the working area.

Save

Saves the settings shown in the working area in a setup file. The file name only needs to be entered once. If the file is saved again, the file name is no longer requested.

Save as ...

Saves the settings shown in the working area in a setup file. In contrast to the "Save" function, a prompt for the file name always appears in this case.

Close

Removes the settings shown in the working area from the working area and closes the Setup window. The user has the opportunity to save changes that have not yet been saved.

Export as RTF

Saves the current setting as an RTF file on the PC.
This function is useful for documenting a device configuration.

Print ...

Prints the setup settings of the project or module (depending on the item highlighted in the navigation tree). The menus to be printed can be selected beforehand.

Print preview ...

The print results are displayed on screen. Several pages can be displayed and the view can be scaled.

Printer setup ...

Allows the printer settings to be changed. When a program starts, the Windows default printer is always used as the active printer.

Standard Settings ...

Allows the default settings of the setup program to be changed. Some changes are not applied until you restart the setup program.

Last Files ...

Displays the file names of the setup files last saved. Clicking once on the file name opens the setup file or displays an already opened setup file as the active window.

End

Quits the setup program. The user has the opportunity to save changes that have not yet been saved.

22.6.2 Data Transfer menu

Establish Connection ...

Opens the device connections list. The content of the device connections list is project-dependent. The device connections list contains all devices to which a connection can be established via the setup program. Devices can be added to or removed from the list. The settings for the connection are also made in the device connections list.
⇨ Chapter 22.7.1 "Device connections list", page 348

Break connection ...

Terminates all connections of the active project, i.e. the selected setup file.

Data transfer to the device ...

Sends the setup data to the device. An existing connection to the device is a requirement. If there is no connection, the device connections list is opened automatically.

Data transfer from the device ...

Reads the configuration from the device. An existing connection to the device is a requirement. If there is no connection, the device connections list is opened automatically.

Data Transfer to Ext. Medium ...

Exports the setup file in SET format to external mass storage (USB flash drive). This file can be loaded directly into the device via the USB interface.

Data Transfer from Ext. Medium ...

Imports a setup file in SET format from external mass storage (USB flash drive) into an open setup file. In this way, an SET file that was previously copied from the device to a USB flash drive can be opened for editing with the JUMO PC set-up program.

Detailed information on loading and saving SET files via the USB interface on the device:
⇨ Chapter 8.4 "Memory Manager (USB flash drive)", page 112

22.6.3 Extras

Enable program options

Activates optional functions of the PC setup program (entry of additional license numbers). Using this function, the PC setup program can also be registered with a valid license number at a later date (30-days test version or full version) if a valid license number was not entered during the installation (demo mode).

Renew login / Change password

Opens a window to activate user login. After the JUMO PC setup program has been installed, prompts for the user name and password do not appear until user login has been activated. The user is logged on initially as "Specialist" with a blank password. This function activates the user and password prompt when the program starts and the current password is changed.

Text library...

Opens a window for editing the text library. The various operating languages for the device are saved in the text library. When a new setup file is generated, the languages are copied to the setup file. If necessary, they can be edited there in the "Country settings" menu. The order of the languages can be changed and also is observed during transfer to the setup file. The first two languages (language 1 and language 2) are transferred to the device and can be selected there. In various submenus, the "Language" button permits editing of the respective language.
⇨ Chapter "Language button", page 368

Version library

Shows the content of the version library. The list contains the standard versions of the device software and the compatible hardware versions provided by the device manufacturer together with the PC setup program. Additional software versions that were imported subsequently (e.g. customer-specific versions) are also contained.

22.6.4 Windows

Cascaded

Arranges all open setup windows in an overlapping arrangement. Left-clicking on a window brings it to the foreground.

Tiled

Arranges all open setup windows in a tiled arrangement. Left-clicking on a window makes it the active window.

Arrange icons

Arranges the symbols for all minimized setup windows in the lower region of the user interface. This function has an effect only if a symbol was previously moved out of the lower region.

Online data

Alternately shows/hides the online data window. A checkmark preceding the menu item indicates that the window is shown.

Connection status

Alternately shows/hides the line for displaying the connection status. A checkmark preceding the menu item indicates that the line is shown.

Opened windows

Displays the names of all opened setup files as a list. Clicking on the name in the list makes the associated window the active window. A checkmark preceding the name indicates the active window.

22.6.5 Info

Setup info

Displays information about the setup program, incl. the version number. The version number is important, for instance, when contacting the service hotline.

Registered license numbers ...

Shows all registered license numbers and any active options. The license numbers and the information about active options are important, for instance, when contacting the service hotline.

Program folder ...

Shows the various folders (directories) that are being used on the hard disk drive or in the network by the setup program. Clicking on the button (to the right of the folder path) displays the content of the folder.

Memory info

Displays the memory information. The memory information is intended for use in diagnostics. It is requested when needed by the device manufacturer's service technician.

22.7 Connection to device

This chapter describes the various ways to establish a connection between the JUMO PC setup program and the device. A connection is possible via:

- LAN interface (HTTP or HTTP proxy)
- USB interface

NOTE

The USB interface is not intended for a permanent connection, since unintentional removal of the USB connector cannot be prevented due to the lack of a captive connection.

An existing connection is a requirement for data transfer between the JUMO PC setup program and system. In the menu bar, open:
Data transfer > Establish Connection ...

22.7.1 Device connections list

The device connections list contains all devices for which a connection has been configured. The user can add connections to new devices, change the properties of existing connections (interface parameters) as well as remove connections.



Connection settings assistant

The "Use connection settings assistant" function assists the user with creating a new entry, i.e. a new connection, and with editing existing entries. The assistant is always active after opening the device connections list (check mark set). It is started whenever a new entry is to be added to the device connection list.
⇨ Chapter 22.7.2 "Configuring the connection with the assistant", page 350
The assistant can be deactivated by removing the check mark. If a new entry is to be added to the device connections list then, the user must select the individual configuration steps on their own. If the device connections list is reopened, the assistant will again be active.
⇨ Chapter 22.7.3 "Configuring the connection without the assistant", page 357

Establishing a connection

If the user wishes to establish a connection (or start date data transfer when

there is no connection), the PC setup program opens the device connection list. The user must first highlight the device concerned in the device connection list and then press the "Establish connection" button. If a device should not be connected, the corresponding dialog ("Device connection list" window) should be closed by means of the "Exit" button or by clicking the "X" at the upper right corner of the dialog window.

Toolbar

The user has access to various functions via the toolbar for the device connections list.



Explanation	Button
New entry Creates a new connection entry	
Edit features Opens a settings dialog for a connection	
Permanently remove entry Deletes a connection entry permanently	
Establish connection Establishes a connection to the device highlighted in the list	
Exit Closes the device connections list	

22.7.2 Configuring the connection with the assistant

The connection settings assistant assists the user with configuring a new connection. The assistant is always active after opening the device connections list (check mark set). It is started whenever a new entry is to be added to the device connection list.
⇨ Chapter 22.7.1 "Device connections list", page 348



NOTE
Configuring a new connection "with the assistant" is the preferred method. It can also be used by a user without expert knowledge.

Setup dialog - Device and type of connection



Settings

Setting item	Selection/ setting option	Explanation
Device version	Selection from dropdown list	Device version of the device to be connected ⇨ Chapter 8.2.4 "Device info", page 97
Connection presets	Setup or ring memory via TCP/IP	LAN interface (HTTP protocol), connection to device in an intranet (or VPN)
	Setup or ring memory[a] via HTTP proxy	LAN interface (HTTP protocol), connection to device via proxy server and Internet
	Connection via USB	USB interface
Description	Text	Description of the connection
Define as default device in the device connection list	Checkboxes	Accesses a default device automatically, other devices must be connected via the device connections list.
Check whether a connection can be established	Checkboxes	With this option active, the program checks whether the selected device can be accessed via the selected interface upon completion of configuration.

[a] Ring buffer = Read out measurement data

After the user clicks on the "Next" button, the assistant opens the next setup dialog.

Setup dialog - Device login



Settings

Setting item	Selection/ setting option	Explanation
Do not log in	Checkboxes	Activate option (set checkmark) if connection to the device takes place without login. Without logging in, some functions probably will not be available. The deciding factor is the authorizations that have been defined for a user who has not logged in. ⇨ Chapter 8.1.1 "Passwords and user rights", page 79
Save ID and password	Checkboxes	Saves the user ID and password for automatic login to the device when establishing a connection the next time
User ID	Text	User name for device login
Device password	Text (is hidden during entry)	Password for device login

After the user clicks on the "Next" button, the assistant opens the next setup dialog.

Setup dialog - TCP/IP port settings

This dialog depends on the selected connection preset. The figure shows the case "Setup or ring buffer via HTTP proxy". Except for the parameters "Proxy" and "Proxy Port", the description applies also for the case "Setup or ring buffer via TCP/IP".



Settings

Setting item	Selection/ setting option	Explanation
Device: IP address / Host name	Enter IP address or name. Or click on the "Search" button and select the device from the list by double-clicking on it.	IP address or host name of the device The search function (telescope button) finds all devices on the local network and displays them in a selection list. ⇨ Chapter 22.7.4 "Searching for a device in the network", page 359
Check and change host name	Open by pressing the button	Button to change the host name into the IP address of the device. All host names registered to an address as well as alternative addresses are displayed when appropriate
Device: Port number-/ Port name	The port number and port name can be changed only in the expanded settings (see below).	Port number or port description of the device Default port: 80
Extended	Open by pressing the button	Extended settings for communication These settings should be changed only in exceptional situations.

After the user clicks on the "Next" button, the assistant opens the next setup dialog.

Setup dialog - Overview of the settings

To complete the configuration, the user is presented with an overview of the settings. If the "Connection via USB" connection setting was selected, this overview appears immediately after the "Device Login" dialog, since normally no settings are required for the USB connection or only a device of the same type is connected.
⇨ Chapter "Setup dialog - USB interface settings on the PC", page 355

An incorrect setting can be corrected by pressing the "Exit" button to reopen the setup dialog concerned and making the correction there. Clicking on the "Finish" button closes the assistant and enters the new connection in the device settings list.



Setup dialog - USB interface settings on the PC

If several devices are connected via a USB interface, one device must be selected here. Moreover, it is possible to activate various test criteria so that the connection to the device is established only upon a successful test.
This dialog depends on the selected connection preset. The figure shows the case "Connection via USB". To access this dialog, it is necessary to click on the "Next" button twice – starting from the "Device Login" dialog – while holding down the "Ctrl" + "Shift" keys.



Settings

Setting item	Selection/ setting option	Explanation
Connected devices	Selection from dropdown list	Devices connected via the USB interface are displayed.
Name	Text (entry field active only when checkbox activated)	With checking active, the device is connected only if the device name matches.
Ser. No.		With checking active, the device is connected only if the device serial number matches.
CPU		With checking active, the device is connected only if the serial number of the CPU matches.
Path		With checking active, the device is connected only if the USB path matches.
Extended	Open by pressing the button	Extended settings for communication These settings should be changed only in exceptional situations.

Clicking on the "Finish" button closes the assistant and enters the new connection in the device connections list.

Setup dialog - Overview of the settings

To complete the configuration, the user is presented with an overview of the settings. An incorrect setting can be corrected by pressing the "Exit" button to re-open the setup dialog concerned and making the correction there.



Clicking on the "Finish" button closes the assistant and enters the new connection in the device connections list.

22.7.3 Configuring the connection without the assistant

The assistant can be deactivated in the device connections list (remove the checkmark).
⇨ Chapter 22.7.1 "Device connections list", page 348

During configuration, the user is not guided to the next step - as with an active assistant - but instead must select the individual steps of the configuration on their own. The following example shows the basic procedure. The parameters in the individual setup dialogs are largely the same as when configuring with an assistant so that a description is not provided here. However, additional protocols and interfaces are available for the settings used to establish communication.

NOTE
Configuring a new connection "without the assistant" requires expert knowledge and is provided only for service purposes.

Step	Action
(1)	Make the settings for the new device and click on "Interface 
(2)	Make the login settings and click on "Properties" 

Step	Action
(3)	Make the protocol and interface settings and click on OK. If necessary, click on the "Extended" button beforehand to make additional settings for communication. 
(4)	Close all previously opened setup dialogs (windows) by clicking on the "OK" button. When the last setup dialog closes, the new connection is entered in the device connections list.

22.7.4 Searching for a device in the network

This function assists the user with selecting the IP address or the host name for the device of interest. A "Search" button is located
to the right of the entry field in the dialog for entering the IP address or host name.



Clicking on this button automatically finds all potentially suitable devices in the local network and displays them in a list.



The listed devices are located in the same subnet as the PC from which the search was initiated. Specifying the software version in the "SW Base" field limits its search to specific devices and versions.

If devices in a different subnet are to be searched, the address range of the device must be known. This address range must be entered into the field "IP-Adr.". The first 3 bytes of the IP-address must be known, only the last byte can be entered as the range (e.g. 10.13.3.50-150).



The device concerned can be highlighted with the mouse pointer (by clicking on the cell) and accepted by pressing **OK** (or by double-clicking on the cell). This

enters the host name (DNS name) in the input field.



You can use the "Check and convert host name" function to establish the IP address and transfer it to the input field (subsequent editing may be necessary in the input field). Depending on the version, there may be an option to select the host name or IP address from a dropdown list.

22.8 Setting up the device with the JUMO PC setup program

22.8.1 Identification

Identifying the device version

All configuration data and the hardware installed in a connected or network-accessible device can be read and displayed here. In addition, the hardware installed in a device can be specified manually in order to create a setup file for a device that is not connected (e. g. a planned new device).
This function is accessed in the navigation tree of the work area by double-clicking on:
Identification > Device Version
A window opens where you must select whether you wish to import the option boards installed in a connected device into a new setup file (Automatic Detection), or manually enter the hardware configuration data for a new setup file (User-defined Settings).



In the next window, you select the device for which the setup file is being created/exported:

- Surface-mount device (JUMO AQUIS touch S)
- Control cabinet device (JUMO AQUIS touch P)

After you have selected the desired device and clicked the "Next" button, the graphical overview showing the installed option boards opens. If "User-defined settings" was selected, the option boards installed can be manually specified for the setup file here. In this case, use drag and drop to select the desired option board symbols from the menu bar above and place them on the intended expansion slots marked in green. The expansion slots available for installation are marked in green while dragging. If "Automatic detection" was selected, the menu bar with option board symbols is not available; instead, the actual configuration of the device read is displayed.



Clicking on the "Next" button opens a dialog window where you can activate extra codes for the setup file:

- Math/Logic
- Recording
- Digital sensors

Activate the extra codes that you wish to configure in the setup file. When you wish to transfer the created setup file to a device, you must activate the selected extra codes for this device.

⇨ Chapter 22.10.4 "Approval of extra codes", page 409

Connection diagram

A graphical connection diagram is saved here. The JUMO PC setup program reads which option boards are installed and the terminal assignment from the configuration data in the setup file. The connection diagram can be printed out and used for wiring the device associated with the setup file. Double-clicking on the "Connection Diagram" menu opens a dialog in which the margins for the connection diagram printout can be set. The contents of the title block below the connection diagram can either be synchronized with the information in the "File Info" menu, or filled in with your own text. If the option "Synchronize Texts with File Info Header" has been activated in the settings dialog for the connection diagram, this file info is displayed there and can also be edited here.

22.8.2 Configuring and parameterizing

All parameters at the configuration level and the parameter level can be set both on the device itself and with the JUMO PC setup program.
⇨ Chapter 10 "Configuration", page 137
⇨ Chapter 9 "Parameterization", page 131

22.8.3 User list

The factory-entered user names, passwords, and user rights (⇨ Chapter 8.1.1 "Passwords and user rights", page 79) can be changed with the JUMO PC setup program.

Configuration point	Selection/ setting option	Explanation
Password rules	Password rules	The re-authentication time can be set here. This time counts down as soon as the user has logged in to the device. Once this time elapses, the logged-in user is logged off automatically. If the re authentication time is set to a value of 0 s, re-authentication is inactive. The user then remains logged in for the entire length of the session. ⇨ Chapter 8.2.1 "Log-on/Log-out", page 93
Character table	⇨ "Character table for passwords", page 364	Character set available for passwords
Public rights	⇨ "Configuring public Rights", page 365	User rights for users who are not logged in
ID	up to 10 text characters	User name for user login
Designation	up to 30 text characters	Name of the user account
Password	up to 10 text characters	Password for user login
Rights	⇨ "Configuring public Rights", page 365	User rights for each individual user account

Character table for passwords

Characters for user login can be added or changed in character tables 5 to 16. Character tables 1 to 4 cannot be changed.



(1) Classification selection field
(2) Visualization of the keyboard layout in the Device menu
(3) Entry field for character set
(4) Header character set for labeling the tab in the device settings menu
(5) Table 1 to 16 selection field
for selecting the character table to be edited

To add password characters, select an editable character table 5 to 16 (5) and enter the desired characters as a string without spaces in the entry field (3). The new or modified character table is available on the device for changing passwords. The
tab label for the virtual keyboard in the device settings menu is entered in the "Header char. set" field.

Configuring public Rights

The access rights for all users who are not logged in are set here.

Open Settings:
Only Setup > User List > Public Rights



Configuring user rights

The user rights for each individual user account are set here. A corresponding user login is required to exercise the respective user rights.

⇨ Chapter 8.1.1 "Passwords and user rights", page 79
⇨ Chapter 8.2.1 "Log-on/Log-out", page 93

Open Settings:
Only Setup > User List > Rights



22.8.4 Country settings

The country settings (language and country-specific settings such as the date format and decimal point) are taken from the text library by the setup program when creating a setup file. A country setting can be moved to another position in the list ("Sort language"). The country settings in the list are sent to the device and are available there for changing the language.



Setting item	Selection/ setting option	Explanation
Specification	No entry possible Assigned automatically	Internal Specification (only for service purposes to identify the language)
National language	Use factory-set text or enter a different text	Designation of the language
Date format	DDMMYYYY MMDDYYYY YYYYMMDD	Display format for the date
Decimal point	The following characters are possible: . ,	e. g. "comma" for German number format or "Point" for American
Separator (Date)	The following characters are possible: . , : ; - / \	Separator for configuring the date format
Separator (time)	The following characters are possible: . , : ; - / \	Separator for configuring the time format
Character entry	2 characters 1st standard character (e. g. lower-case letter) 2nd with Shift key (e. g. upper-case letter)	The assignment of characters to the individual keyboard fields of the virtual on-screen keyboard of the device can be changed here if necessary. ⇨ Chapter 22.8.5 "Device character set", page 372

Language button

Languages can be created, edited, and deleted with the "Language" button. New languages can be created on the basis of already existing languages. Available languages as well as languages from libraries can be selected as a template for new languages in the open setup. It is further possible to import available languages from a saved setup file as the new language. In this way, it is possible to transfer languages from one device to other devices with the aid of a device's setup file

Creating a new language

From an available language in the PC setup program

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Select and highlight a language as the template
(3)	Copy the selected language: Button "Language" > New Language > Create
(4)	The new language can now be edited and loaded into the device with the next data transfer.

From an available language in a saved setup file

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Select setup file for language import: Button "Language" > New Language > From Setup File
(3)	Select and open desired setup file in Explorer
(4)	Set checkmark in the checkbox for the selected language and accept
(5)	The new language can now still be edited if necessary and loaded into the device with the next data transfer

From a language in the current library (internal library of the JUMO PC set-up program)

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Open the current library: Button "Language" > New Language > From Current Library
(3)	Set checkmark in the checkbox for the selected language and accept
(4)	The new language can now still be edited if necessary and loaded into the device with the next data transfer

From a language in another library (library file stored on the hard drive)

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Select the library file: Button "Language" > New Language > From Another Library
(3)	Select and open desired library file in Explorer
(4)	Set checkmark in the checkbox for the selected language and accept
(5)	The new language can now still be edited if necessary and loaded into the device with the next data transfer

Edit languages

NOTE

Standard languages cannot be edited.

Only languages created by the user can be edited with the JUMO PC setup program.

⇨ Chapter "Creating a new language", page 368

The following figure shows the source language text on the left and the target language text on the right. "Source language" dropdown list: Selection of the language in the left column. This language cannot be edited. "Target language" drop-down list: Selection of the language in the right column. Editing possible only in this column.



	German	English
1	Einzelbild 1	Individual screen 1
2	Zusatzwert	Addition. value
3	Binärwerte	Binary values
4	Einzelbild 2	Individual Screen 2
5	Zusatzwert	Addition. value
6	Binärwerte	Binary values
7	Einzelbild 3	Single image 3
8	Zusatzwert	Addition. value
9	Binärwerte	Binary values
10	Einzelbild 4	Single image 4
11	Zusatzwert	Addition. value
12	Binärwerte	Binary values
13	Einzelbild 5	Single image 5
14	Zusatzwert	Addition. value
15	Binärwerte	Binary values
16	Einzelbild 6	Single image 6
17	Zusatzwert	Addition. value

Texts displayed in red characters on a white background have not yet been edited (equivalent to not translated). The other forms of display are listed below in the "Toolbar" section. To change a text, it is only necessary to left-click once in the text field. The selected field is then displayed with a black frame. If the text has been changed, it appears in black characters on a white background upon leaving the field. The text is then considered edited (translated).

NOTE

Static texts, e. g. the names of parameters that are too long to be displayed on the screen of the device, are automatically shortened in the menus ("..."). However, in the dialog window for setting the parameter concerned, the text is displayed in its full length. Texts should generally be kept as short and clear as possible. Longer texts that appear in the same menu should already differ from one another at the start of the text.

Toolbar

The toolbar gives the user access to various functions for editing text.



Explanation	Button
Search text	
Replace text with other text	
Use filter to reduce the number of texts in the list	
Sort texts alphabetically	
Display text ID (instead of Row number)	
Mark text as "not edited closed votes (red text)	
Mark text as "to be checked" (blue text)	
Mark text as "edited" (translated) (black text)	
Bookmark text	
Open next entry with a bookmark	
Write-protect text (gray background)	

Errors during Text input

Errors that occur during Text input are signaled by a colored background.

Explanation	Background
Too little memory space available. The total number of characters in a text is too large and must be reduced (shorten text).	Blue
The entered text is too long; it does not fit in the window provided.	Yellow
The text entered contains characters that cannot be displayed on the device.	Violet
Errors while editing a placeholder (#). The "#" symbol serves as a placeholder. Text is generated automatically by the device software at the location of the placeholder. Example: "Device ID #1.100". "Device ID" may be changed, "#1.100" **not**.	Brown

22.8.5 Device character set

When creating a new language, it is also possible to specify the characters available on the device for Text inputs (virtual keyboard).



(1) Entry field for character selection
The characters that are entered here are offered for selection by the virtual keyboard on the device later upon pressing the corresponding key.

(2) Selection on the device keyboard
In the example, the key for the plus sign was pressed on the virtual device keyboard.

To edit the character set for the device keyboard, proceed as follows:

Step	Action
(1)	Left-click the virtual key in the "Character entry" field (Example: "+"). The characters assigned to the key appear in the text field. The first character from the left corresponds to the character on the key.
(2)	Change the key assignment in the text field as necessary (if invalid characters are entered, the background changes to violet).

22.8.6 User levels

The user-defined parameter and settings lists on the user levels are created in this menu of the JUMO PC setup program. The configuration item "Source of designation" can be used to select between your own designation of the individual user level (configuration item "Level designation") and the designation of a selectable analog signal (configuration item "Signal designation") as the designation of a user level.

Explanation of the User level:
⇨ Chapter 8.2.2 "User levels", page 94

Open Settings:
Only Setup > User level > User level 1 to 16



22.8.7 Formula

Formula must be created with the JUMO PC setup program. During data transfer to the device, the formula are then loaded into the JUMO AQUIS touch P together with the setup. For formula that have already been loaded into the device, the configuration data below the formula entry field can also be set on the device as an alternative.

Explanation of the configuration data for "Formula":
⇨ Chapter 10.23 "Formula", page 221

Open Settings:
Only Setup > Formula > Formula 1 to 16



To create formula, open the Formula Editor by pressing the button. With the aid of the Formula Editor, you can select variables from the analog and binary selectors as well as available operators to add them to the mathematical expression in the text window by pressing the corresponding "Add" button.
If necessary, the formula can also be edited by entering characters with the keyboard.

22.8.8 Logic formula

Logic formula must be created with the JUMO PC setup program. During data transfer to the device, the formula are then loaded into the JUMO AQUIS touch P together with the setup. For formula that have already been loaded into the device, the description below the formula entry field and the alarm configuration can also be set on the device as an alternative.

Explanation of the configuration data for "Logic formula":
⇨ Chapter 10.24 "Logic formula", page 222

Open Settings:
Only Setup > Logic Formula > Formula 1 to 30



To create formula, open the Formula Editor by pressing the button. With the aid of the Formula Editor, you can select variables from the Binary selection as well as available operators in order to add them to the logic expression in the text window by pressing the corresponding "Add" button.
If necessary, the formula can also be edited by entering characters with the keyboard.

22.8.9 Customer-specific linearization

Value tables and formula for customer-specific linearization must be created with the JUMO PC setup program. During data transfer to the device, the linearization is then loaded into the JUMO AQUIS touch P together with the setup. After the linearizations have been loaded into the device, they can be used when configuring the following types of analog inputs:

- Universal inputs with a standard signal
  (except pH/T-compensated chlorine measurement)
  ⇨ Chapter 10.5.2 "Universal inputs of base unit and optional boards", page 145
- Temperature inputs for RTD temperatures probes with a customer-specific characteristic curve (up to 400 Ω, 4000 Ω or 100 kΩ)
  ⇨ Chapter 10.5.1 "Base unit temperature inputs", page 143
- Analysis measuring inputs for electrolytic conductivity
  ⇨ Chapter 10.5.8 "CR/Ci measuring ranges", page 153

Open Settings:
Only Setup > Customer-Specific Linearization > Tabs 1 to 8



Symbol buttons – Basic values table

"Insert line" Inserts a new line above the highlighted line[a]	
"Delete line" Deletes the highlighted line from the Basic values table[a]	
"Delete table" Delete all entries in the Basic values table	
"Generate formula" Generates an approximation formula from the values in the basic values table	

[a] Lines are highlighted by clicking the Row numbers.

Display graphic

The linearization characteristic curve is displayed by tapping the "Display graphic" button. By entering the "Lower limit" and "Upper limit" and then pressing the "Update" button, the display range of the Measuring value axis can be specified.



Settings for customer-specific linearizations 1 to 8

Setting item	Selection/ setting option	Explanation
Designation	up to 20 text characters	Linearization name
Kind of linearization	Grid values Formula	Way of entering linearization data In order to display a measurement characteristic curve, the customer-specific linearization can be entered as a value table with discrete value pairs or as a formula (fourth-degree polynomial).
Measuring range start	-99999 to 99999	**only with "Formula" as "Linearization type":** Value range limits for the Y-column The signal values from the sensor (X-values) are converted by the formula to values of the process variable (Y-values). The Y-values function as measuring values for input at the analog inputs of the AQUIS touch P.
Measuring range end		
Grid values	Table with discrete value pairs	**only for "Supporting values" as "Linearization type":** Entry of discrete value pairs of a measurement characteristic curve The signal values from the sensor can be entered in the X-column of the values table and the associated values of the process variable in the Y-column. The intervals between two value pairs are calculated internally by linear interpolation. The Y-values function as measuring values for input at the analog inputs of the AQUIS touch P.
Formula	Coefficients of a 4th degree polynomial	**only with "Formula" as "Linearization type":** Approximation formula for displaying a measurement characteristic curve Formula are entered as a fourth-degree polynomial and used to convert the signal values from the sensor (X-values) into the corresponding values of the process variable (Y values). The Y-values function as measured values for input at the analog inputs of the AQUIS touch P. The "Generate formula" button can be used to generate an approximation formula on the basis of the Basic values entered in the table.

22.8.10 Buffer set tables

Three buffer set tables are created in the JUMO AQUIS touch P.
Buffer set tables are needed for calibration of pH sensors when using automatic buffer detection.

⇨ Chapter 13 "Calibrating a pH measuring chain", page 241

.
These Buffer set tables can be changed as often as necessary here.

The factory settings for the Buffer set tables are as follows:

- **Buffer set 1:** Reference buffer solutions for calibrating pH measuring instruments acc. to DIN 19266
- **Buffer set 2:** Technical buffer solutions, preferably for calibrating and adjusting technical pH measuring instruments acc. to DIN 19267
- **Buffer set 3:** No data

Open Settings:
Only Setup > Buffer Set Tables > "Buffer Set Table 1 to 3“ tab



	Temperature	Buffer value 1	Buffer value 2	Buffer value 3	Buffer value 4	Buffer value 5	Buffer value 6
	°C	pH	pH	pH	pH	pH	pH
1	0.0 °C	1.67	4.01	6.95	9.46	13.42	
2	10.0 °C	1.67	4.00	6.92	9.33	13.00	
3	20.0 °C	1.67	4.00	6.88	9.23	12.63	
4	25.0 °C	1.68	4.01	6.86	9.18	12.45	
5	30.0 °C	1.68	4.01	6.85	9.14	12.29	
6	40.0 °C	1.69	4.03	6.84	9.07	11.98	
7	50.0 °C	1.71	4.06	6.83	9.01	11.70	
8	60.0 °C	1.72	4.09	6.84	8.96	11.45	
9	70.0 °C	1.74	4.13	6.84	8.92	11.21	
10	80.0 °C	1.77	4.16	6.86	8.89	10.99	
11	90.0 °C	1.79	4.20	6.88	8.85	10.79	
12	95.0 °C	1.81	4.23	6.89	8.83	10.69	

22.8.11 Process images

Up to 8 "Process screens" can be created in the Operation loop of the JUMO AQUIS touch P in order to design a dynamic overview display of a system or a process. Process screens must be created with the JUMO PC setup program and loaded into the JUMO AQUIS touch P together with the configuration.

Components of a Process screen:

- **Background color:** Selectable color of the background
  ⇨ "Background color", page 385
- **Background:** Any image in bitmap format
  (the dimensions of the Process screen are 316 × 182 pixels)
  ⇨ "Background", page 386
- **Objects:** Graphical elements for visualizing the operating state of the equipment in a system (e.g. pumps, valves, heating elements etc.)
  ⇨ "Objects", page 388

NOTE
Operation screens can be shown/hidden in the configuration. Check the Process screen setting in the configuration.

Device Menu > Display > General > Display Process Screen

Open Settings (Process screen Editor):
Only Setup > Process Screens (double-click) > "Process screen 1 to 8" tab

Process screen editor

Process screens for the JUMO AQUIS touch P must be created with the JUMO PC setup program. These are then transferred from the PC to the device together with the setup.



(1) Description of the Process screen (appears in the title bar of the Process screen)

(2) Setting for the background color of the Process screen

(3) Buttons for editing objects in the Process screen
⇨ "**Process screen Editor buttons**", page 383

(4) Object list with 100 objects
The list shows all 100 objects. The objects can be configured, formatted, and activated with the editor. Objects shown as "Off" are not active in the Process screen. Objects with higher numbers cover objects with lower numbers in the Process screen.

(5) "Preview" button
Opens the preview window with the concept for the Process screen
⇨ "Preview", page 384

(6) Background
Clicking this button opens a dialog for selecting an image from the image list.
It is also possible to import user-defined images into the image list.
⇨ "Background", page 386

(7) The "Active" option is used to activate and display the screen with the Process screen in the Operation loop.

Process screen Editor buttons

"Cut" Copies the highlighted object to the clipboard and deletes it from the list		
"Copy" Copies the highlighted object to the clipboard		
"Insert" Inserts an object from the clipboard at the highlighted position in the list; the highlighted object and all objects below it are shifted downward		
"New" Inserts a new object at the highlighted position in the list, the highlighted object and all objects below it are shifted downward		
"Remove" Removes the highlighted object from the highlighted position in the list; objects below it are shifted upward		
"Move up" Moves the highlighted object up one position in the list (corresponds to moving to the back in the Process screen)		
"Move down" Moves the highlighted object down one position in the list (corresponds to moving to the front in the Process screen)		
"Edit" Opens a dialog for editing the highlighted object ⇨ Chapter "Objects", page 388		
Cancel Cancels the editing step made in the object list; the button only becomes active if an editing step was made in the object list during a session.	Active 	Inactive 
Restore Restores editing steps in the object list that were canceled; the button only becomes active if editing steps were canceled in a session.	Active 	Inactive 

Preview

The "Preview" button in the Process screen Editor opens the preview. The concept for the Process screen can be viewed here. The Process screen is displayed as it will appear later on the device.
Objects can be repositioned via drag and drop. The size of object can be changed by dragging the corners and edges.
Using the buttons in this window, objects can be repositioned, aligned with one another, formatted, and simulated.
The X-position axis runs from left to right; the Y-position axis from top to bottom.
The origin of the coordinate system is the top left edge of the Process screen.



Buttons in the preview

"Frame type" Changes the frame format of a framed object	
"Font size" Changes the font size in an object with text	
"Alignment" Changes the alignment of the lettering in objects with text	
"Object type" Changes the orientation of the object (horizontal/vertical)	
"One step forward" Moves an object on the graphic levels one step forward	
"One step back" Moves an object on the graphic levels one step back	

"Move" Opens a window with arrow buttons from moving objects one step at a time Single arrow: Move by 1 pixel Double arrow: Move by 10 pixels	
"Align left" Simultaneously aligns several highlighted objects along the left edge of the object highlighted first[a]	
"Align right" Simultaneously aligns several highlighted objects along the right edge of the object highlighted first[a]	
"Align top" Simultaneously aligns several highlighted objects along the top edge of the object highlighted first[a]	
"Align bottom" Simultaneously aligns several highlighted objects along the bottom edge of the object highlighted first[a]	

[a] Several objects can be highlighted simultaneously by holding down the Shift key and left clicking with the mouse.

Background color

The background color on the level behind all objects and the background image can be selected in the Process screen Editor.

Background

The next level in front of the background color level is reserved for the background. Any image in the image list can be selected and displayed here in front of the background color level.
User-defined images can be imported into the image list. The images must be created in bitmap format. The dimensions of the Process screen are 316 × 182 pixels.

Open the "Background" dialog:
Only Setup > Process Screens > "Process screen 1" tab > "Background" button



(1) "Image List" button
This button opens a further dialog that is used to select an image as the background, and to import/export user-defined bitmaps into the image list.

⇨ "**Selecting an image as the background**", page 386
⇨ "Importing/exporting images", page 387

(2) Show/hide the background in the Process screen to provide a better overview of the objects in the Process screen during editing

(3) Center the background in the Process screen (the "Center" option has higher priority than the coordinate information)

(4) X-coordinate of the top left corner of the background image

(5) Y-coordinate of the top left corner of the background image

Selecting an image as the background

Step	Action
1	Open the image list Only Setup > Process Screens > "Process screen 1" tab > "Background" button > "Image List" button
2	Highlight the desired image in the list
3	Confirm by pressing "OK"

Importing/exporting images

Step	Action
1	Open the image list Only Setup > Process Screens > "Process screen 1" tab > "Background" button > "Image List" button
2	**Import:** Highlight an image in the list that you wish to overwrite with the new one and click the "Replace" button. **Export:** Highlight an image in the list that you wish to export and click the "Replace" button.
3	**Import:** In the Explorer window, select the new image file and click on "Open". **Export:** In the Explorer window, select the location where you wish to save the exported image, enter a file name and click on "Save".
4	The import/export process is now complete. You can close all windows that were opened in step 1 by pressing "OK" or "Cancel".

Tip: We recommend that you create an image that contains all static elements of your system representation and then use this as the background. The next step, all dynamic visualization elements are placed at the intended locations in the Process screen in the form of objects (e.g. pictograms for valves and pumps or analog displays).

Example: A Process screen for a CIP system is needed. In the first step, the representation of all static elements (pipes, tanks etc.) is created as a bitmap. The bitmap is imported into the image list and selected as the background. In the next subchapter (⇨ Chapter "Objects", page 388), objects are added to the sample Process screen.



Objects

The object list of the process screen editor contains 100 empty objects. Double-clicking on an entry or clicking the "Edit" button in the process screen editor opens a dialog for configuring, designing, and formatting the corresponding object in detail. For greater clarity, the dimensions, location in the process screen, type, and visibility are shown in the list for each object.
The object number in the object list is also the display priority of an object. Objects with higher object numbers cover those with lower object numbers.
The buttons in the Process screen Editor can be used to copy, cut, insert, move, and delete object list entries.
⇨ Chapter "**Process screen Editor buttons**", page 383

Object types

Pictograms:
A binary signal has two images associated with it. Depending on the value of the binary signal, one of the two images is displayed.
Example: An indicator light needs to be visualized. The image of a green indicator light is displayed for "TRUE" and a gray image (light off) is displayed for "FALSE".

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Digital signal	Selection from the binary selector	Binary signal for switching between the two images configured (see the following two lines)
Image Digital signal = TRUE	Selection from the image list	Image displayed when the binary signal = "TRUE" (on-signal)
Image Digital signal = FALSE	Selection from the image list	Image displayed when the binary signal = "FALSE" (Off-signal)

Analog signals:
The numerical value of an analog signal is displayed in the Process screen.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Analog signal	Selection from the analog selector	Analog signal source whose value is to be displayed
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame form	None Fine Bold Upper case Lower case	Selection of a frame format
Foreground color	Selection from color palette	Font color of the numeric display
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display
Comma format	Auto, Fixed comma format	Decimal points in the display

Digital signals:
A binary signal has two plain texts associated with it. Depending on the value of the binary signal, one of the two plain texts is displayed.
Example: A manual / automatic selector switch needs to be visualized. Depending on the switch position, either "Manual mode" or "Automatic mode" text is displayed.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Digital signal	Selection from the Binary selection	Binary signal source for the Digital display
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame form	None Fine Bold Upper case Lower case	Selection of a frame format
Color (low)	Selection from color palette	Font color for binary value = 0
Text for low	up to 30 text characters	Text for binary value = 0
Color (high)	Selection from color palette	Font color for binary value = 1
Text for high	up to 30 text characters	Text for binary value = 1
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display

Universal display:
Display of configuration settings, e.g. units or identifiers of an internal analog signal source for the JUMO AQUIS touch P.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Analog signal	Selection from the analog selector	Analog signal source whose value is to be displayed
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame form	None Fine Bold Upper case Lower case	Selection of a frame format
Foreground color	Selection from color palette	Font color of the numeric display
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display
Display type	Description Scale start Scale end Unit Limit value alarm 1 Limit value alarm 2 Window range alarm 1 Window range alarm 2	Selection of the configuration setting for the selected analog signal that is to be displayed

Text:
Plain text for labeling of visualization elements.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame form	None Fine Bold Upper case Lower case	Selection of a frame format
Foreground color	Selection from color palette	Font color of the numeric display
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display
Text	up to 30 text characters	Plain text for the identification field

Frames and rectangles:
Design elements for emphasizing or delimiting visualization elements of the Process screen. Rectangles are always transparent for objects. Every object is visible at all times regardless of the location of a rectangle in the object list.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	

Configuration item	Selection/ setting option	Explanation
Color	Selection from color palette	**For rectangles only:** Fill color of the rectangle (transparent for objects)
Frame form	None Fine Bold Upper case Lower case	Selection of a frame format

Bar graph:
Vertical or horizontal bar for visualizing analog values.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Transparent	Checkmark in the checkbox	Hide the background color; only the bar is visible
Frame form	None Fine Bold Upper case Lower case	Selection of a frame format
Color (off)	Selection from color palette	Background color of the bar graph display
Color (on)	Selection from color palette	Bar color in the bar graph display
Object type	horizontal vertical	Orientation of the bar graph display

Example: Objects now need to be added to the sample Process screen from the previous chapter (⇨ Chapter "Background", page 386). Valves and pumps are represented by pictograms. Two analog displays serve as the process value display.





22.8.12 Email

NOTE

The prerequisite for the e-mail function to operate is that the settings for the e-mail server and Ethernet are configured correctly. In particular, the DNS server and standard gateway entries must be correct.

⇨ Chapter "Setting up the e-mail server", page 398
⇨ Chapter 22.10.3 "Ethernet", page 408

The JUMO AQUIS touch P can be configured for event-controlled sending of e-mail notifications. Up to 5 e-mail templates can be stored in the JUMO AQUIS touch P. Sending of the e-mail is triggered by a rising edge of the binary signal in the "Alarm signal" field.

Typical networking and company networks



Function of the individual nodes

Gateway:
Separates local subnets from each other and thus filters the packets. Not all packets are received in every subnet. Packets from outside the local subnet must be addressed to the gateway.

DHCP server:
Can automatically assign an IP address, subnet mask, and gateway address to other nodes when switching on. These parameters can also be entered manually; a DHCP server is then no longer needed.

DNS server:
Converts symbolic names into IP addresses. Example: the query "www.name.de" will generate the response "www.name.de has IP = 10.12.32.45".

POP3 server:
used to read e-mails received in an e-mail account. The POP3 mail account can be accessed after log-in entering user name and password. A successful log-in process often releases the transmission authorization of a connected SMTP server.

SMTP server:
Used to send e-mails. In many networks, the authorization to send e-mails via a mail account must be released by previously logging in at the corresponding POP3 server.
Proxy:
Serves as a gateway from the local company network to the worldwide Internet. It is also used for the conversion of "local" IP addresses (used in the company network) to "one-time" IP addresses (used on the Internet). The device software cannot address a proxy! However, there are also "transparent proxies" that make it possible to address IP addresses worldwide without a special protocol.

SMS gateway

If present, e-mail messages can be redirected to your mobile phone through the SMS gateway of your wireless service provider. For e-mail forwarding through an SMS gateway, contact your wireless service provider.

Setting up e-mail templates

Open Settings:
Only Setup > e-mail (double-click) > "e-mail 1 to 5" tab



The following table explains the settings for event-controlled sending of e-mails.

Configuration point	Selection/ setting option	Explanation
E-mail addresses 1 to 3	Enter a valid e-mail address	Up to 3 e-mail addresses to each of which a particular e-mail is sent can be entered in each e-mail template. Sending is triggered by the indicated alarm signal.
Alarm signal	Select from the binary selection	A rising flank of the selected alarm signal triggers sending of the particular e-mail to the listed e-mail addresses.
E-mail subject	Input text	Text for the subject line of each e-mail
E-mail text	Input text	Text of each e-mail

Setting up the e-mail server

To send messages, you must specify the data for the outgoing mail server. Open the server settings window and enter the information here. You can obtain the server settings from your e-mail service provider or network administrator.

Open the dialog for the server settings:
Only Setup > e-mail (double-click) > "e-mail Server" button



The following table explains the settings for the e-mail server.

Configuration point	Selection/ setting option	Explanation
Authentication	None SMTP-After-POP SMTP-Auth	Authentication process (login) for the e-mail server You receive the configuration data for the e-mail server from the operator of the e-mail service that you use to send e-mail.
E-mail user name	Input text	User name of the e-mail account for the device for authentication (logging on to the e-mail servers)
E-mail password	Input text	Password of the e-mail account for the device for authentication (logging on to the e-mail servers)
Server URL POP3	Input text	URL (Internet address) or IP address of the incoming mail server (POP3 server) e. g. pop.provider.com
Server URL SMTP	Input text	URL (Internet address) or IP address of the outgoing mail server (SMTP server) e. g. smtp.provider.com
E-mail sender	Input text	E-mail address of the e-mail account for the device e. g. Anlage@provider.com

NOTE
An e-mail server within the company network must be entered (not on the Internet or accessible without proxy addressing)! This mail server should be able to also forward e-mails to the Internet.

Procedure for sending an e-mail over the Internet

To better understand the process of sending an e-mail and correct any errors in the configuration of e-mail servers and Ethernet, a graphical representation of the processes is presented in the following.



Checking the e-mail function

Proper execution of the e-mail sending process can be checked in the event list. When an e-mail is sent successfully, a corresponding entry is made in the event list. Entries are made in the event list even in the case of a fault and can be helpful when diagnosing a problem.

⇨ Chapter 8.3 "Alarm/Event list", page 104

22.8.13 Web server

As an alternative to online visualization, the webserver can be activated with a customer-specific website. If the webserver is activated, its website automatically replaces the online visualization.
⇨ Chapter 8.7 "Online visualization", page 126



NOTE
Creating websites requires the appropriate knowledge about website programming and specifying the webserver In the JUMO AQUIS touch P.

Customer-specific websites can be imported into the configuration of the web server. To edit an already saved website, it can be exported. Data from the memory of the AQUIS touch S can also be displayed in the web document.

Open Settings:
Only Setup > Webserver Configuration (double-click)



(1) "Import Web" button
(2) "Export Web" button
(3) "Delete Web" button
(4) Window with tree view of the saved website
(5) "HTML Tags" button
Opens a dialog for copying the IDs of internal data from the device memory
These IDs are needed to request the internal data from the web document.
(6) "Security" button
Opens a dialog to configure the webserver password

22.8.14 TC curve

Temperature coefficient curves are intended for temperature compensation for conductivity measurements in media with non-linear temperature coefficients. TC curves are normally determined by means of calibrations and stored in the device. If required, these can also be edited in the JUMO setup program and stored in the device. In the dialog for "TC-curve", you can find relevant tables for entering or manually changing the TC curves for each conductivity measurement input that is configured with TC curve as a compensation method.
You can find more information on TC curves for conductivity measurements in the relevant calibration chapters of this manual.

⇨ Chapter "TC curve for conductivity sensors on analysis or universal inputs (for nonlinear temperature coefficients)", page 270
⇨ Chapter "TC curve for JUMO digiLine Ci (for nonlinear temperature coefficients)", page 271
⇨ Chapter "TC curve for JUMO digiLine CR (for nonlinear temperature coefficients)", page 258

22.8.15 Modbus frames for reading

This function is used to compile up to eight Modbus frames for reading process values of external devices (via interface) individually for each opposite end. The process values (analog, integer, and digital values, and text) are written to the selected variables from the received Modbus telegram and are available for use in the system. Each frame can be used to configure up to 16 entries (variables); the process values are then grouped and transmitted in a Modbus telegram.

22.8.16 Modbus frames for writing

This function is used to compile up to eight Modbus frames for writing process values to external devices (via interface) individually for each opposite end. The process values (analog, integer, and digital signals, and text) are written to the frames by the system and are available to external devices. Each frame can be used to configure up to 16 entries (process values), which are then grouped and transmitted in a Modbus telegram.



NOTE

Configuration of Modbus frames is described in detail in the Modbus interface description of the device.

22.9 Diagnosis

22.9.1 Calibration logbooks

The calibration logbooks for all analysis inputs can be displayed on both the device and under this menu item in the JUMO PC setup program.

⇨ Chapter 12.3 "Calibration logbook", page 237

22.9.2 Digital sensor calibration logbooks

The calibration logbooks for all digital sensors can be displayed on both the device and under this menu item in the JUMO PC setup program.

⇨ Chapter 12.3 "Calibration logbook", page 237

22.9.3 Digital sensor connection list

If the JUMO AQUIS touch P must be replaced, e.g. because of a defect in the device, and a backup of the configuration is available as a setup file, the configuration can be loaded into the new device. However, the original links of the digital sensors to the corresponding inputs for the digital sensors must be reestablished manually. The information required to do this can be displayed with the PC setup program. The setup file backup from the original device contains the list of link data. Open this setup file and click in the navigation area of the PC setup program:
Diagnosis > Digital Sensor Connection List

The link data is displayed in this list. By comparing this data, the sensors can be reassigned to their original inputs and linked manually.

⇨ Chapter 8.2.7 "Digital sensors", page 99

Procedure for linking digital sensors following device replacement:

Step	Action
1	Using the JUMO PC setup program, load the originally backed up configuration into the device.
2	Press the "Print" button or File > Print
3	In the print selection list, select "Digital Sensor Connection List".
4	Print out the list (confirm the selection with "OK")
5	On the device, open the menu Device Menu > Digital Sensors, scan, and link all connected sensors. ⇨ Chapter 8.2.7 "Digital sensors", page 99

22.10 Online parameters

To set online parameters in the device, the software accesses the device memory directly. The device must thus be connected via a USB or Ethernet port to the PC on which the JUMO PC setup program is installed, and a connection between the JUMO PC setup program and device must be established.
⇨ Chapter 22.8.2 "Configuring and parameterizing", page 363

22.10.1 Date and time

Here, the current date and the current time in the device are obtained from the JUMO PC setup program.
Open Settings:
Online Parameters > Date and Time (double-click)



(1) "Read Continuously" button
Starts continuous synchronization of the date / time in the software with the device

(2) "Stop" button
Stops continuous synchronization of the date / time in the software with the device

(3) "Synchronize" button
Synchronizes the device time with the time set in the PC setup program
The time in the device is matched to the set time as long as the difference is not more than 30 s. This function is used primarily to synchronize the PC time with the device time.

(4) "Set" button
Sets the time in the device to match the setting in the PC setup program

(5) Time setting
The PC time can be used or a time may be entered. The specified time is set in the device by clicking the "Synchronize" or "Set" button.

22.10.2 Screenshot

This function can be used to transfer the current display on the device to the PC.

Screenshots can be printed out or saved on the PC in common image formats, e.g. bitmap, tiff, JPEG etc.
Open:
Online Parameters > Screenshot (double-click)



22.10.3 Ethernet

This menu item in the online parameters permits configuration of the Ethernet interface from the PC setup program.
Open Settings:
Online Parameters > Ethernet (double-click)

The Ethernet settings are explained in the configuration.
⇨ Chapter 10.20 "Ethernet", page 217

NOTE
The Ethernet settings are entered in the online parameters in the JUMO PC setup program.
The IP configuration of the device can also be changed from the PC if the PC and device are connected via Ethernet. In this case, changing the IP address or subnet mask can interrupt the PC-device connection.

22.10.4 Approval of extra codes

This function allows the customer to enable extra codes in the device software (recording function, math, and logic module). After purchasing an extra code in the device software, you must generate a code number with the aid of the PC setup program. This is needed by JUMO to generate an individual activation code that you as a customer need to enable the desired device functions. After opening "Enable extra codes", you have 3 options available:

- **Generate code number**
  If you wish to purchase an extra code in the device software, you must generate a device- and option-specific code number and send it to JUMO. After it receives this code number, JUMO provides you with the activation code with which you can enable the desired option.
- **Enter activation code**
  After you have sent the code number for the desired extra code to JUMO, you receive the activation code for this option. Following correct entry of the activation code, this option is available for use in the device.
- **Reset the extra codes**
  All software-based extra codes in your device can be deactivated with this option.

Open "Enable Extra Codes":
Online Parameters > Enable Extra Codes (double-click)

22.10.5 Deleting internal measurement data

Upon executing this function, data are **deleted completely** and **permanently** from the measurement memory of the data monitor and recording function. Following this, recording of measurement data is started anew.

Delete internal measurement data:
Online Parameters > Delete Internal Measurement Data (double-click)

22.10.6 Adjust / test



CAUTION!

When "Adjusting / Testing" is opened, the outputs assume undefined states. For this reason, "Adjusting / Testing" may not be opened during operation of equipment being controlled by the JUMO AQUIS touch P.

Numerous testing functions that are available in similar form in the device settings menu at the "Functional level" or under "Device info" can be found under "Adjusting / Testing". The contents and functions of the individual tabs in the "Adjusting / Testing" window are described in the following.

Hardware / Software

This is used to query the version information for the device software and hardware, e.g. which optional boards are installed.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Hardware / Software tab

Calibration constants

Displays characteristic curve date (e. g calibration values for analysis inputs) for each analog input and output.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Calibration Constants tab

Analog inputs

Proper operation of the analog inputs of the device can be checked here.
In addition to selecting the analog input and signal type, the line frequency of the power supplied to the device must be set in order to test an analog input correctly. Pressing the "Test" button displays a connection diagram for the test signal. Ensure that a valid test signal acc. to the connection diagram is present at the input. Confirming the connection diagram starts the test. The measuring values coming from the analog input concerned can be viewed in the actual-value display and in the measuring value table. To stop the test, press the "Stop" button.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Analog Inputs tab



(1) "Stop" button
Stops a test

(2) "Test" button
Starts a test

(3) Measured value display
Displays the actual analog value at the input

(4) Measuring value table
Lists the measuring values over the course of time

(5) "Supply frequency" setting

(6) Selection of the analog input to test

(7) Selection of the signal type to test

Analog outputs

Proper operation of the analog outputs of the device can be checked here. A desired output value can be specified in the "Setpoint value" field for the selected output and signal type set. Pressing the "Test" button starts the test. During the test, a window for monitoring the output signal is displayed. Here, you can enter the actual output value that you may have obtained with a measuring instrument as a way to check the output signal value. The test is stopped by pressing the "Stop" button.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Analog Outputs tab



(1) "Stop" button
Stops a test

(2) Dialog window for checking the measuring value during the test

(3) "Test" button
Starts a test

(4) Selection of the analog output to test

(5) Selection of the signal type to test

(6) Setpoint value
Desired output value during the test

Binary outputs

Proper operation of the Digital outputs of the device can be checked here. After setting checkmarks in the option fields, the Digital outputs of the device can be controlled manually via the PC setup program. The "Set All" and "Delete All" buttons allow all Digital outputs to be switched on and off at once.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Digital Outputs tab



Digital inputs

Proper operation of the Digital inputs of the device can be checked here.
The "Read Continuously" button starts a continuous test that can be stopped by pressing the "Stop" button. During this test, the binary values of the device inputs are read continuously and displayed in acc. with the checkmarks in the option fields.
Pressing the "Read Once" button captures and displays the momentary binary values of the inputs.
By clicking on individual binary input entries, the binary value of the entry can be updated selectively.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Digital Inputs tab



Battery

The **voltage of the buffer battery** and the **circuit board temperature** in the device are displayed in the JUMO PC setup program.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Battery tab



CAUTION!

A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

Touch

In this view, touchscreen calibration (⇨ Chapter 8.2.6 "Calibrating the touchscreen", page 99) can be started from the JUMO PC setup program. In addition, the calibration data for the touchscreen are displayed in detail. These are used to diagnose problems with touch operation together with JUMO Service.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Touch tab

Display

Four different test images can be activated on the device display on this tab. These are used to diagnose display problems together with JUMO Service.

To call it up:
Online Parameters > Adjusting / Testing (double-click) > Display tab

Different process values

Process data are selected here for display in the online window.
In addition to tabs with standard selections of process data, the online window contains the "Selected Process Data" tab. The process data selected here are displayed on this tab.



NOTE

Process data from the internal device memory can be displayed in real time in the online window.
⇨ Chapter "Online data", page 336
A requirement for real-time display of process data is an existing connection between the JUMO PC setup program and the device.

22 PC Setup Program

23.1 Analog inputs base unit

23.1.1 Temperature measurement input (IN 4)

Probe-/Signal type	Connection type	Measuring range	Measuring accuracy	Ambient temperature influence
Pt100 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.05 % of MR[a]	≤ 50 ppm/K
Pt1000 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.1 % of MR[a]	≤ 50 ppm/K
RTD temperature probe with customer-specific characteristic line[b]				
up to 400 Ω	2-wire/3-wire	0 to 400 Ω	≤ 0.1 % of R_{max}[c]	≤ 100 ppm/K
to 4000 Ω	2-wire/3-wire	0 to 4000 Ω	≤ 0.1% of R_{max}[c]	≤ 100 ppm/K
Sensor lead resistance	maximal 30 Ω per line with 3-wire circuit			
Lead compensation	Not required for 3-wire circuit. With a 2-wire circuit, lead calibration can be executed at the respective input by means of an measured value correction with the aid of the "Offset" setting.			

[a] MR: measuring range span
[b] Customer-specific linearization can be used to enter a sensor characteristic line.
[c] R_{max}: maximal resistance across the measuring range (400 Ω, or 4000 Ω)

23.1.2 Temperature measurement input (IN 5)

Probe-/Signal type	Connection type	Measuring range	Measuring accuracy	Ambient temperature influence
Pt100 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.05 % of MR[a]	≤ 50 ppm/K
Pt1000 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.1 % of MR[a]	≤ 50 ppm/K
Resistance transmitter	3-wire	0 to 100 kΩ	0.5 % of R_{Tot}[b]	≤ 100 ppm/K
RTD temperature probe with customer-specific characteristic line[c]				
up to 400 Ω	2-wire/3-wire	0 to 400 Ω	≤ 0.1 % of R_{max}[d]	≤ 100 ppm/K
to 4000 Ω	2-wire/3-wire	0 to 4000 Ω		
to 100 kΩ	2-wire/3-wire	0 to 100 kΩ		
NTC 8k55	2-wire/3-wire	0 to 150 °C	≤ 0.1 % of R_{max}[d]	≤ 100 ppm/K
NTC 22k	2-wire/3-wire	0 to 150 °C		
Sensor lead resistance	maximal 30 Ω per line with 3-wire circuit			
Lead compensation	Not required for 3-wire circuit. With a 2-wire circuit, lead calibration can be executed at the respective input by means of an measured value correction with the aid of the "Offset" setting.			

[a] MR: measuring range span
[b] R_{Tot}: total resistance of the resistance transmitter/Resistance potentiometer
[c] Customer-specific linearization can be used to enter a sensor characteristic line.
[d] R_{max}: maximal resistance across the measuring range (400 Ω, 4000 W or 100 kW)

23.1.3 Universal input (IN 6)

Signal type	Measuring range	Measuring accuracy	Ambient temperature influence
Current signal	0(4) to 20 mA	0.1 % of MR[a]	100 ppm/K

[a] MR: measuring range span

23.1.4 Measuring circuit monitoring base unit

Inputs	Underrange/ overrange
Temperature input	Yes
Universal input (current signal)	Yes

23.2 Analog inputs optional boards

23.2.1 Universal input (IN 11, IN 12)

Probe-/Signal type	Connection type	Measuring range	Measuring accuracy	Ambient temperature influence
Pt100 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.05 % of MR[a]	≤ 50 ppm/K
Pt1000 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.1 % of MR[a]	≤ 50 ppm/K
Resistance transmitter	3-wire	100 to 4000 Ω	0.5 % of R_{Tot}[b]	≤ 100 ppm/K
RTD temperature probe with customer-specific characteristic line[c]				
up to 400 Ω	2-wire/3-wire	0 to 400 Ω	≤ 0.1 % of R_{max}[d]	≤ 100 ppm/K
to 4000 Ω	2-wire/3-wire	0 to 4000 Ω	≤ 0.1 % of R_{max}[d]	≤ 100 ppm/K
Voltage signal	-	0 to 10 V	0.2 % of MR[a]	100 ppm/K
Current signal	-	0(4) to 20 mA	0.1 % of MR[a]	100 ppm/K
Sensor lead resistance[e]	maximal 30 Ω per line with 3-wire circuit			
Lead calibration[e]	Not required for 3-wire circuit. With a 2-wire circuit, lead calibration can be executed at the respective input by means of an measured value correction with the aid of the "Offset" setting.			

[a] MR: measuring range span
[b] R_{Tot}: total resistance of the resistance transmitter/Resistance potentiometer
[c] Customer-specific linearization can be used to enter a sensor characteristic line.
[d] R_{max}: maximal resistance across the measuring range (400 Ω or 4000 Ω)
[e] Specification does not apply for standard signals

23.2.2 Analysis input: pH/Redox/NH_3

Measurand	Measuring range	Temperature compensation	Measuring accuracy	Ambient temperature influence
pH-value (standard electrode)	-2 to +16 pH	-10 to +150 °C	≤ 0.3 % of MR[a]	0.2%/10 K
pH-value (ISFET electrode)	-2 to +16 pH	through electrode[b]		
Redox voltage	-1500 to +1500 mV	None		
NH_3 (ammonia)	0 to 20000 ppm	-10 to +150 °C		

[a] MR: measuring range span
[b] ISFET electrodes supply a temperature-compensated pH-measured value.

23.2.3 Analysis input: CR (resistive conductivity)

Units	µS/cm mS/cm kΩ × cm MΩ × cm

23 Technical data

Display ranges[a]	0.0000 to 9.9999 00.000 to 99.999 000.00 to 999.99 0000.0 to 9999.9 00000 to 99999
Temperature compensation	TC-linear, natural water DIN EN 27888, natural water with expanded range, TDS[b], ASTM D-1125-95 for neutral (NaCl), acid (HCl) and alkali (NaOH) impurities
Cell constant	0.01 to 10 cm^{-1}
Measuring range selection[c]	4 configurable measuring ranges
Measuring accuracy	£ 0.6% of MR[d] 0.3 µS × cell constant (C)
Ambient temperature influence	0.2%/10 K

[a] The display range is scalable. The decimal place is user configurable. In addition, an automatic Comma format can be set.

[b] TDS (**T**otal **D**issolved **S**olids)

[c] In the Configuration up to 4 different measuring ranges with separate display range limits, units,temperature compensation methods, and alarm functions can be configured. The respective active measuring range is selected via binary signals.

[d] MR: measuring range span

23.2.4 Analysis input: Ci (conductivity, inductive)

Units	µS/cm mS/cm
Measuring/display ranges[a]	0.0000 to 9.9999 00.000 to 99.999 000.00 to 999.99 0000.0 to 9999.9 00000 to 99999
Temperature compensation	TC linear[b] TC curve natural water natural water with expanded temperature range NaOH 0 to 12% NaOH 25 to 50% HNO_3 0 to 25 % HNO_3 36 to 82 % H_2SO_4 0 to 28 % H_2SO_4 36 to 85 % H_2SO_4 92 to 99% HCl 0 to 18 % HCl 22 to 44 %
Cell constant	4.00 to 8.00 cm^{-1}
Measuring range selection[c]	4 configurable measuring ranges
Measuring accuracy	for 0 to 999 µS/cm: 1.5% of the MRE[d] for 1 to 500 mS/cm: 1% of the MBE[d] for 500.1 to 2000 mS/cm: 1.5% of the MBE[d]
Ambient temperature influence	0.1 %/K

[a] The display range is scalable. The decimal place is user configurable. In addition, an automatic Comma format can be set.

[b] TC: temperature coefficient

[c] In the Configuration up to 4 different measuring ranges with separate display range limits, units, temperature compensation methods and alarm functions can be configured. The respective currently active measuring range is selected via binary signals.

[d] MRE: Measuring range end value

23.2.5 Temperature compensations

Compensation type	Compensation range
TC linear[a]	-50 to +250 °C
TC curve	-50 to +250 °C
TDS	-50 to +250 °C
natural water according to DIN EN 27888	0 to 36 °C
natural water with expanded temperature range[b]	0 to 100 °C
ASTM D-1125-95 (neutral, alkaline, and acidic impurities)	0 to 100 °C
NaOH 0 to 12 %	0 to 90 °C
NaOH 25 to 50 %	10 to 90 °C
HNO_3 0 to 25 %	0 to 80 °C
HNO_3 36 to 82 %	-20 to +65 °C
H_2SO_4 0 to 28 %	-17 to +104 °C
H_2SO_4 36 to 85 %	-17 to +115 °C
H_2SO_4 92 to 99 %	-17 to +115 °C
HCl 0 to 18 %	10 to 65 °C
HCl 22 to 44 %	-20 to +65 °C

[a] TC: temperature coefficient

[b] The temperature compensation "natural water with expanded temperature range" extends beyond the standardized temperature thresholds of DIN EN 27888.

23.2.6 Measuring circuit monitoring, optional boards

Input/Sensor	Underrange / overrange	Short circuit/ sensor break	Line break	Special features
pH-value (glass electrode)	Yes	Configurable Impedance measurement[a]	Configurable Impedance measurement[a]	-
pH-value (ISFET)	Yes	No[b]	No[b]	-
Resistive conductivity	Yes	No[b]	Configurable	Only with 4-wire circuit[a]
Inductive conductivity	Yes	No[b]	No[b]	-
Universal input for connection of: voltage/current signal, RTD temperature probe	Yes	No[b]	No[b]	-
Universal input for connection of: resistance transmitter	No[b]	No[b]	No[b]	-

[a] With impedance monitoring and detection of deposits, the sensor alarm is tripped in case of a fault. Monitoring via impedance measurement can also be activated.
The following points should be observed to ensure correct function:

Impedance measurements are possible only with glass-based sensors.

Sensors must be connected directly to an analysis input for pH/Redox/NH_3 on the device.

Impedance converters must not be installed in the measuring circuit.

The maximal admissible cable length between sensor and device is 10 m.

Liquid resistance has a direct impact on the measurement result. It is therefore advisable to activate the impedance measurement in liquids at a minimum conductivity of approx. 100 µS/cm.

[b] Errors in the measuring circuit (short circuit or line break) lead to display errors (underrange or overrange or inadmissible value).

23 Technical data

23.3 Analog outputs of base unit and optional boards

Signal type	Signal range	Admissible load resistance	Accuracy	Ambient temperature influence
Voltage signal	0 to 10 V	> 500 Ω	≤ 0.25 %	≤ 100 ppm / K
Current signal	0/4 to 20 mA	< 450 Ω	≤ 0.25 %	≤ 100 ppm / K

23.4 Digital inputs base unit

Designation	Input frequency ranges	Min. pulse duration		Signal type	Switching thresholds[a]	
		On	Off		On	Off
IN 1[b]	≤ 1 Hz	300 ms	300 ms	Configurable as: potential-free contact, or ext. voltage supply (maximal 28 V)	> 8 V > 1.8 mA	< 5 V < 1.2 mA
IN 2 to 3[b,c] Switching signal	≤ 1 Hz	30 µs	30 µs			
IN 2 to 3[b,c] Flow	3 to 300 Hz 300 Hz to 10 kHz	30 µs	30 µs			

[a] This specification is relevant only if the Ext. voltage supply is selected under the “Contact” point in the Configuration. Sensors and transmitters should be supplied from voltage supply outputs on the JUMO AQUIS touch P. An externally supplied voltage signal must not have a voltage over 28 V.

[b] All digital inputs IN 1 to 3 are suitable for connecting proximity switches. Recommended types are: Wachendorff P2C2B1208NO3A2 and Balluff BES M12EG-PSC80F-BP03.

[c] Digital inputs IN 2 and IN 3 can be used for paddlewheel flow sensors (water meters) or magnetic-inductive flow meters (square-wave signal), for example. The input frequency depends on the configured measurement principle in the flow function.

23.5 Digital inputs optional boards

Max. number of retrofittable digital inputs	Max. pulse frequency	Min. pulse duration		Signal type
		On	Off	
max. 2 optional boards with 3 digital inputs each	1 Hz	300 ms	300 ms	Potential-free contact

23.6 Digital outputs, power supply unit board

Designation	Switching output	Ampacity at resistive load	Contact life[a]
OUT 1	Relay, changeover contact	3 A at AC 250 V	150,000 switching cycles
OUT 2	Relay, changeover contact		

[a] The maximal ampacity of the contacts must not be exceeded.

23.7 Digital outputs, optional boards

Optional card	Switching output	Ampacity at resistive load	Contact life[a]	Special features
Relay output, dual normally open contacts	2 normally open contacts[b]	3 A at AC 250 V	150,000 switching cycles	-
Relay output, single Changeover contact	1 changeover contact			-
Solid state relay triac	Switching output with triac (protected by varistor)[c]	1 A at AC 230 V	wear-free	-
PhotoMOS®[e] solid state relay	Switching output with PhotoMOS®[d]	200 mA at DC 45 V and/or AC 30 V	wear-free	not short-circuit-proof; max. voltage DC 45 V AC 30 V
Logic output 0/12 V	High/low signal	20 mA[e]	wear-free	-
Logic output 0/22 V	High/low signal	30 mA[e]	wear-free	-

[a] The maximal ampacity of the contacts must not be exceeded.
[b] Combining a mains voltage circuit with a protective low-voltage circuit on the "dual normally open contact" option is not admissible.
[c] A varistor protects the triac against excessive voltages such as those that can occur during switching.
[d] PhotoMOS® is a registered trademark of Panasonic.
[e] Current limiting via the logic output of the device

23.8 Voltage supply outputs, optional board

Designation	Output voltage	Ampacity	Connection
DC 24 V voltage supply for external transmitters[a]	DC 24 V +5 / -5 %	42 mA	Screw terminals
DC ±5 V voltage supply (e.g. for ISFET pH-sensors)	DC +5 V +10 / 0 % (between terminals 3 and 4)	150 mA	
	DC -5 V ±15 % (between terminals 5 and 4)	30 mA	

[a] An optional board for voltage supply outputs accommodates all the outputs listed in this table. A maximum of 1 such optional board can be integrated into a device.

23 Technical data

23.9 Interfaces

23.9.1 Serial interface RS485 (base unit)

Protocol	Data formats[a]	Device addresses as slave	Baud rates in baud	Connection
Modbus slave Modbus master Modbus digital sensors	8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity	1 to 254	9600 19200 38400	Screw terminals

[a] Specification in useful bit - stop bit - parity format. Therefore, the frame always comprises 8 useful bits and 1 stop bit. Only the parity is differentiated.

23.9.2 Serial Interface RS422/485 (optional board)

Protocol	Data formats[a]	Device addresses as slave	Baud rates in baud	Connection
Modbus slave Modbus master Modbus digital sensors	8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity	1 to 254	9600 19200 38400	Screw terminal

[a] Specification in useful bit - stop bit - parity format. Therefore, the frame always comprises 8 useful bits and 1 stop bit. Only the parity is differentiated.

23.9.3 PROFIBUS-DP (optional board)

Protocol	Data formats[a]	Device addresses	Baud rates	Connection
DP-V0	Big Endian Little Endian	0 to 127	9.6 kBaud to 12 MBaud	D-sub socket 9-pole 

[a] Big Endian corresponds to the Motorola® data format and Little Endian to Intel® data format.

23.9.4 Scanning cycle times for digital sensors

with up to 2 digital sensors with baudrate = 9600 and generally with baud rate > 9600 baud[a]	500 ms
at baud rate = 9600 baud and more than 2 digital sensors on the bus[b]	1 s

[a] Baud rates above 9600 are supported only by JUMO tecLine sensors and JUMO sensors with JUMO digiLine electronics. JUMO ecoLine sensors support only a baud rate of 9600.

[b] For JUMO ecoLine O-DO sensors, the sample rate can be adjusted (1 to 999 s). JUMO ecoLine NTU sensors have a fixed sample rate of 1 s.

23.9.5 Ethernet optional board (10/100Base-T)

Function	Use	Application protocol/ program	Special features	Connection
Web server	Online visualization via web browser	HTTP	Editable via HTML Editor	RJ 45 socket 
E-mail/SMS text message[a]	E-mail dispatch via SMTP server Transmission as SMS text message	SMTP	5 e-mail templates can be stored, up to 3 recipients for each e-mail template	
Modbus TCP/IP	Process data exchange with Modbus users as slave or master[b]	Modbus TCP/IP	-	
Automatic IP-configuration	Network administration[c]	DHCP	-	
Setup via PC	Device settings via PC setup program	JUMO PC setup program (HTTP)	-	
Recording function[d]	Extract, archive, evaluate measurement data	JUMO PCC and PCA 3000	-	

[a] The e-mail function allows the device, when triggered by internal and/or external binary signals, to send hard-programmed messages. This requires the data of an SMTP server (E-mail intermediate server) to be known. The e-mail function can be configured exclusively via the PC setup program.

[b] Modbus TCP/IP enables Modbus users to communicate via a LAN, provided this is connected to the LAN (e.g. via gateways). You can find further information on this in the interface description of the JUMO AQUIS touch P.

[c] Enlist the help of your network administrator or an IT specialist for the IP-configuration.

[d] The recording function stores measurement data in a ring buffer inside the device. Further details appear on ⇨ Page 431.

23.9.6 USB interfaces

Interface	Use	Support	Connection	version
USB Host interface	Extract measurement data memory[a], Read/write device settings, Save service data[b] Update device software	USB flash drive	USB port Type A 	USB 2.0
USB device interface	Device setting via PC setup program, Extract, archive, evaluate measurement data	JUMO PC setup program, JUMO PCC/PCA 3000 software	USB port Type Mini-B 	

[a] The recording function stores measurement data in a ring buffer inside the device.
[b] Service data can be stored on a USB flash drive for diagnostic purposes.

23.10 Electrical data

Voltage supply (switch-mode)	AC 110 to 240 V +10/-15%; 48 to 63 Hz or AC/DC 24 V +30/-25 %; 48 to 63 Hz
electrical safety	According to EN 61010, part 1 overvoltage category III, pollution degree 2
Max. power consumption AC 110 to 240 V AC/DC 24 V	 27.9 VA (11.7 W at 230 V) 25.2 VA (14.7 W at DC 24 V)
Data backup	Flash memory
Electrical connection	at the back via screw terminals Specifications for conductor cross-sections ⇨ Chapter 6.2.2 "Conductor cross-sections for base unit and power supply unit", page 39
electromagnetic compatibility (EMC): Interference emission Interference immunity	DIN EN 61326-1 Class A – only for industrial use – Industrial requirement

23.11 Screen Touchscreen

Type	TFT-touchscreen
Touchscreen sensors	Resistive (can also be operated wearing gloves)
Display protection	Front/design film for protection against damage and scratches
Size	3.5"
Dissolution	320 × 240 pixel
Color depth	256 colors
Viewing angle	Horizontal: ±65° Vertical: -65 to +40°

23 Technical data

23.12 Housing

geographic height for operation	maximum 2000 m above sea level
Housing type	Plastic front frame with metal case barrel (for use indoors only)
Materials	Plastic front panel UL 94 V0 Case barrel from zinc-plated steel sheet
Dimensions of the front	96 mm × 96 mm
Dimensions of the panel cut-out	92 mm × 92 mm Tolerance = +0.8 mm
Mounting depth	
without Ci-conductivity sensor	130.9 mm
with Ci-conductivity sensor	283.3 mm (including manoeuvring space for sensor cable)
Panel thickness	Max. 5 mm
Minimum distance to other operating equipment	from edge of the panel cut-out horizontal 35 mm, vertical 80 mm
Ambient temperature	-5 to +50 °C
Storage temperature	-30 to +70 °C
Resistance to climatic conditions	Relative humidity < 85% annual average, no condensation
Operating position	Any (with due consideration for the viewing angle of the screen)
Protection type	According to DIN EN 60529
Case front in panel mounting	IP66
Metal case barrel	IP20
Weight (fully fitted)	approx. 1000 g

23.13 Functions

23.13.1 Controller channels

Quantity	4
Controller type	Two-state controller Three-state controller Continuous controller Coarse/fine controller Modulating controller proportional controller with integrated actuator driver
Controller structure	P, PI, PD, PID
Controller outputs	For each controller channel, 2 outputs configurable as: pulse length output, pulse frequency output (maximal 240 pulses per minute), continuous output
Disturbance feedforward control	multiplicative and/or additive[a]
Autotuning	Step response method
Sampling rate	250 ms

[a] Ena. variable disturbance permits consideration of influencing variables in the process environment beyond the actual value alone. This keeps the control response stable, even when fluctuations in such ambient conditions occur.

23.13.2 Recording function

	Data monitor	**Recording function (also available)**
Number of groups[a]	4	4
Number of input variables per group	4× analog 3× digital	4× analog 3× digital
Recording / Memory rate	1 to 3600 s	1 to 3600 s
Memory values	Current value Average value Minimum value Maximum value	Current value Average value Minimum value Maximum value
Size of the ring buffer[b]	sufficient for 150 entries[c]	sufficient for approx. 31 million entries[c]
History function[d]	No	Yes
Archiving/evaluation	No	Yes (via JUMO PCA3000 evaluation software)

[a] A user configurable set of input variables can be pooled in one group.
Each group has its own display screen. The group affiliation is considered for data storage to enable evaluation via PC.

[b] The measurement data are stored in a ring buffer. When the ring buffer is full, the recording function begins at the start of the ring buffer by overwriting the measuring value history.

[c] One entry contains 3 analog values and 3 binary values. The sum total of all 4 groups is indicated.

[d] The history function allows the user to scroll the diagram back in the recording time period. All measured data stored in the ring buffer can thus be viewed on the device.

23.13.3 Customer-specific linearization

Number of grid points[a]	up to 40 value pairs
Interpolation[b]	linear
Formula entry[c]	4th degree polynominal

[a] An approximate characteristic line can be entered by inputting grid points (value pairs of the customer-specific characteristic line). Kennlinie) kann eine genäherte Kennlinie eingegeben werden.

[b] Linear interpolation means forming a slope function from 2 grid points.

[c] As an alternative to entering support points, a customer-specific characteristic curve can also be entered as a formula in the form of a polynomial.

23.14 Approvals/approval marks

c UL us	
Test facility	Underwriters Laboratories
Certificate/certification number	E201387
Inspection basis	UL 61010-1 (3rd Edition), CAN/CSA-C22.2 No. 61010-1 (3rd Edition)
Valid for	Type 202580/...
DNV GL	
Test facility	DNV GL
Certificate/certification number	TAA000014K
Inspection basis	Class Guideline DNVGL-CG-0339
Valid for	Type 202580/...

23 Technical data

24.1 Troubleshooting and remedies for digital sensors

24.1.1 Possible faults on sensors with JUMO digiLine electronics

Fault symptom	Possible cause	Remedy
A sensor is not detected after being connected and is also not visible for manual linking (⇨ .Chapter "Submenu for linking", page 101).	The serial interface of the device concerned is configured incorrectly.	Check the following serial interface setting: **Protocol:** Modbus digital sensors
	More than 6 digital sensors were connected.	Ensure that no more than 6 digital sensors are connected to a JUMO AQUIS touch P.
	The voltage supply for powering the sensor electronics is inadequate.	Ensure compliance with the specifications in the tables for planning the cabling for digital sensors. ⇨ Chapter 24.2 "Planning the cabling for digital sensors", page 441

Fault symptom	Possible cause	Remedy
Sensors are not linked	The JUMO AQUIS touch P cannot unambiguously assign the sensors to specific inputs for digital sensors. Possible causes: • Several sensors with JUMO digiLine electronics of the same kind that were not yet linked to the device were connected simultaneously. • Several inputs were configured for digital sensors of the same kind and show the status "Installation".	Follow the instructions in the operating manual for startup of digital sensors. Sensors with JUMO digiLine electronics of the same kind must be put into operation individually. Sensors with JUMO digiLine electronics can only be linked to inputs for digital sensors if the configuration of the input matches the type of sensor. If "TAG check" is activated in the configuration of an input for digital sensors, the "Sensor TAG" must match the "TAG number" in the configuration of the JUMO digiLine electronics to be linked. ⇨ Chapter 7.2 "Digital sensors", page 72 ⇨ Chapter 8.2.7 "Digital sensors", page 99
	"TAG check" is activated in the configuration of the input for digital sensors concerned and the "Sensor TAG" does not match the "TAG number" in the configuration of the JUMO digiLine electronics to be linked.	
	No suitably configured input for digital sensors is available for the type of sensor (status "Installation").	
	The interface configuration of the JUMO digiLine electronics concerned does not match the interface settings of the JUMO AQUIS touch P (baud rate or data format)	Perform a manual bus scan (⇨ Chapter "Submenu for linking", page 101).
	The data of JUMO digiLine electronics required for linking do not match any configured input for digital sensors, because a sensor with JUMO digiLine electronics was replaced or removed from the bus and incorrectly reconfigured via the JUMO DSM software.	Try to link the sensor with JUMO digiLine electronics through a manual bus scan (⇨ Chapter "Submenu for linking", page 101). If this fails, check the settings of the JUMO digiLine electronics and of the corresponding input for digital sensors. **Identical type information** must be set on both sides. When the TAG test is activated, the **TAG number** must be identical on both sides.

Fault symptom	Possible cause	Remedy
Some of the connected sensors malfunction sporadically. (bus status appears as "Yellow" in the title bar of the user interface and in the "Alarm list")[a]	Poor contact in the bus cabling	Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage. The occurrence and clearing of bus faults is recorded in the "Event list". This allows you to use the entries to investigate sporadic bus faults.
Individual sensors malfunction continuously. ("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")	Poor contact in the bus cabling	Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage.
	Defect in the sensor electronics	Replace the sensor electronics.
All sensors connected to the bus simultaneously malfunction continuously. ("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")	The bus voltage supply has failed.	Diagnose the failure of the voltage supply with a multimeter and replace the faulty voltage source or correct the short-circuit in the voltage supply.

[a] ⇨ Chapter 8.3.1 "Alarm list", page 105 if a "Bus fault" is signaled.

24.1.2 Possible faults on digital JUMO ecoLine and tecLine sensors

Fault symptom	Possible cause	Remedy
A sensor is not detected after being connected and is also not visible for manual linking (⇨ .Chapter "Submenu for linking", page 101).	The serial interface of the device concerned is configured incorrectly.	Check the following serial interface setting: **Protocol:** Modbus digital sensors **Baudrate** • with JUMO ecoLine sensors: 9600 • only JUMO tecLine sensors and sensors with JUMO digiLine electronics: 9600, 19200 or 38400 **Data format** • with JUMO ecoLine sensors: 8 - 1 - no parity • only JUMO tecLine sensors and sensors with JUMO digiLine electronics: 8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity
	Two or more sensors of the same kind were connected.	Follow the instructions in the operating manual for startup of digital sensors. Digital JUMO ecoLine and tecLine sensors must be put into operation individually. ⇨ Chapter 7.2 "Digital sensors", page 72 ⇨ Chapter 8.2.7 "Digital sensors", page 99
	Several digital JUMO ecoLine or tecLine were connected to the same device address, causing collisions during bus communication.	
	More than 6 digital sensors were connected.	Ensure that no more than 6 digital sensors are connected to a JUMO AQUIS touch P.
see previous page	The voltage supply for powering the sensor electronics is inadequate.	Ensure compliance with the specifications in the tables for planning the cabling for digital sensors. ⇨ Chapter 24.2 "Planning the cabling for digital sensors", page 441

Fault symptom	Possible cause	Remedy
A sensor is not detected after being connected and is also not visible for manual linking (⇨ .Chapter "Submenu for linking", page 101).	The device address of the sensor is outside the range provided for the sensor type.	The device address must be set to the base address for the particular sensor type using the JUMO DSM software. Then, the sensor must be put into operation at the JUMO AQUIS touch P (initial startup). **Base addresses** • JUMO ecoLine O-DO (Type 202613): 10 • JUMO tecLine Cl2 (Type 202630): 20 • JUMO tecLine TC (Type 202631): 30 • JUMO ecoLine NTU (Type 202670): 40 • JUMO tecLine O3 (Type 202634): 50 • JUMO tecLine H2O2 (Type 202636): 60 • JUMO tecLine PAA (Type 202636): 70 • JUMO tecLine ClO2 (Type 202634): 80 • JUMO tecLine BR2 (Type 202637): 90 • JUMO tecLine Cl2 (Type 202638): 100
Sensors are not linked	No suitably configured input for digital sensors is available for the type of sensor (status "Installation").	Digital JUMO ecoLine and JUMO tecLine sensors can only be linked to inputs for digital sensors if the configuration of the input matches the type of sensor.
Some of the connected sensors malfunction sporadically. ("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")	Poor contact in the bus cabling	Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage. The occurrence and clearing of bus faults is recorded in the "Event list". This allows you to use the entries to investigate sporadic bus faults.
Individual sensors malfunction continuously. ("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")	Poor contact in the bus cabling	Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage.
	Defect in the sensor electronics	Replace the sensor electronics.

Fault symptom	Possible cause	Remedy
All sensors connected to the bus simultaneously malfunction continuously. ("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")	The bus voltage supply has failed.	Diagnose the failure of the voltage supply with a multimeter and replace the faulty voltage source or correct the short-circuit in the voltage supply.

24.2 Planning the cabling for digital sensors

24.2.1 Introduction

JUMO offers a number of different digital sensors for the JUMO AQUIS touch P. In addition to the voltage outputs of the JUMO AQUIS touch P, there is also the possibility to supply the bus by means of a power supply unit in conjunction with the JUMO digiLine hub to ensure a stable voltage supply for all sensors on the JUMO digiLine bus. Planning correct installation of the various digital sensors from JUMO is discussed in detail in the following chapters.

24.2.2 Voltage supply to the bus with DC 5 V from a JUMO AQUIS touch P

The cable length information in this subchapter applies when supplying **JUMO ecoLine sensors as well as pH, redox, and temperature sensors with** JUMO digiLine electronics from a DC 5 V voltage supply output on the JUMO AQUIS touch P. In this case, stub lines can also be supplied from a JUMO digiLine hub or through use of JUMO Y-splitters. If a JUMO digiLine hub is used, the slide switch on the JUMO digiLine hub must be set to DC 5 V as input voltage. In this setting, the DC 5 V input voltage is passed through to the outputs of the JUMO digiLine hub.

Bus cabling in line topology

In the line topology, the bus line must be provided with terminating resistors at both ends wherever possible, in order to avoid transmission interference through reflections. If JUMO ecoLine sensors are used, however, terminating resistors must not be employed. You should therefore use terminating resistors only in a JUMO digiLine bus without JUMO ecoLine sensors. M12 terminating connectors are available from JUMO for the bus termination.
⇨ Chapter 4.4 "Accessories", page 27
Terminating resistors can be activated via DIP switch on the options board for serial interface RS422/485.
⇨ Chapter "Interfaces for data and bus communication - Optional boards", page 66

Sensor type	Max. length of bus line[a]	Max. length of stub lines[b]	Max. number of connectable sensors	Comment
JUMO digiLine pH/ ORP/T	100 m	10 m	6	max. admissible voltage drop between DC 5 V supply and the last sensor: 1.0 V
JUMO ecoLine O-DO JUMO ecoLine NTU	100 m	10 m	6	Bus termination not admissible; max. admissible voltage drop between DC 5 V supply and the last sensor: 1.3 V
JUMO digiLine CR/Ci	Because of the energy requirement, installation of a JUMO digiLine hub with separate power supply the unit is required for connection of JUMO digiLine CR/Ci devices. The voltage supply from the JUMO AQUIS touch P is not sufficient in this case. ⇨ Chapter 24.2.5 "Voltage supply of the bus for JUMO digiLine CR/Ci", page 448			

[a] The maximum length of the bus line depends on the number and type of connected sensors and on how they are distributed along the bus line. Due to the widely varying current consumptions of the different sensor types, it is difficult to state a generate value that will apply for all installation situations. In case of doubt, it is advisable to carry out a voltage drop calculation during the planning phase (⇨ Chapter 24.2.6 "Voltage drop calculation", page 449).

[b] Stub line from a JUMO digiLine hub or Y-splitter up to a JUMO ecoLine sensor or a sensor with JUMO digiLine electronics

Bus cabling in star topology

Bus terminations should not be used for star topology (with stub line). Transmission over stub lines is unproblematic. The use of numerous terminating resistors in a bus, however, can severely disrupt the signal.

Sensor type	Maximum length per branch	Max. number of connectable sensors	Comment
JUMO digiLine pH/ ORP/T	50 m	6	Bus termination is not permissible
JUMO ecoLine O-DO JUMO ecoLine NTU	50 m	6	Bus termination is not permissible
JUMO digiLine CR/Ci	Because of the energy requirement, installation of a JUMO digiLine hub with separate power supply the unit is required for connection of JUMO digiLine CR/Ci devices. The voltage supply from the JUMO AQUIS touch P is not sufficient in this case. ⇨ Chapter 24.2.5 "Voltage supply of the bus for JUMO digiLine CR/Ci", page 448		

24.2.3 Voltage supply to the bus with DC 5 V from a JUMO digiLine hub

The line length specifications in this subchapter apply when supplying **JUMO ecoLine sensors and sensors with JUMO digiLine electronics** with DC 5 V from a JUMO digiLine hub. In this case, the JUMO digiLine hub must be supplied with DC 24 V. The slide switch on the JUMO digiLine hub must be set to the position for DC 24 V as the input voltage. The electronics of the JUMO digiLine hub generate the bus supply voltage of DC 5 V internally and supply its outputs with this voltage.

Bus cabling in line topology

In the line topology, the bus line must be provided with terminating resistors at both ends wherever possible, in order to avoid transmission interference through reflections. If JUMO ecoLine sensors are used, however, terminating resistors must not be employed. You should therefore use terminating resistors only in a JUMO digiLine bus without JUMO ecoLine sensors. M12 terminating connectors are available from JUMO for the bus termination.
⇨ Chapter 4.4 "Accessories", page 27
Terminating resistors can be activated via DIP switch on the options board for serial interface RS422/485.
⇨ Chapter "Interfaces for data and bus communication - Optional boards", page 66

Sensor type	Max. length of bus line[a]	Max. length of stub lines[b]	Max. number of connectable sensors	Comment
JUMO digiLine pH/ ORP/T	200 m	10 m	6	-
JUMO ecoLine O-DO JUMO ecoLine NTU	200 m	10 m	6	Bus termination is not permissible
JUMO digiLine CR/Ci	Because of the energy requirement, installation of a JUMO digiLine hub with separate power supply the unit is required for connection of JUMO digiLine CR/Ci devices. The voltage supply from the JUMO AQUIS touch P is not sufficient in this case. ⇨ Chapter 24.2.5 "Voltage supply of the bus for JUMO digiLine CR/Ci", page 448			

[a] The maximum length of the bus line depends on the number and type of connected sensors and on how they are distributed along the bus line. Due to the widely varying current consumptions of the different sensor types, it is difficult to state a generate value that will apply for all installation situations. In case of doubt, it is advisable to carry out a voltage drop calculation during the planning phase (⇨ Chapter 24.2.6 "Voltage drop calculation", page 449).

[b] Stub line from a JUMO digiLine hub or Y-splitter up to a JUMO ecoLine sensor or a sensor with JUMO digiLine electronics

Bus cabling in star topology

Bus terminations should not be used for star topology (with stub line). Transmission over stub lines is unproblematic. The use of numerous terminating resistors in a bus, however, can severely disrupt the signal.

Sensor type	Maximum length per branch	Max. number of connectable sensors	Comment
JUMO digiLine pH/ ORP/T	50 m	6	_
JUMO ecoLine O-DO JUMO ecoLine NTU	50 m	6	Bus termination is not permissible
JUMO digiLine CR/Ci	Because of the energy requirement, installation of a JUMO digiLine hub with separate power supply the unit is required for connection of JUMO digiLine CR/Ci devices. The voltage supply from the JUMO AQUIS touch P is not sufficient in this case. ⇨ Chapter 24.2.5 "Voltage supply of the bus for JUMO digiLine CR/Ci", page 448		

24.2.4 Voltage supply to the bus with DC 24 V

The cable length information in this subchapter applies when supplying **digital JUMO tecLine sensors** with DC 24 V. In this case, stub lines can also be supplied from a JUMO digiLine hub or through use of JUMO Y-splitters. If a JUMO digiLine hub is used, the slide switch on the JUMO digiLine hub must be set to the correct position for the voltage supply being used. There are two possibilities:

- DC 24 V voltage supply from the voltage supply output on the JUMO AQUIS touch P via the bus input of the JUMO digiLine hub
- DC 24 V voltage supply through a separate power supply unit for the JUMO digiLine hub (available from JUMO, part no.: 00646871)

In both settings, the respective DC 24 V input voltage is fed through to all bus connections on the JUMO digiLine hub.

Bus cabling in line topology

In the line topology, the bus line must be provided with terminating resistors at both ends wherever possible, in order to avoid transmission interference through reflections. If JUMO ecoLine sensors are used, however, terminating resistors must not be employed. You should therefore use terminating resistors only in a JUMO digiLine bus without JUMO ecoLine sensors. M12 terminating connectors are available from JUMO for the bus termination.
⇨ Chapter 4.4 "Accessories", page 27
Terminating resistors can be activated via DIP switch on the options board for serial interface RS422/485.
⇨ Chapter "Interfaces for data and bus communication - Optional boards", page 66

Sensor type	Max. length of bus line[a]	Max. length of stub lines[b]	Max. number of connectable sensors	Comment
digital JUMO tecLine sensors (Types 20263x)	100 m	10 m	6	max. admissible voltage drop between DC 24 V supply and the last sensor: 1.5 V

[a] The maximum length of the bus line depends on the number and type of connected sensors and on how they are distributed along the bus line. Due to the widely varying current consumptions of the different sensor types, it is difficult to state a generate value that will apply for all installation situations. In case of doubt, it is advisable to carry out a voltage drop calculation during the planning phase (⇨ Chapter 24.2.6 "Voltage drop calculation", page 449).

[b] Stub line from a JUMO digiLine hub or Y-splitter up to a JUMO tecLine sensor.

Bus cabling in star topology

Bus terminations should not be used for star topology (with stub line). Transmission over stub lines is unproblematic. The use of numerous terminating resistors in a bus, however, can severely disrupt the signal.

Sensor type	Maximum length per branch	Max. number of connectable sensors	Comment
digital JUMO tecLine sensors (Types 20263x)	50 m	6	Bus termination is not permissible

24.2.5 Voltage supply of the bus for JUMO digiLine CR/Ci

Because of their high energy requirement, conductivity sensors with JUMO digiLine electronics (JUMO digiLine CR/Ci, Types 20276x) may only be connected if a JUMO digiLine hub is used. Each hub must be supplied separately with DC 24 V. If necessary, separate power supply units and connecting cables with appropriately sized wires must be used. Only one JUMO digiLine electronics may be connected to each output of the hub. The maximum allowed length of the stub line between the hub and sensor with JUMO digiLine electronics is 10 m. If a longer length is needed, an additional hub must be used.

Sensor type	Max. length of bus line[a]	Max. length of stub lines[b]	Max. number of connectable sensors	Comment
JUMO digiLine pH/ ORP/T	200 m	10 m	6	-
JUMO ecoLine O-DO JUMO ecoLine NTU	200 m	10 m	6	Bus termination is not permissible
JUMO digiLine CR/Ci	200 m	10 m	6	-

[a] The maximum length of the bus line depends on the number and type of connected sensors and on how they are distributed along the bus line. Due to the widely varying current consumptions of the different sensor types, it is difficult to state a generate value that will apply for all installation situations. In case of doubt, it is advisable to carry out a voltage drop calculation during the planning phase (⇨ Chapter 24.2.6 "Voltage drop calculation", page 449).

[b] Stub line from a JUMO digiLine hub or Y-splitter up to a digital sensor.

24.2.6 Voltage drop calculation

In the case of a JUMO digiLine bus with line topology (Y-adapter or JUMO digiLine hub with 5.3 V through a separate power supply unit) there is inevitably a voltage drop between the supply voltage feed-in and each sensor. The amount of the voltage drop depends on the sensor type, the number of sensors, the length of the bus, and the distribution of the sensors on the bus. Since each sensor requires a minimum voltage for proper operation, the voltage drop needs to be considered in the planning.

In the following description the calculation of the voltage drop is shown with the help of an example.

Bus structure



L_x	Length of line segment x (x = 1, 2, 3)
U_{PS},	Supply voltage at the point of feed-in
U_x	Voltage drop at line segment x
I_x	Current through line segment x
S_x	Sensor x
I_{Sx}	Current consumption of sensor x
U_{Sx}	Supply voltage at sensor x

Step 1: Calculate the current in the individual line segments

For the calculation of the current flowing through a line segment, the partial currents of all sensors, which are supplied via this segment, are added. For the bus structure shown above this means:

$I_1 = I_{S1} + I_{S2} + I_{S3}$
$I_2 = I_{S2} + I_{S3}$
$I_3 = I_{S3}$

The current consumption of a sensor is shown in the following table; it applies for Modbus operation without bus termination and a sampling time of 1 second.

Sensor	Average value of current consumption	Peak value of current consumption
JUMO digiLine pH/ORP/T	approx. 17 mA	approx. 20 mA
JUMO ecoLine O-DO	approx. 4 mA	approx. 50 mA
JUMO ecoLine NTU	approx. 2 mA	approx. 60 mA

In the case of bus termination at both ends (120 ohm), the current consumption increases during communication by up to 55 mA.

When operating with JUMO digiLine protocol, collisions occur on the bus during bus scan; this can also lead to increased current consumption. However, this is usually not critical, since there is no measured value processing during the scan

and therefore the supply voltage of the sensor may be lower.
For sensors of type JUMO digiLine pH/ORP/T, the calculation must be performed with the peak values:
$I_1 = I_{S1} + I_{S2} + I_{S3}$ = 20 mA + 20 mA + 20 mA = 60 mA
$I_2 = I_{S2} + I_{S3}$ = 20 mA + 20 mA = 40 mA
$I_3 = I_{S3}$ = 20 mA
For sensors of type ecoLine O-DO/NTU, the highest peak value is used once and the remaining sensors are considered with their average values. Example for 1 x O-DO and 2 x NTU:
$I_1 = I_{S1} + I_{S2} + I_{S3}$ = 4 mA + 2 mA + 60 mA = 66 mA
$I_2 = I_{S2} + I_{S3}$ = 2 mA + 60 mA = 62 mA
$I_3 = I_{S3}$ = 60 mA
For further calculation it is assumed that the following sensors are used in the bus structure shown above:
Sensor 1: JUMO digiLine pH (use peak value)
Sensor 2: ecoLine O-DO (use average value)
Sensor 3: ecoLine NTU (use peak value)
Thus, the following currents result:
$I_1 = I_{S1} + I_{S2} + I_{S3}$ = 20 mA + 4 mA + 60 mA = 84 mA = **0.084 A**
$I_2 = I_{S2} + I_{S3}$ = 4 mA + 60 mA = 64 mA = **0.064 A**
$I_3 = I_{S3}$ = 60 mA = **0.06 A**

Step 2: Calculate the voltage drop on the individual line segments

The cable lengths of the line segments are **20 m** each.
The voltage drop on a line segment is calculated in accordance with the following formula:
$U_x = \rho \times 2 \times L_x \times I_x / A$; where ρ = 1/56 $\Omega mm^2/m$ and A = 0.34 mm^2
In the above example this means:
$U_1 = \rho \times 2 \times L_1 \times I_1 / A$ = 1/56 $\Omega mm^2/m \times 2 \times$ **20 m × 0.084 A** / 0.34 mm^2 = 0.177 V
Shown in simplified form:
U_1 = 1/56 Ω × 2 × **20 × 0.084 A** / 0.34 = **0.177 V**
U_2 = 1/56 Ω × 2 × **20 × 0.064 A** / 0.34 = **0.135 V**
U_3 = 1/56 Ω × 2 × **20 × 0.06 A** / 0.34 = **0.126 V**



NOTE
The calculation of the voltage drop according to the sample shown is not valid for mixed connection of sensors with 5 V and 24 V voltage supply.

Step 3: Calculate the voltage at the respective sensor

The value of the supply voltage at the respective sensor is given by the supply voltage at the point of feed-in minus the sum of all the voltages which drop on the line segments that are located between the point of feed-in and the sensor. In the above example this means:

$U_{S1} = U_{SV} - U_1 = 5.3\ V - 0.177\ V = 5.123\ V \approx$ **5.1 V**

$U_{S2} = U_{SV} - U_1 - U_2 = 5.3\ V - 0.177\ V - 0.135\ V = 4.988\ V \approx$ **5.0 V**

$U_{S3} = U_{SV} - U_1 - U_2 - U_3 = 5.3\ V - 0.177\ V - 0.135\ V - 0.126\ V = 4.862\ V \approx$ **4.9 V**

The required minimum voltage of the sensors is shown in the following table.

Sensor	Minimum voltage
JUMO digiLine pH/ORP/T	4.2 V
JUMO ecoLine O-DO	5 V
JUMO ecoLine NTU	5 V

The voltage at sensor 1 (JUMO digiLine pH) is well above the minimum value (4.2 V). The voltage at sensor 2 (ecoLine O-DO) roughly corresponds to the minimum value (5 V). For sensor 3 (ecoLine NTU), the voltage is not enough.

NOTE

For the operation of JUMO ecoLine sensors, it is generally recommended to use JUMO digiLine hubs and to generate the DC 5.3 V supply voltage within the JUMO digiLine hub.

NOTE

The voltage drop calculation shown here only applies when using digital sensors of types 202705 (JUMO digiLine pH/ORP/T), 202613 (JUMO ecoLine O-DO) and 202670 (JUMO ecoLine NTU).

部件名称 Product group: 202580/81	有毒有害物质或元素 Hazardous substances					
	铅（Pb）	汞（Hg）	镉（Cd）	六价铬（Cr(VI)）	多溴联苯（PBB）	多溴二苯醚（PBDE）
外壳 Housing (Gehäuse)	○	○	○	○	○	○
过程连接 Process connection (Prozessanschluss)	○	○	○	○	○	○
-螺母 Nut (Mutter)	○	○	○	○	○	○
螺钉 Screw (Schraube)	○	○	○	○	○	○

本表格依据 SJ/T 11364-2014的规定编制。
(This table is prepared in accordance with the provisions of SJ/T 11364-2014.)
O：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。
(O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.)
X：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。
(X: Indicates that said hazardous substance contained in one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572.)

JUMO GmbH & Co. KG
Street address:
Moritz-Juchheim-Straße 1
36039 Fulda, Germany
Delivery address:
Mackenrodtstraße 14
36039 Fulda, Germany
Postal address:
36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
Email: mail@jumo.net
Internet: www.jumo.net

JUMO UK LTD
JUMO House
Temple Bank, Riverway
Harlow, Essex, CM20 2DY, UK
Phone: +44 1279 63 55 33
Fax: +44 1279 62 50 29
Email: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.
6724 Joy Road
East Syracuse, NY 13057, USA

Phone: +1 315 437 5866
Fax: +1 315 437 5860
Email: info.us@jumo.net
Internet: www.jumousa.com